

MAC mini iH Series

MAC mini iH / iHF / iHP
MAC mini iH2 / iHT

User's Manual

Configuration of user's manual

The user's manual consists of the following items.



- Operation Manual
- Parameter • Expansion Manual
- Maintenance Manual
- Connection Manual
- Parts List

Carefully understand conditions such as product specifications, usage limit, etc., before using products.

FOR SAFE OPERATION

This manual is described to help you get the best use from your MAC mini iH series. Improper handling can cause unexpected accidents or damage, therefore read this manual carefully and thoroughly before using the equipment.

Keep this manual handy for easy reference as it will help you use many controls to their full advantage.

F O R Y O U R S A F E T Y	
Before using the equipment, carefully read this instruction manual and familiarize yourself with the equipment and all safety precautions. Safety precautions in this manual are divided into the following two types.	
 DANGER	Indicates an imminently hazardous situation which will result in death or serious injury if proper safety procedures and instructions are not adhered to.
 CAUTION	Indicates a potentially hazardous situation which may result in minor or moderate injury if proper safety procedures and instructions are not adhered to.
There is a possibility that serious accident will be caused by the situation even items described for CAUTION, therefore, be sure to observe contents carefully.	

Reference

- Each manual can't be mentioned about all terms of use though it was intended to be mentioned for the details. In thing not mentioned, consider that it is "IMPOSSIBLE".
- Please understand that the manual may be changed without prior notice because of machine modification, specification change, etc.

1. To Prevent Electric Shock



- ◆ Do not open the cover because any electric shock will be caused.
(High voltage terminals and live parts are exposed in the controller and live parts are remained even if the main power is turned OFF.)
- ◆ Check the voltage with the tester, etc., after the power is turned OFF before performing wiring work and inspection because the electric shock will be caused.
- ◆ Perform the grounding work of Class D (Class No. 3).
- ◆ Only qualified persons shall perform the wiring work and inspection.
- ◆ Never touch the equipment with wet hands because the electric shock will be caused.
- ◆ Do not damage, pull cables forcedly, ride heavy thing on cables, and also do not pinch the cables because the electric shock will be caused. Because electric shock, burning and unexpected motion of machine will be caused.
- ◆ After power is turned OFF, never touch the terminal for 5 minutes because there is a possibility to get an electric shock through residual voltage.

2. To Prevent Fire



- ◆ Install the MAC mini iH away from flammables.
If the machine will be installed on flammables directly or near it, fire will be caused.
- ◆ If the controller fails, turn OFF power because fire occurs if over-current flows continuously.

3. To Prevent Damage



- ◆ Do not touch the movable parts of machine during operation.
- ◆ Apply only voltage specified in this manual to each terminal. Improper voltage will cause the equipment damage.
- ◆ Do not connect terminal in mistake because the machine will be broken or damaged.
- ◆ Do not touch the fan and other parts of the MAC mini iH because they become high temperature while the equipment is charged and shortly after the power is turned OFF.

4. Other Precautions

Observe the following precautions at all times. Mishandling will cause machine trouble, personal injury and electric shock.

(1) Transportation and Installation



- ◆ Transport the machine and equipment by the ways suited to their weights.
- ◆ Do not stack the equipment at multistage.
- ◆ Install the equipment at the floor where it withstands equipment weight and at wide area where operator can work without danger.
- ◆ Do not climb on the equipment or place any objects on it.
- ◆ Install the equipment in the specified orientation.
- ◆ Ensure a specified space between the controller and the inside of control panel or other equipment. Also, arrange the equipment so that external cables are easily routed and space the controller at least 0.2m or more from the floor.
- ◆ Do not enter the screws, metal pieces of electrically conductive objects or flammable foreign matters of oil, etc., inside of the controller.
- ◆ Since the controller is the precision equipment, do not drop it or apply any impact shock to the controller.
- ◆ Install the pendant at place where it will be arranged 0.6m or more from a working floor level that operator stands. Also, install the pendant so that the LCD of pendant can be checked.

(2) Environment



- ◆ Install the main controller in the environment to pollution level 2.
- ◆ Ensure a specified space between the controller and the inside of control panel or other equipment.
- ◆ Do not enter the screws, metal pieces of electrically conductive objects or flammable foreign matters of oil, etc., inside of the controller.
- ◆ Store and use the MAC mini iH under the environment conditions described in the Instruction Manual.
(Ambient temperature, ambient humidity, storage (transportation) temperature, storage humidity, etc.)

(3) Wiring



- ◆ Install the circuit breaker that is an optimum for the insulation of IEC60947-2. Each rated current for circuit breaker as follows:

Controller Type	Capacity of Circuit Breaker
MAC mini iHF	5A
MAC mini iH	10A
MAC mini iH2/iHT	15A

- ◆ Route cables correctly and securely.
- ◆ Securely connect cables so as not to be loosened into a chain reaction.
When connecting the cables (CB1i cable) to the rotary table, don't bend them forcedly. Also, don't apply stress to cables.
Route cables so that they do not interfere with the machine while the machine is operating.
In case a ground-fault circuit breaker is used, please use that to which 100mA or more of sensed current and time of operation are 0.1 seconds or more, or performed the measure against high frequency for a preventing-incorrect operation by high-frequency of motor sake.
When you cannot perform change of the ground-fault circuit breaker of the present attachment, please supply a power supply by the following method.
A power supply is supplied from a secondary the transformer of a machine side.
When cannot be carried out, please connect a noise filter to a power supply line.

(4) Adjustment by Trial Run



- ◆ Check and adjust parameters before operation. The equipment may move unexpectedly if any parameter is incorrect.
- ◆ Never adjust the parameter extremely because the equipment becomes unstable.

(5) Precautions



- ◆ Route an external emergency stop circuit so that the equipment can be stopped immediately.
- ◆ Do not disassemble and repair the equipment.
- ◆ Do not modify or remodel the equipment.
- ◆ Minimize the effect of electromagnetic interference with a noise filter, etc.

(6) Countermeasures



- ◆ If an alarm occurs, eliminate the cause and check safety before resetting the alarm, and then restart the equipment.

Configuration

	Item	Specifications																																								
1	Controlled axes	MAC mini iH / iHF : 1 axis (Servo motors 750W / 400W) MAC mini iH2 / iHT : 2 axis (Servomotors 750W+750W / 750W +400W) MAC mini iHP : 1 axis (Servomotors 2KW)																																								
2	Data memory	Backup by EEPROM (Writing frequency: 100000 times)																																								
3	Motor capacity	400W / 750W / 2KW																																								
4	Table I/O	<div>INPUT DC24V 5mA</div> <table> <tr> <th rowspan="2">Input signal name</th><th colspan="2">MAC mini</th></tr> <tr> <th>iH / iHF / iHP</th><th>iH2 / iHT</th></tr> <tr> <td>CLAMP INPUT 1 (BK.C1)</td><td></td><td></td></tr> <tr> <td>UNCLAMP INPUT 1 (BK.UC1)</td><td></td><td></td></tr> <tr> <td>OVERRUN INPUT A1 (OVRUNA1)</td><td></td><td></td></tr> <tr> <td>OVERRUN INPUT B1 (OVRUNB1)</td><td></td><td></td></tr> <tr> <td>CLAMP INPUT 2 (BK.C2)</td><td>-</td><td></td></tr> <tr> <td>UNCLAMP INPUT 2 (BK.UC2)</td><td>-</td><td></td></tr> <tr> <td>OVERRUN INPUT A2 (OVRUNA2)</td><td>-</td><td></td></tr> <tr> <td>OVERRUN INPUT B2 (OVRUNB2)</td><td>-</td><td></td></tr> </table> <div>OUTPUT DC24V 0.5A</div> <table> <tr> <th rowspan="2">Input signal name</th><th colspan="2">MAC mini</th></tr> <tr> <th>iH / iHF / iHP</th><th>iH2 / iHT</th></tr> <tr> <td>BRAKE OUTPUT 1 (BK+1 / BK-1)</td><td></td><td></td></tr> <tr> <td>BRAKE OUTPUT 2 (BK+2 / BK-2)</td><td>-</td><td></td></tr> </table>	Input signal name	MAC mini		iH / iHF / iHP	iH2 / iHT	CLAMP INPUT 1 (BK.C1)			UNCLAMP INPUT 1 (BK.UC1)			OVERRUN INPUT A1 (OVRUNA1)			OVERRUN INPUT B1 (OVRUNB1)			CLAMP INPUT 2 (BK.C2)	-		UNCLAMP INPUT 2 (BK.UC2)	-		OVERRUN INPUT A2 (OVRUNA2)	-		OVERRUN INPUT B2 (OVRUNB2)	-		Input signal name	MAC mini		iH / iHF / iHP	iH2 / iHT	BRAKE OUTPUT 1 (BK+1 / BK-1)			BRAKE OUTPUT 2 (BK+2 / BK-2)	-	
Input signal name	MAC mini																																									
	iH / iHF / iHP	iH2 / iHT																																								
CLAMP INPUT 1 (BK.C1)																																										
UNCLAMP INPUT 1 (BK.UC1)																																										
OVERRUN INPUT A1 (OVRUNA1)																																										
OVERRUN INPUT B1 (OVRUNB1)																																										
CLAMP INPUT 2 (BK.C2)	-																																									
UNCLAMP INPUT 2 (BK.UC2)	-																																									
OVERRUN INPUT A2 (OVRUNA2)	-																																									
OVERRUN INPUT B2 (OVRUNB2)	-																																									
Input signal name	MAC mini																																									
	iH / iHF / iHP	iH2 / iHT																																								
BRAKE OUTPUT 1 (BK+1 / BK-1)																																										
BRAKE OUTPUT 2 (BK+2 / BK-2)	-																																									
5	OUTER INPUT Signals	<div>INPUT DC24V 5mA</div> <table> <tr> <th rowspan="2">Input signal name</th><th colspan="2">MAC mini</th></tr> <tr> <th>iH / iHF / iHP</th><th>iH2 / iHT</th></tr> <tr> <td>START INPUT (ST)</td><td></td><td></td></tr> <tr> <td>STOP INPUT (SP)</td><td></td><td></td></tr> <tr> <td>OUTER EMG. STOP INPUT (EXTEM)</td><td></td><td></td></tr> <tr> <td>CHANNEL SET INPUT (CHSET)</td><td></td><td></td></tr> <tr> <td>CHANNEL SELECT INPUT 0 ~ 3 (CHSEL0 ~ 3)</td><td></td><td></td></tr> <tr> <td>OUTER ZEN INPUT 1 (ZRN1)</td><td></td><td></td></tr> <tr> <td>OUTER RESET (RST)</td><td></td><td></td></tr> <tr> <td>OUTER MODE CHANGE (AUTOSET/MANUALSET)</td><td></td><td></td></tr> <tr> <td>OUTER ZRN INPUT 2 (ZRN2)</td><td>-</td><td></td></tr> </table>	Input signal name	MAC mini		iH / iHF / iHP	iH2 / iHT	START INPUT (ST)			STOP INPUT (SP)			OUTER EMG. STOP INPUT (EXTEM)			CHANNEL SET INPUT (CHSET)			CHANNEL SELECT INPUT 0 ~ 3 (CHSEL0 ~ 3)			OUTER ZEN INPUT 1 (ZRN1)			OUTER RESET (RST)			OUTER MODE CHANGE (AUTOSET/MANUALSET)			OUTER ZRN INPUT 2 (ZRN2)	-									
Input signal name	MAC mini																																									
	iH / iHF / iHP	iH2 / iHT																																								
START INPUT (ST)																																										
STOP INPUT (SP)																																										
OUTER EMG. STOP INPUT (EXTEM)																																										
CHANNEL SET INPUT (CHSET)																																										
CHANNEL SELECT INPUT 0 ~ 3 (CHSEL0 ~ 3)																																										
OUTER ZEN INPUT 1 (ZRN1)																																										
OUTER RESET (RST)																																										
OUTER MODE CHANGE (AUTOSET/MANUALSET)																																										
OUTER ZRN INPUT 2 (ZRN2)	-																																									

6	Outer output signals (Dry contact)	The power specifications of output circuit are to be within range specified to PELV(Protection ultra-low voltage) and to be the following specifications. 25V ACrms / 30V DC		
		Input signal name	MAC mini	
			iH / iHF / iHP	iH2 / iHT
		Optionally completed OUTPUT 1 (G99FIN1)		
		360 completed OUTPUT 1 (360FIN1)		
		ZRN completed OUTPUT 1 (ZRNFIN1)		
		Alarm OUTPUT A,B (ALMOUTA,B)		
		EMG. STOP OUTPUT (EMOUT)		
		Channel No. OUTPUT 0 ~ 6 (CHOUT0 ~ 6)		
		Optionally completed OUTPUT 2 (G99FIN2)	-	
		360 Completed OUTPUT 2 (360FIN2)	-	
		ZRN COMP OUTPUT 2 (ZRNFIN2)	-	
7	Power INPUT Vol.	AC200/230V 1 MAC mini iH / iHF / iH2 / iHT		
		AC200/230V 3 MAC mini iHP		
	Voltage fluctuation	-10% ~ +10%		
	Frequency	50/60Hz		
	INPUT capacity	0.6KVA MAC mini iHF		
		1.0KVA MAC mini iH		
		1.6KVA MAC mini iHT		
		2.0KVA MAC mini iH2		
		2.5KVA MAC mini iHP		
	Momentary power interruption	1-cycle or less		
8	Grounding condition	Class D grounding (Grounding resistance value 100 or less) or more		
	Environment	0 ~ 45		
	Service temp.	-10 ~ 60		
	Storage temp.			
	(Transp. Temp.)	85%RH or less (Condensation or freezing not to be occurred.)		
	Humidity	0.5G or less		
	Vibration proof	1G or less		
	Shock resistant	to pollution level 2.		
	Atmosphere			
9	Sizes W×D×H	328.7×305×190mm (not including convex) MAC mini iH / iHF		
		398.7×400×250mm (not including convex) MAC mini iH2 / iHT / iHP		
10	Weight	14kg MAC mini iH / iHF		
		24kg MAC mini iH2 / iHT / iHP		

OPERATION MANUAL

■ Readers for this manual

Readers for this manual are as follows:

- All persons to use controller.

C o n t e n t s

◆ Main Body ・ Pendant

1	Start-up	01-1
1.1.	POWER ON/OFF	01-1
1.1.1.	Power ON	01-1
1.1.2.	Power OFF	01-1
1.2.	SCREEN CONFIGURATION IN START-UP	01-2
1.2.1.	Sum check situation of servo parameters	01-2
1.2.2.	System information	01-2
1.2.3.	EDIT Information	01-3
2	Key Switches & Display Part	02-1
2.1.	OPERATION SWITCHES	02-2
2.1.1.	Power switch	02-2
2.1.2.	Emergency stop switch	02-2
2.1.3.	ENABLE switch	02-2
2.2.	KEY OPERATION	02-3
2.2.1.	Mode operation key	02-3
2.2.2.	Axis change key	02-3
2.2.3.	Manual operation keys	02-3
2.2.4.	Automatic operation keys	02-4
2.2.5.	Program operation keys	02-5
2.2.6.	Program communication keys	02-7
2.2.7.	Parameter operation keys	02-7
2.2.8.	Parameter communication keys	02-8
2.2.9.	Self-diagnosis operation keys	02-9
2.2.10.	Operation keys in alarm	02-9
2.3.	LAMP INDICATION	02-10
2.3.1.	MODE	02-10
2.3.2.	STATUS	02-11
2.3.3.	STATUS	02-11
2.4.	DATA DISPLAY	02-12
2.4.1.	Data display part	02-12
3	Mode	03-1
3.1.	MODE SELECTION	03-1
3.1.1.	Mode selection	03-1
3.1.2.	External mode selection	03-1
3.2.	OUTLINE OF MODE	03-2
3.2.1.	Outline of mode	03-2

4	Programs	04-1
4.1.	PROGRAM STRUCTURE	04-1
4.2.	PROGRAM AREA STRUCTURE	04-2
4.3.	PROGRAM DISPLAY METHOD	04-3
4.4.	ADDRESS FUNCTIONS	04-5
4.5.	G-CODE FUNCTIONS	04-6
4.5.1.	Non-G-code	04-8
4.5.2.	G04 (DWELL)	04-10
4.5.3.	G07 (LEAD CUT)	04-12
4.5.4.	G08 , G09 (CONT. BUFFER)	04-15
4.5.5.	G10 , G11 (CLAMP UNUSED/USED)	04-18
4.5.6.	G15 , G16 (POS-DEV CHECK VALID/INVALID)	04-20
4.5.7.	G21 (INTERLOCK START)	04-22
4.5.8.	G22 (CONT. START)	04-25
4.5.9.	G23 (MZRN)	04-27
4.5.10.	G24 (WZRN)	04-28
4.5.11.	G25 (LOOP JUMP)	04-30
4.5.12.	G27 (REPEATING)	04-32
4.5.13.	G90 / G91 (ABSOLUTE/INCREMENTAL)	04-35
4.5.14.	G92 (WCRT SYS SET)	04-37
4.5.15.	G97 (BLKFIN NON-OUTPUT)	04-39
4.5.16.	G98 (BLKFIN · G99FIN)	04-41
4.5.17.	G99 (G99FIN OUTPUT)	04-44
4.6.	DIVIDING FEED FUNCTION	04-46
4.6.1.	Dividing feed	04-46
4.7.	SUBPROGRAM FUNCTION	04-47
4.7.1.	Subprogram structure	04-47
4.7.2.	Subprogram example	04-47
5	Program Operation	05-1
5.1.	CHANNEL CALL	05-1
5.1.1.	Channel call	05-1
5.2.	BLOCK NUMBER CALL	05-2
5.2.1.	Former block call	05-2
5.2.2.	Next block call	05-2
5.2.3.	Block number call	05-2
5.3.	PROGRAM INPUT (FOR 1-AXIS)	05-3
5.3.1.	Program examples	05-3
5.3.2.	Program input examples	05-3
5.4.	PROGRAM INPUT (FOR 2-AXIS)	05-6
5.4.1.	Program examples	05-6
5.4.2.	Program input examples	05-6
5.5.	PROGRAM DELETE	05-9
5.5.1.	ALL PRG DEL	05-9
5.5.2.	PRG DEL in channel	05-9
5.5.3.	1 BLOCK DEL	05-10
5.5.4.	1 BLOCK DATA DEL	05-10
5.6.	PROGRAM COPY	05-11
5.6.1.	Program copy between channels	05-11
5.6.2.	1 BLOCK COPY	05-12

6	Operation	O6-1
6.1.	EMERGENCY STOP	O6-1
6.1.1.	To perform EMERGENCY STOP	O6-1
6.1.2.	To release EMERGENCY STOP	O6-1
6.2.	AUTO RUN	O6-2
6.2.1.	Program selection	O6-2
6.2.2.	Mode selection	O6-2
6.2.3.	Program START	O6-2
6.2.4.	To stop program temporarily during execution	O6-3
6.2.5.	To restart program during TEMP. STOP	O6-3
6.2.6.	Program interruption	O6-3
6.3.	MANUAL RUN	O6-4
6.3.1.	Mode selection	O6-4
6.3.2.	Axis selection	O6-4
6.3.3.	Low speed JOG feed	O6-4
6.3.4.	High speed JOG feed	O6-5
6.3.5.	STEP feed	O6-5
6.4.	OVERRIDE	O6-6
6.4.1.	Override display	O6-6
6.4.2.	Override change	O6-6
6.5.	MANUAL PULSE GENERATOR (OPTION)	O6-7
6.5.1.	Conf. display of manual pulse generator	O6-7
6.5.2.	Shifted by manual pulse generator	O6-7
7	Diagnostics	O7-1
7.1.	DIAGNOSTIC SCREEN STRUCTURE / OPERATION	O7-1
7.1.1.	Diagnostic screen structure	O7-1
7.1.2.	Diagnostic screen display	O7-1
7.1.3.	I/O diagnostic display content confirmation	O7-2
7.2.	COMMAND WORK COORDINATE DISPLAY (WP-R)	O7-3
7.3.	COMMAND MACHINE COORDINATE DISPLAY (MP-R)	O7-3
7.4.	REMAINED SHIFT DISPLAY (RD-R)	O7-4
7.5.	EXTERNAL CONNECTION INPUT CONDITION DISPLAY (AC-I)	O7-5
7.6.	TABLE INPUT CONDITION DISPLAY (EA-I)	O7-6
7.7.	EXTERNAL CONNECTION OUTPUT CONDITION DISPLAY (AC-O)	O7-7
7.8.	TABLE OUTPUT CONDITION DISPLAY (EA-O)	O7-8
7.9.	WCRNT ENCODER DATA DISPLAY (WP-E)	O7-9
7.10.	MACHINE COORDINATE ENCODER DATA DISPLAY (MP-E)	O7-9
7.11.	POS-DEV DISPLAY (P-DEV)	O7-10
7.12.	ROTOR ANGLE DISPLAY (ROTOR)	O7-10
7.13.	MZRN DATA DISPLAY (DA-ZP)	O7-11
7.14.	CURRENT % DISPLAY (CUR-LF)	O7-11

8 Program Examples08-1

8.1. UNEQUAL PARTITION 08-1

8.2. EQUIPARTITION..... 08-1

8.3. LOOP JUMPING FUNCTIONS08-2

8.4. REPEATING FUNCTIONS08-2


8.5. SUBPROGRAMS.....08-2

Main Body of MAC mini iH Series



Main Body of MAC mini iH2 Series



Pendant of MAC mini iH Series

1 Start-up

1.1. Power ON/OFF

1.1.1.

Power ON

Turn ON the power switch of the controller.

The sum check of control is performed in start-up.

(1.2 See Screen Configuration in Start-up.)

1.1.2.

Power OFF

Turn OFF the power switch of the controller.

Wait for 5 seconds before turning ON the power again.

※ If the power is turned ON again within 5 seconds, any data memory may be incorrectly stored.

1.2. Screen Configuration in Start-up

When the controller is started, the information and sum check situation for the controller are displayed on the screen and their contents are as follows:

- . Sum check situation of servo parameters
- . System information
- . EDIT information

1.2.1.

Sum check situation of servo parameters

When the power is turned ON, the system checks that the servo parameter stored into memory in previous power shutoff corresponds to the data set value.

Because the set value varies when the servo amp., inside of controller is changed for maintenance, the system encourages the resetting for servo amp., and also gives warning so as to operate the machine in safety.

PARAM CHECK

Check Display for Servo Parameter

When any FAULT occurs by the servo parameter check, the checked number (address) is displayed on the right side of 「 PARAM CHECK 」 on the screen.

When nothing is displayed on the right side of 「 PARAM CHECK 」, the servo parameter means the same content in the previous power shutoff.

※ The servo parameter sum check function can change the content by the parameter. (For details, refer to the explanation of parameters.)

1.2.2.

System information

The version of system program for the controller is displayed and the creation date of software is also displayed on its right side.

Ver100I 2002-04

Version Display


1.2.3.**EDIT Information**

The channel number of program selected in the screen start and the coordinate of machining zero position that the channel is common are displayed.



CH00 A 0.000

EDIT Information for 1 Axis



CH00 A 0.000
B 0.000

EDIT Information for 2 Axis

2 Key Switches & Display Part

Controller's switches and operation keys feature various operations.

During operation, each mode LED and the screen may indicate machine conditions.

- . Operation switches
 1. Power switch
 2. Emergency stop switch
 3. ENABLE switch
- . Operation keys
 1. Mode operation
 2. Axis change operation
 3. Manual operation
 - JOG feed
 - Zero position return
 - Machining zero position return
 4. Automatic operation
 5. Program operation
 6. Program communication
 7. Parameter operation
 8. Parameter communication
 9. Self diagnosis operation
 10. Operation in alarm
- . Lamp indication
 1. MODE
 2. STATUS
 3. CPU status
- . Data display

2.1. Operation switches

2.1.1.

Power switch

Turns ON the power of controller.

When pushing the locker switch to【 I 】side, the power is turned ON and to【 O 】 side, the power is turned OFF.

2.1.2.

Emergency stop switch

This button is pushed when stopping the rotary table urgently.

When the emergency stop button is pushed, the power to the servo is turned OFF and the rotary table stops urgently.

When the emergency stop button is pushed, the table is self-held and it does not return automatically to the zero position. To release the emergency stop switch, manually turn the operation part to right.

To release the emergency stop state, push 『 RESET 』 button manually after releasing the above operation to recover the circuit.

2.1.3.


ENABLE switch

The pendant is equipped with enable switch for 3 positions. When the manual operation and automatic operation from the pendant are performed, place the enable switch to intermediate position.

When the signal of enable switch is not detected (switch release or more pushed) while the machine is running, the machine stops immediately.

Operation of 3-position enable switch

- Switch is not pushed.
..... Position 1: Switch OFF
- Pushed to intermediate position.
..... Position 2: Switch ON
- Pushed over intermediate position.
..... Position 3: Switch OFF



- Even if the switch is returned to position 2 from position 3, the switch does not turn ON.

2.2. Key operation

2.2.1.

Mode operation key

To perform each operation, it is necessary to select each operation mode.

➤ Mode change key



Changes the mode in order.

2.2.2.

Axis change key

Since MAC mini iH2/iHT have two control axes, it is necessary to change the axis when each mode is set.



Changes the display of A-axis/B-axis as often as the switch is pushed.

2.2.3.

Manual operation keys

This key operates and sets the circular table connected to the controller under the manual operation mode.

➤ JOG feed (low speed)



ENABLE switch

Operates the table in CW (Clockwise direction). The table rotates continuously at speed set to PRM005 with the key still pushed.



ENABLE switch

Operates the table in CCW (Counterclockwise direction). The table rotates continuously at speed set to PRM005 with the key still pushed.

➤ Step feed



ENABLE switch
(1-shot pushed)

Pushing this key 1-shot feeds at a step in CW (Clockwise direction). The feedrate is the angle set to PRM006.



ENABLE switch
(1-shot pushed)

Pushing this key 1-shot feeds at a step in CCW (Counterclockwise direction). The feedrate is the angle set to PRM006.


➤ JOG feed (high speed)



ENABLE switch

Operates the table at rapid traverse in CW (Clockwise direction)

The table rotates at speed set to PRM004.



ENABLE switch

Operates the table at rapid traverse in CCW (Counterclockwise direction)

The table rotates at speed set to PRM004.

➤ **M/C zero position return**



ENABLE switch

Returns the table to M/C zero position.

When the STATUS “READY A” or “READY B” lamp lights, the table rotates to the M/C zero position at high speed of PRM003.

When STATUS “READY A” or “READY B” lamp goes out (PRM123=0), the M/C zero position is set at value set to PRM122.

➤ **Machining zero return**



ENABLE switch

Returns the table to the machining zero position at the speed set to PRM003.

➤ **Machining zero position setting**



Sets the current position as the machining zero position.

However, since the priority for keys is established, it is necessary to push the **INPUT** key with the **ORG** key still pushed.

➤ **Override**



Displays the current override state.

CH00 A ovr.100
N000



Increases the override value.

The increased value of override is set to PRM014.



Reduces the override value.

The reduced value of override is set to PRM014.

• **State display**

When the mode is set to “AUTO” or “MANUAL” with the override set to 100%, the mode LED lights and with the override set to the point except 100%, it flickers.

2.2.4.

Automatic operation keys

This key is for operating the program automatically.

➤ **Operation control key**



ENABLE switch

Executes the program operation.

Or, restarts the program while stopping once.



Stops the program once while executing.



Rewinds the program of selected channel to return it to a top block.


2.2.5.

Program operation keys


These keys are used for editing the program to operate the circular table automatically.

(For detailed program, see 4. Program.)

The following procedure is recommended for operating the program under the EDIT mode.

➤ **Address keys**

Pushed when various addresses are selected.

➤ **Numerical keyboard**

Pushed when numerical values are inputted.

➤ **Channel key**

This key is for selecting the channel.

➤ **Rewind key**

Rewinds the program of selected channel to return it to the top block.

➤ **Program EDIT keys**


Establishes the selected address to be edited and determines the inputted value.



Cancels the established address and determined input value.



Erases the set value of EDIT address.



Stores the program after editing.

If the power is turned OFF without operating left keys, the program in the block finally edited is not stored, thus eliminating its edited program.

• **Status display**

When the selected address is established by **ENT** key, the character of selected address flickers on the screen and the data is erased.

When editing the program by **ENT** key, “/A/” which displays the screen axis flickers.

When storing the edited program with “/A/” flickered, “/A/” lights.

➤ **Block key**



Used for specifying the block number. After inputting this key, the specified block number is continuously inputted.



Calls a next block for a current block.



Calls a former block for a current block.

➤ **Block EDIT keys**



Copies the selected block or the selected channel to another channel.



Deletes the selected block or the program of selected channel completely.



Determines block copy, block deletion, channel copy, etc.



(Pushed for 2 seconds)

Shifts a channel copy screen.

Copies all program of selected channel to another channel.

Copy 00--00



(Pushed for 2 seconds)

Deletes the program of selected channel.

The following message is displayed while all programs are being executed.

CH03 PRG DEL



Cancels variously established modes.

• **State display**

When block copy or block DELETE is established by **INS** and **DEL** keys, the block number flickers on the screen.

2.2.6.

Program communication keys

These keys are used for communicating the program data to external equipment.

The following procedure is recommended for operating the program under the EDIT mode.

➤ **Channel key**

This key is used for selecting the channel.

➤ **Communication key**

This key is used for inputting the program to the selected channel from the external equipment.

CH00 IN END



This key is used for outputting the program of selected channel to the external equipment.

CH00 OUT END

• **State display**

When the external INPUT or OUTPUT of program is selected, the external communication is started and the message showing I/O and the block No. while communicating are displayed on the screen. When the communication is finished, the message of “END” is displayed.

➤ **Communication EDIT key**

Cancels variously established modes and interrupts data communication.


2.2.7.

Parameter operation keys

These keys are used for operating various parameters to control the circular table.

(For detailed parameters, see Clause 15 Parameters.)

The following procedure is recommended to operate the table under the PARAM mode.

➤ **Numerical keyboard**

The numerical keyboard has ten-key and mark keys to input the number and set value of each parameter with these keys.

➤ **Block keys**

Used when the parameter No. is specified. The specified parameter No. is continuously inputted after inputting this key.



Calls a parameter of next number.



Calls one former parameter No.

➤ **Parameter EDIT keys**

Establishes the parameter No. to be changed and determines an inputted value.



Cancels the established parameter No. to be changed and also, cancels the determined input value.



Clears the set value of parameter and sets value "0".



Stores the parameter after changing it.

2.2.8. Parameter communication keys

These keys are used for communicating the parameter data to external equipment.

The following procedure is recommended for operating the program under the PARAM mode.

➤ **Communication keys**

Inputs parameters from external equipment.

When this key is pushed, the following external parameter INPUT screen is displayed.

PARAMETER IN



Outputs the parameters to external equipment.

When this key is pushed, the following external parameter OUTPUT screen is displayed.

PARAMETER OUT

• **State display**

When the external INPUT or OUTPUT of parameter is selected, the external communication screen appears. During data communication, the message and the parameter No., are displayed. When the communication is finished, the message of "END" is displayed.

➤ **Communication
EDIT keys**



Cancels variously established data and interrupts the data communication.

**2.2.9.
Self-diagnosis
operation keys**

Operated for checking various conditions of circular table.

(For details, see Clause 7. Self-diagnosis.)

The self-diagnosis screen becomes effective under 『AUTO』, 『MANUAL』 and 『SINGLE』 modes.

➤ **Self-diagnosis
display key**



Various self-diagnosis screens are changed and displayed in order.

➤ **Operation key**



This is the positive direction change key that the signal displayed in the I/O self-diagnosis means what to be displayed.



This is the opposite direction change key that the signal displayed in the I/O self-diagnosis means what to be displayed.




Selects the top of signal displayed in I/O diagnosis.

**2.2.10.
Operation keys in
alarm**

When some alarms occur, ALARM LED of STATUS flickers.

At this time, the alarm contents except display can be checked with the following keys.

➤ **Change keys**




When some alarms occur, the operation can be changed with the left keys in order.

2.3. Lamp indication

2.3.1. MODE

Displays that the mode selected for each operation is which mode.



When the LED of selected mode becomes red, the lamp lights.

AUTO	Auto operation mode When override is other than 100%, the lamp flashes.
MANUAL	Manual operation mode When override is other than 100%, the lamp flashes.
EDIT	Edits, inputs and output the programs.
PARAM	Sets, inputs and output the parameters.
SINGLE	Makes single operation with the controller.

- * When all LEDs of MODE light with power ON, since CPU error occurs, turn OFF power once and turn ON the power after elapsing 5 seconds.

2.3.2. STATUS

Displays the conditions of controller.

STATUS

- RUN
- STOP
- RESET
- ALARM
- READY A
- READY B

When the LED of STATUS becomes red, each lamp lights.

RUN Lamp lights during auto operation.

STOP Lamp lights during operation stop.
When machine is held during auto operation, the lamp lights simultaneously with RUN.

RESET Lamp lights just after power ON and after resetting.

ALARM Lamp lights when alarm occurs. The lamp flashes while alarms occur redundantly.


READY A MZRN position of A-axis is established.

READY B MZRN position of B-axis is established.

* When all LEDs of STATUS light with power ON, because CPU error occurs, turn OFF power once and turn ON the power again after elapsing for 5 seconds.

2.3.3. CPU status

It is displayed that CPU is correctly started.



When "CPU NORMALCY" does not light with power ON, CPU error occurs. Turn OFF power once and turn ON the power again after elapsing for 5 seconds.


2.4. Data display

2.4.1.


Data display part Displays LCD (Liquid Crystal Display) to display various data.

The following shows the basic display screen of each mode.


- **AUTO**
- **MANUAL**
- **SINGLE**



- **EDIT**




EDIT Screen for 1 axis



EDIT Screen for 2 axis(A-axis)

- **PARAM**



3 Mode

3.1. Mode selection

3.1.1. Mode selection

To perform each operation, it is necessary to select each mode.

The mode is changed in order as often as **MODE** key is pushed.

However, the selected mode differs by the UNESTABLISH/ESTABLISH modes for setting the MZRN position.

In MZRN position setting UNESTABLISH mode

[MANUAL] [EDIT] [PARAM] [MANUAL] ...

As shown the above, spaces between [MANUAL] , [EDIT] , [PARAM] are looped.

In MZRN position setting ESTABLISH mode

[MANUAL] [EDIT] [PARAM] [SINGLE]
[AUTO] [MANUAL] ...

As shown the above, spaces between [AUTO] , [MANUAL] , [EDIT] , [PARAM] , [SINGLE] and all modes are looped.

※ When power is turned ON, the system is started at 『MANUAL』 mode.

3.1.2. External mode selection

After setting the machine zero position, 『AUTO』 and 『MANUAL』 modes can be selected with the external input signals.

【External mode selection spec.】

The external mode can be selected when the controller is ready. When the controller is not ready, the external mode cannot be selected even if AUTOSSET or MANUALSET is inputted.

READY status means that the machine zero position is set.

External modes can be changed even from any modes.

However, when the following status, the mode cannot be changed.

- While the program is editing under EDIT mode.
- While the parameter is setting under PARAM mode.

Only either mode is to be inputted. When both modes are inputted, an alarm occurs.

- Err219 EXT MODE SEL ERROR (External mode selection error)

The mode after external mode input OFF returns to the mode just before input ON.

With external mode input ON, the panel mode is not selected.

3.2. Outline of mode


3.2.1. Outline of mode

Mode	Description
AUTO (Auto Run)	<ul style="list-style-type: none"> ➤ Operates the program edited by EDIT mode automatically. ➤ Executes the program block by block as often as a start signal is inputted. ➤ Interlocks M-signal from an external start signal.
MANUAL (Manual Run)	<ul style="list-style-type: none"> ➤ Rotates the circular table manually. ➤ Performs a manual MZRN, manual WZRN and WZRN position setting. ➤ Operates a manual pulse generator too.
EDIT (Program EDIT)	<ul style="list-style-type: none"> ➤ Edits the program for automatic operation. ➤ Inputs and outputs the program from/to the external equipment. ➤ Communicates the programs to some personal computers with the data management software. (It is necessary to use the exclusive data management software.)
PARAM (Parameter)	<ul style="list-style-type: none"> ➤ Edits the parameters for operational conditions and data setting required for controlling by the controller. ➤ Inputs and outputs the parameters from/to external equipment. ➤ Communicates the parameters to some personal computers with the data management software. (It is necessary to use the exclusive data management software.)
SINGLE (Single Run)	<ul style="list-style-type: none"> ➤ Does not output a BLKFIN and a G99FIN in case of SINGLE mode though an operation content is the same as an AUTO mode.

4 Programs

4.1. Program structure

The program consists of 『Channel』, 『Block』, 『Address』 and 『Data』.



Channel

To classify the multiple programs stored into memory, each block is called the channel.

Though 16 channels are prepared usually, maximum 90 channels can be increased optionally by parameter change.

Block

The programs in the channel are numbered with block No., in order from the program top.

Address

Address shows factors required for the programs such as angle, speed, etc., with alphabetic characters.

Data

Data means the value set to each address.

4.2. Program area structure

The program in the controller manages the information of channels and blocks into the memory (EEPROM).

Area structure

The operation program is stored in the area called the program area.

The size of this storage area (program area) is fixed and the area has the capacity of 2000-block.

For this reason, the program can be created into the max. total capacity of 2000-block.

However, one channel (program block) cannot occupy all blocks. This program area is divided into min. 2 channels ~ max. 90 channels.

In the standard, this program area is divided into 16 channels.

Dividing of program area

Standard Volume (50 blocks are summed up to one lot.)

CH00			CH02	CH04	CH06	CH08	CH10	CH12	Ch14
		CH01	CH03	CH05	CH07	CH09	CH11	CH13	CH15

In case of standard, the number of channels and the number of blocks are determined.

CH00 : 500-block (Block Nos. N000 ~ N499)

CH01 ~ CH15 : 100-block (Block Nos. N000 ~ N099)

In case of extension, the number of channels and the number of blocks can be changed optionally.

However, maximum set values are as follows:

Number of channels: 90 Number of blocks: 1000

Extension Volume (50 blocks are summed up to one lot.): Example

CH00					CH01				

CH00	CH04	CH08	CH12	CH16	CH20	CH24	CH26	CH28	CH30
CH01	CH05	CH09	CH13	CH17	CH21		CH27		
CH02	CH06	CH10	CH14	CH18	CH22			CH29	
CH03	CH07	CH11	CH15	CH19	CH23	CH25			


To simplify the above, though 50 blocks are summed up to one lot, the number of channels can be set at 1 block unit.

4.3. Program display method

The program is displayed on the LCD by editing the mode.

Though 『Channel』 and 『Block』 are usually displayed, the display contents of 『Address』 and 『Data』 are changed by the program contents.

Since this is divided into two addresses (NEEDED/UNNEEDED) by G-code inside of program, unneeded address is not displayed.



EDIT Screen Display on 2nd Axis

- ① **Channel** Displays the number of program channel currently selected.
- ② **Block** Displays the number of program block currently selected.
- ③ **Axis name** Displays the axis No. currently selected.
In case of exclusive control for 1-axis, 『 /A/ 』 is displayed usually.
In case of the exclusive controller for 1-axis, the change key A/B can change the key to 『 /A/ 』 or 『 /B/ 』.
- ④ **G-address** For address G, prepared G-code command is displayed.
When only address G is displayed, the data shows nil.
- ⑤ **A-address** Address A that shows the angle and time is displayed on the upper right stage.
When only address A is displayed, the data shows nil.
- ⑥ **F-address** Address F that shows rotation speed is displayed on the right side of lower stage block No.
When only address F is displayed, the data shows nil.
- ⑦ **D-address** Address D that shows the dividing is displayed on the right side of lower stage address F.
When only address D is displayed, the data shows nil.

⑧ J-address


Address J that shows jump is displayed on the lower right stage.

When only address J is displayed, the data shows nil.

⑨ Other axis mark

In 2-axis spec., when the program exists to the axis that is different as the screen display axis, this mark is displayed.

In 1-axis spec., this mark is not displayed.



⑩ P-address

Address P that shows the start block No., of repeating function is displayed to the right side of G27 on the right stage only when G27 is commanded.

When only address P is displayed, the data shows nil. At this time, when the program is stored, the alarm of 『 Err962 EDIT ILLEGAL G 』 occurs.

⑪ E-address

Address E that shows the end block No., of repeating function is displayed to the upper right side only when G27 is commanded.

When only address E is displayed, the data shows nil. At this time, when the program is stored, the alarm of 『 Err962 EDIT ILLEGAL G 』 occurs.

⑫ L-address

Address L that is optionally outputted in the repeating frequency of its function or interlocking function (G21) is displayed on the center of lower stage.

The address L is displayed only when G21 and G27 are commanded.

When only address L is displayed, the data shows nil. When the program is stored with G27 commanded, the alarm of 『 Err962 EDIT ILLEGAL G 』 occurs.

4.4. Address functions

The detailed explanation of addresses for program structure is as follows:

Address	Content	Set unit	Set range	Remarks
G	See the Clause of G-code function.			
A	Rotation angle command	degree	± 999.999	
	Dwell time command	sec	0.01 ~ 999.99	
F	Rotation speed command	0.01min^{-1}	0、3 ~ 9999	It becomes the setup of 0.025min^{-1} when the setup of 1 or 2 is done.
J	Jump command	Block No.	0 ~ 998	When jumped to block before command block.
	Subroutine command	Block No.	1 ~ 999	When jumped to block after command block
	Return command	Return No.	-1	Single subroutine end
D	Dividing command	Dividing number	0 ~ 999	
P	Start block command of repeating function (G27)	Block No.	1 ~ 999	
E	End block command of repeating function (G27)	Block No.	1 ~ 999	
L	Repeating frequency command of repeating function (G27)	Repeating number	1 ~ 999	
	G99 command of interlock start function (G21)	G99 command number	99	G99 can be commanded in the same block as G21.

4.5. G-code functions

The controller provides the preparatory function (G-code) to allow the machine to make the determined operation. The preparatory function command is indicated with the value continued to the address G.

The G-code is divided into two types.

Type	Contents
One shot G-code	G-code effective only block specified
Modal G-code	G-code effective continuously until a reciprocity G-code is commanded.

- Any G codes marked with , are in the modal information column of G-code list are modal type. The G code marked with becomes effective continuously until the G-code marked with is commanded. Similarly, the G code marked with becomes effective continuously until the G-code marked with is commanded.
- G codes except marks , are one shot type.
- Modal information is returned to the initial setting mode which becomes the state marked with of the modal information list, when MAC-controller is operated by turning the power off, reset, mode change, channel change by the panel, and external channel change (PRM112=1).
- When any G-code except the G-code in the list is commanded, the alarm of Err940 PROG G ERROR (Program G-code error) occurs.

Precautions)

- Even if the program is executed at 2-axis spec., modes do not synchronize. The program is executed the program content set every axis.
- When the block having programs for two axes is executed, BLKFIN is outputted after programs of both axes are completed.

G-code	Function Name	Description	Modal inf.
None	ROTATION SPEED COMMAND	Only index command is possible.	
G04	DWELL	Waits for some times without shifting.	
G07	LEAD CUT	Rotates the table repeatedly.	
G08	CONT. BUFFER	Executes the program block continuously. CONT. EXECUTE becomes effective until next G09 is commanded.	
G09	CONT. BUFFER CAN.	Cancels the continuous buffer of G08 to return it to usual SINGLE BLOCK EXECUT.	
G10	CLAMP UNUSED	Makes CLAMP MEC in table stop in an unused state. CLAMP MEC UNUSED becomes effective until next G11 is commanded.	
G11	CLAMP USED	Cancels CLAMP MEC UNUSED state of G10 and clamps the table in table stop.	
G15	POS-DEV CHECK VALID	Emphasizes joint by checking POS-DEV Between program blocks when CONT. BUFFER becomes effective (G08). POS-DEV CHECK becomes valid until next G16 is commanded.	
G16	POS-DEV CHECK INVALID	Cancels POS-DEV CHECK MEC. VALID state of G15 and POS-DEV is not checked between program blocks.	
G21	INTERLOCK START	Outputs BLKFIN SIGNAL in program execution before operation and it is used for interlocking operation with the machine.	
G22	CONT. START	When G22 is commanded, the table rotates continuously until next START is inputted.	
G23	MZRN	Positions the table in MZRN position.	
G24	WZRN	Positions the table in zero position of work coordinate system.	
G25	LOOP JUMP	Loops the program until reaching WZRN. When reaching WZRN, the program jumps out of the loop and it executes next block.	
G27	REPEATING	Repeats the program from specified block to block to specified number of times.	
G90	ABSOLUTE	Positions the table at the absolute coordinate of work coordinate system.	
G91	INCREMENTAL	Positions the table at the relative coordinate.	
G92	WCRD SYS SET	Sets WZRN position optionally with the program.	
G97	BLKFIN NON-OUTPUT	Not output BLKFIN.	
G98	BLKFIN/G99FIN OUTPUT	Outputs both BLKFIN and G99FIN.	
G99	G99FIN OUTPUT	Outputs only G99FIN without outputting BLKFIN.	

4.5.1. Non-G-code

When G-code is unnecessary on positioning, dividing motion, subprogram, etc., this code is set.

In case of non G-code block, the program is operated at the modal state before executing block. The address of this non-G-code type is used normally.

【Program Format】

A_ F_ D_ J_

Boldface and italic type characters can be abbreviated.

<i>A_</i>	: Rotation angle	Setting unit	: deg
		Setting range	: ± 999.999 (In incremental) 0 ~ 359.999 (In absolute)
<i>F_</i>	: Rotation speed	Setting unit	: 0.01min^{-1}
		Setting range	: 0, 3 ~ 9999
<i>D_</i>	: Equal dividing number	Setting range	: 0 ~ 999
<i>J_</i>	: PRM jump destination	Setting range	: -1 ~ 999
		J-1	: Subprogram return command

Description

【Modal information absolute – Address A (Rotation angle)】

- The address A is set at 0 ~ 359.999 within one rotation by regarding WZRN position as “0”.
- When the value of 360 or more is set to the Address A by program communication, the alarm of \square Err216 ANGLE ERROR IN ABS (Angle error in absolute command) \blacktriangledown occurs.
- When set over set range, the alarm of \square Err944 PROG A ERROR (Program A-address INPUT error) \blacktriangledown occurs.

【Modal information incremental – Address A (Rotation angle)】

- The relative rotation angle from current position is set at value of ± 999.999 .
- Unless otherwise Address J is commanded independently, the Address A becomes the essential setting address.
- When set over set range, the alarm of \square Err944 PROG A ERROR (Program A-address INPUT error) in continuous buffer VALID \blacktriangledown occurs.

【Address F (Rotation speed)】

- When F is not set, the feedrate set at a former block is used continuously as the modal information.

However, the program setting the feedrate is not executed once before executing block, the alarm of \square Err210 F DATA ERROR (Feedrate data error) \square occurs.

- When set to “F0”, the table rotates at set speed of PRM003 (Rapid traverse).

However, override becomes effective during automatic operation. When the override is set other than 100%, the LED of AUTO mode flickers.

When the override more than the set speed of MAX. or PRM003 is set, speed is clamped at the upper limit of PRM003 speed.

【Address D (Equal dividing number) 】

- If there is no D-setting or “0” or “1” is set, an usual positioning is performed as non-divide.
- When the relationship between A-command and D-command is $A/D < \text{Min.}$, shift unit (0.001 deg), the alarm of \square Err207 DIVIDE CMD ERROR (Divide command error) \square occurs.
- When the modal information is absolute and Address D is set at the same position as the current position, the alarm of \square Err207 DIVIDE CMD ERROR \square occurs when the program is executed.

【Address J (Jump)】

- When J is not set, the program advances to next block after finishing the block.
- When the block No. is set to J, the program jumps to the specified block No., after finishing the block.
- When “J-1” is set inside of program at the subprogram, the program returns to the main program.

Input regulation of 2-axis spec.

- When address J is commanded to each axis, the same address J is automatically set to another axis.

4.5.2. G 0 4 (DWELL)

The program waits by the specified time to delay the movement to next block operation.

【Program Format】

G04 **A**__ **J**__

Boldface and italic type characters can be abbreviated.

G04 : Dwell time

A__ : Waiting time

J__ : PRM jump destination

Setting unit : second

Setting range : ± 999.999

Setting range : -1 ~ 999

J-1 : Subprogram return command

Description

【Address A (Waiting time)】

- When Address A is not set, an internal processing is performed without waiting time, BLKFIN is outputted simultaneously with START.




Address J is the same as “Non-G code Type (Standard)”.

Precautions on 2-axis spec.

When commanding G04, 2-axis specifications are limited to the following items.

- When commanding G04 on both axes, “Err962 EDIT ILLEGAL G” occurs.
- The output timing of BLKFIN is as follows:
 1. When a dwell time is longer than the time of axis that the operation command is completed, BLKFIN is outputted after the dwell is completed.
 2. When a dwell time is shorter than the time of axis that the operation command is completed, BLKFIN is outputted after the dwell is completed.
 3. When any data is not set to either axis, the BLKFIN is outputted after the dwell is completed. However, since non-command axis is also unclamped and clamped, when the dwell time shorter than its time is set, the BLKFIN is outputted after the axis is unclamped and clamped.

Timing chart

In case of 1 axis spec.In case of 2 axis Precautions 1 (Example : /A/A360F500/B/G04A10)In case of 2 axis Precautions 2 (Example : /A/G04A1/B/A360F500)

4.5.3. G 0 7 (LEAD CUT)

When performing the multiple rotating index at $\pm 999.999\text{deg}$ or more that cannot be indexed on usual index, max. 1000-rotation (999-rotation +360deg) can be indexed by commanding G07.

【Program Format】

G07 **A**__ **D**__ **F**__ **J**__

Boldface and italic type characters can be abbreviated.

G07 : Lead cutting command

A__ : Rotary direction & rotary angle

Setting mark : Rotary direction
deg : deg

Setting range : ± 360.000

D__ : RPM

deg : 1 rotation (360.000deg)

Setting range : 0 ~ 999

F__ : Rotation speed

deg : 0.01min^{-1}

Setting range : 0, 3 ~ 9999

J__ : Program jump destination

Setting range : -1 ~ 999

J-1 : Subprogram return command

Description

【Address A (Rotary direction + Angle)】

- Marks “ + ”, “ - ” of Address A show the rotary directions.
- When the modal information is an absolute command, after rotating by rpm of Address D in the specified rotary direction of Address A, the table rotates for the absolute positioning in the same direction above. (See Fig. 4.5.3-1.)

【Address D (Rotation speed)】

- When D is not set, the rotation speed is 0 and the same positioning as usual index is performed.

Address F and J are the same as “Non-G code Type (Standard)”.

Concerned parameters

PRM021





The timing of BLKFIN OUTPUT in G07 command is changed to START or FINISH.

0 : Outputs BLKFIN when G07 block execution is finished.

1 : Outputs BLKFIN when G07 block execution is started.

(OUTPUT starts after about 10msec from ST INPUT.)



Timing chart

PRM021=0 , PRM032=0PRM021=0 , PRM032=1PRM021=1 , PRM032=0PRM021=1 , PRM032=1

- Precautions
- 1. The OUTPUT time of BLKFIN is the set time of PRM035 in PRM035 0. In case of PRM035=0, BLKFIN OUTPUT is turned OFF at the timing of START OFF.
 - 2. Since CLAMP/UNCLAMP times are added by changing PRM032, the OUTPUT timing varies.

Operation examples

Different operation contents by command modal information

Execution program : G07 A30 D2 F0	
Modal information : Incremental	Modal information : Absolute
	
The table rotates twice in + direction from the current position (Start point) and it advances at 30deg.	The table rotates twice in + direction from the current position and it advances at 30deg of work coordinate system.



Execution program : G07 A-30 D2 F0	
Modal information : Incremental	Modal information : Absolute
	
The table rotates twice in - direction from the current position and it advances at 30deg.	The table rotates twice in - direction from the current position and it advances at 30deg of work coordinate system.

Fig. 4. 5. 3-1

4.5.4. G 0 8、 G 0 9 (CONT. BUFFER)

The blocks from a continuous buffer START COMMAND (G08) to END COMMAND (G09) are operated continuously.

In the block during continuous buffer execution, BLKFIN/G99FIN are not outputted.

Since G08 and G09 are modal commands, unless opposite command(G08 \leftrightarrow G09)is commanded, they are continued continuously.

【 Program Format 】

G08
G09 *A*__ *D*__ *F*__ *J*__ Boldface and italic type characters can be abbreviated.

G08	:	Continuous buffer start command		
G09	:	Continuous buffer end command		
A__	:	Rotation angle	Setting unit	: deg
			Setting range	: ± 999.999 (In incremental) 0 ~ 359.999 (In absolute)
F__	:	Rotation speed	Setting unit	: 0.01min ⁻¹
			Setting range	: 0、 3 ~ 9999
D__	:	Equal dividing number	Setting range	: 0 ~ 999
J__	:	Program jump destination	Setting range	: -1 ~ 999
			J-1	: Subprogram return command

Description

Addresses A, F, D and J are the same as “Non-G code Type (Standard)”.

Precautions on 2-axis spec.

When commanding G08 and G09, 2-axis specifications are limited to the following items.

- When commanding G08, both axes execute buffer continuously.
- Since the program in command into the buffer mode are moved in next block after both 2 axes are operated, the axis that operation time is short stops and waits until other axis operation finishes.
- Though G8 may command either A-axis or B-axis, G09 is commanded to the axis that G08 is commanded.

When G09 is commanded to another axis, “Err230 ILLEGAL G09” occurs.

- For the block that G8 or G9 exists in each axis, G code cannot be programmed to another axis.

When G code is commanded, “Err962 EDIT ELLIAGAL G” occurs.

Inadequate program examples

Prg.G08_09-1... When G09 is commanded, command it to the axis that G08 has already been commanded.

```

N000 /A/G08
N001 /A/G24/B/G24
N002 /A/A10.000F0/B/A45.000F0
N003 /A/A5.000/B/G09    ... Because command axis is
                           different, Err occurs.

```

Prg.G08_09-2... Other G codes cannot be commanded into block of G08 command.

```

N000 /A/G08/B/G24

```

Concerned parameters

PRM020


The timing of FIN SIGNAL OUTPUT is changed to G08 START or G09 FINISH.

0 : When G08 BLK operation is started, BLKFIN is outputted.


1 : When G09 BLK operation is finished, BLKFIN is outputted.

Timing chart


PRM020=0 , PRM032=0




PRM020=0 , PRM032=1



PRM020=1 , PRM032=0



PRM020=1 , PRM032=1



Precautions

1. Since CLAMP/UNCLAMP times are added by changing PRM032, the OUTPUT timing varies.

4.5.5. G 1 0、G 1 1 (CLAMP UNUSED/USED)

When the clamp mechanism of the table is unused (usually unclamped state) by commanding a CLAMP UNUSED (G10), the clamp release time every block is eliminated and the system can be smoothly interlocked to the machine from the next block.

When PRM032=1, G10 becomes INVALID.

Since G10 and G11 are modal commands, unless opposite command (G10⇔G11) is commanded, they are continued continuously.

When G10 is executed under the SINGLE mode, the table is clamped after G10 block is executed. (In the SINGLE mode, the table is clamped per block.)

Since G08 command unclamps the table at the space to G09, G11 command becomes invalid.

【Program Format】			
G10			Boldface and italic type characters can be abbreviated.
G11	<i>A__</i>	<i>D__</i>	
	<i>F__</i>	<i>J__</i>	
G10	: Clamp unused	(G10 is commanded independently.)	
G11	: Clamp used		
A__	: Rotation angle	Setting unit	: deg
		Setting range	: ± 999.999
			(In incremental)
			0 ~ 359.999
			(In absolute)
F__	: Rotation speed	Setting unit	: 0.01min ⁻¹
		Setting range	: 0、3 ~ 9999
D__	: Equal dividing number	Setting range	: 0 ~ 999
J__	: Program jump	Setting range	: -1 ~ 999
	destination	J-1	: Subprogram return command

Description

Addresses A, F, D and J are the same as “Non-G code Type (Standard)”.


Timing chart

Usual operation

Program examples

N000 G21 A90 F0

N001 G21 A90 F0

G10 Command operation


Program examples

N000 G10

N001 G21 A90 F0

N002 G21 A90 F0

N003 G11



As shown in the above timing chart, though time of about 200msec is required usually from START INPUT to operation START, the clamped state becomes unclamped state by commanding G10. The time required for clamp release motion (clamp release/signal check) can be reduced from the next block and the motion can be started at about 50msec.

This mode is used when desiring to reduce a time difference as much as possible in interlocking motion with the machine.

However, the above time differs by the circular table type.

4.5.6. G 1 5、G 1 6 (POS-DEV CHECK VALID/INVALID)

G15 command can emphasize the pastern between blocks by checking the position deviation every block during continuous execution of continuous buffer.

When POS-DEV CHECK INVALID, the table operates under non-deceleration fairly because of continuous operation between blocks through the look-ahead function of program.

Since G15 and G16 are modal commands, unless opposite command (G15⇔G16) is commanded, they are continued continuously.

G15 command becomes valid only inside of continuous buffer of G08.

【Program Format】

G15

G16

A__ D__ F__ J__

Boldface and italic type characters can be abbreviated.

G15 : POS-DEV check VALID

G16 : POS-DEV check INVALID

A__ : Rotation angle

Setting unit : deg

Setting range : ± 999.999

(In incremental)

0 ~ 359.999

(In absolute)

F__ : Rotation speed

Setting unit : 0.01min⁻¹

Setting range : 0、3 ~ 9999

D__ : Equal dividing number

Setting range : 0 ~ 999

J__ : Program jump

Setting range : -1 ~ 999

destination

J-1 : Subprogram return command

Description

Addresses A, F, D and J are the same as “Non-G code Type (Standard)”.

Timing chart


In G15 unused

Program examples

N000 G08

N001 A360 D3 F0

N002 G09

In G15 used

Program examples


N000 G08

N001 G15

N002 A360 D3 F0

N003 G16

N004 G09



When commanding G15, the table decelerates to the position deviation volume of PRM010 set value or less after dividing completely at the joint between blocks or operations. The table checks that the position deviation volume becomes PRM010 set value or less and it shifts a next operation without stopping.

4.5.7. G 2 1 (INTERLOCK START)

The INTERLOCK START command (G21) can be synchronized with the external equipment simply by outputting BLKFIN when operation is started.

【Program Format】

G21 **A**__ **F**__ **L**__ **J**__

Boldface and italic type characters can be abbreviated.

G21 : Interlock start

A__ : Rotation angle

Setting unit : deg

Setting range : ± 999.999
(In incremental)
0 ~ 359.999
(In absolute)

F__ : Rotation speed

Setting unit : 0.01min⁻¹

Setting range : 0, 3 ~ 9999

L__ : G99FIN

Setting value : 99

J__ : Program jump
destination

Setting range : -1 ~ 999

J-1 : Subprogram return command

Description

【Address L (G99FIN)】

- Setting value of Address L is only 99.
- The G99FIN is outputted by specifying L99 in G21 command when the operation is started. However, when L99 is specified, BLKFIN does not output.

Addresses A, F, and J are the same as “Non-G code Type (Standard)”.

Precautions on 2-axis spec.

When commanding G21, 2-axis specifications are limited to the following items.

- In the block commanding G21, only G21 can be commanded to another axis.

If commands except G21, G21L99 are issued, “Err962 EDIT ELLIAGAL G” occurs.

Inadequate program example

Prg.G21-1... If command except G21, G21L99 is issued to the axis that is different as the axis commanding G21.

/A/G21A360F0/**B/A90F0**

/A/A360F0/B/G21A90F0

Concerned parameters

PRM042

Selects VALID/INVALID of delay timer of BLKFIN/G99FIN in G21 command.

0 : Delay timer (PRM043) INVALID

1 : Delay timer (PRM043) VALID

PRM043

Sets the delay time of output signal of BLKFIN or G99FIN in G21 execution.

Precautions


- Though PRM043 can be set from 0.00sec., it takes about 10 ~ 20msec., of time for internal processing.

Therefore, even if $\text{PRM043} < 0.02$ is set, the system cannot output BLKFIN according to the set time.

Timing chart


In case of PRM042=0 or PRM042=1 , PRM043<0.02 (Delay time : 20msec) .

Program : N000 G21 A360 F0



In case of PRM042=1 , PRM043=100 (Delay time : 1sec)


Program : N000 G21 A360 F0



G21 L99 command


In case of PRM042=0 or PRM042=1 , PRM043<0.02 (Delay time : 20msec) .

Program : N000 G21 A360 F0 L99

G21 L99 command

In case of PRM042=1 , PRM043=100 (Delay time : 1sec) .

Program : N000 G21 A360 F0 L99



4.5.8. G 2 2 (CONT. START)

The ST signal rotates the table at “Rotary Direction” and “Feedrate” specified in continuous start command (G22) and a next signal stops the table.

At this time, BLKFIN is outputted once in ST for first start, and also, once in ST for stop.

When Addresses A and F are not specified for G22 command, the rotary direction and the feedrate are determined by PRM040 and PRM041.

【Program Format】

G22 **A__** **F__** **J__**

Boldface and italic type characters can be abbreviated.

G22 : Cont. start

A__ : Rotary direction

Setting range : 0、 -0

F__ : Rotation speed

Setting unit : 0.01min⁻¹

Setting range : 0、 3 ~ 9999

J__ : Program jump
 destination

Setting range : -1 ~ 999

J-1 : Subprogram return command

Description

【Address A (Rotary Direction)】

- The rotary direction is set with “0” or “-0”.
0 : The table rotates in CW direction.
-0 : The table rotates in CCW rotation.
- Though Address A can be abbreviated, if it is abbreviated, the table rotates in the direction set to PRM040.

【Address F (Rotation speed)】

- Though Address F can be abbreviated, if it is abbreviated, the table rotates in the rotation speed set to PRM041.

Address J is the same as “Non-G code Type (Standard)”.

Precautions on 2-axis spec.

When commanding G22, 2-axis specifications are limited to the following items.

- In the block commanding G22, only G22 can be commanded to another axis or any code cannot also be set.

When the command except G22 is issued, “Err962 EDIT ELLIAGAL G” occurs.

Inadequate program example

Prg.G22-1... In G22 command block, if other axis issues the command G22 or non-setting.

/A/G22/B/A180.000

/A/A180.000/B/G22

Concerned parameters

PRM040

Selects the table rotary direction in G22 command.

0 : CW direction

1 : CCW direction


PRM041

Sets the table rotation speed in G22 command.


Timing chart

In case of G22 command PRM040=1 , PRM041=16.66.

Program : N000 G22 A0 F0 (PRM040、PRM041: INVALID)

In case of G22 command PRM040=1 , PRM041=16.66

Program : N000 G22 (PRM040、PRM041: INVALID)



Precautions

1. When the start signal is except one shot type, do not use G22 at the space between G08 and G09.

Though G22 command controls the table start and stop, because BLKFIN is outputted only first or last one time when G22 is used inside of G08 and G09, the start signal does not turn OFF on the start signal OFF type (a general M-signal type) by BLKFIN OUTPUT confirmation.

4.5.9. G 2 3 Machine zero return (MZRN)

This code rotates the table to the mechanical zero position. This is called MZRN.

When MZRN is finished, ZRNFIN and BLKFIN signals are outputted.

The G23 code rotates the table at the rapid traverse set to PRM003 as MZRN feed.

Though MZRN direction is set to PRM016, when SHOT CUT ZRN of PRM017 is set, PRM017 takes precedence.

When G23 is commanded at MZRN position, MZRN is performed again and BLKFIN and ZRNFIN are outputted. However, when UNIDIRECTIONAL is valid, the unidirectional motion is performed.

【Program Format】

G23 *J__*

Boldface and italic type characters can be abbreviated.

G23 : Machine zero return (MZRN)

J__ : Program jump destination Setting range : -1 ~ 999
J-1 : Subprogram return command

Description

Address J is the same as “Non-G code Type (Standard)”.

Concerned parameters

PRM003

The MZRN feed is rapid traverse.

PRM016

Selects MZRN direction.

0 : CW direction

1 : CCW direction

PRM017

Selects ZRN SHORT CUT DIR.

0 : INVALID


1 : VALID

2 : ZRN SHORT CUT DIR VALID of OPT POS spec. type

PRM018

Sets the angle position (M/C coordinate system) that is the boundary of ZRN SHORT CUT DIR of OPT POS spec. type.

Timing chart



4.5.10. G 2 4 Work zero return (WZRN)

G24 code rotates the table to the Work ZERO position. This is called WZRN.

This code rotates the table at the rapid traverse set to PRM003 as WZRN feed.

When WZRN is finished, 360FIN and BLKFIN signals are outputted.

Though WZRN direction is set to PRM016, when SHORT CUT ZRN of PRM017 is set, PRM017 takes precedence.

When G24 is commanded at WZRN position, WZRN is performed again and BLKFIN and 360FIN are outputted. However, when UNIDIRECTIONAL is valid, the unidirectional motion is performed.

【Program Format】

G24 ***J***

Boldface and italic type characters can be abbreviated.

G24 : Work zero return
 (WZRN)

J : Program jump
 destination

Setting range : -1 ~ 999

J-1 : Subprogram return command

Description

Address J is the same as “Non-G code Type (Standard)”.

Concerned parameters

PRM003

The WZRN feed is rapid traverse.

PRM017

Selects ZRN SHORT CUT DIR.

0 : INVALID

1 : VALID

2 : ZRN SHORT CUT DIR VALID of OPT POS spec. type

PRM018

Sets the angle position (M/C coordinate system) that is the boundary of ZRN SHORT CUT DIR of OPT POS spec. type.

PRM025

Selects the OUTPUT FORM of WZRN position conf.
(360FIN) .

0 : One shot OUTPUT


1 : Area OUTPUT

PRM026


Sets the output range of area output type of WZRN position conf. (360FIN) .

Timing chart

In case of PRM025=0 (Standard : One shot output) .



In case of PRM025=1 (Area OUTPUT) 、 PRM026 0.



4.5.11. G 2 5 (LOOP JUMP)

When the table stops at WZRN position or passes it during loop jump command (G25) block execution, the program ignores the jump command inside of G25 command block and shifts to next block.

When the table does not stop at WZRN position or pass it during G25 block operation, the system commands the jump mode in the same block as G25 command and loops the program.

【Program Format】

G25 **A**__ **F**__ **D**__ **J**__ Boldface and italic type characters can be abbreviated.

G25	:	Loop jump		
A__	:	Rotation angle	Setting unit	: deg
			Setting range	: ± 999.999
				(In incremental)
				0 ~ 359.999
				(In absolute)
F__	:	Rotation speed	Setting unit	: 0.01min ⁻¹
			Setting range	: 0, 3 ~ 9999
D__	:	Equal dividing number	Setting range	: 0 ~ 999
J__	:	Program jump	Setting range	: -1 ~ 999
		destination	J-1	: Subprogram return command

Description

【Address A (Rotation angle)】

- When A is not set, because G25 loop jump becomes impossible, the alarm of 『Err962 EDIT ILLEGAL G (Illegal G code)』 occurs.
- Other contents are the same as 『Non-G-code type』.

【Address J (Jump)】

- When J is not set, G25 command becomes invalid and the program shifts to next block after BLKFIN.
- When block No., is set to J, the program jumps to specified block No., after BLKFIN.

Addresses F and D are the same as “Non-G code Type (Standard)”.

Precautions on 2-axis spec.

When commanding G25, 2-axis specifications are limited to the following items.

- When commanding G25, both axes perform the loop motion of G25. However, in case G25 command is only either axis, G25 command axis becomes loop OUT. When G25 is commanded to both axes, object axes are both axes. The loop OUT occurs at side where the work zero position is detected at G25 command block in advance.

Program examples

Prg.G25-1... When A-axis stops at work zero position or passes it, the program advances to N002 and B-axis clears the same term.

```
N000 /A/A45.000F0 /B/A90.000F0
N001 /A/G25A90.000J0 /B/A90.000J0
N002 /A/G24J0 /B/G24
```

Prg.G25-2... When B-axis stops at work zero position or passes it, the program advances to N002 and A-axis clears the same term.

```
N000 /A/A90.000F0 /B/A45.000F0
N001 /A/A90.000J3 /B/G25A90.000J0
N002 /A/G24J0 /B/G24
```

Prg.G25-3... G25 command is for both A and B axes. When either axis stops at work zero position or passes it, the program advances to N002.


```
N000 /A/A45.000F0 /B/A90.000F0
N001 /A/G25A90.000J0 /B/G25A90.000J0
N002 /A/G24J0 /B/G24
```

Program examples

Program	Contents
N000 G24	WZRN
N001 A90.000 F0	Indexes 90° at the rapid traverse of rotation speed.
N002 A30	
N003 G25 A60.000 J2	Indexes 30° at the rapid traverse of rotation speed. The program jumps to N003 when stopping at WZRN and passing it position during this block operation and it jumps to N001 when not stopping at WZRN and passing it.
N004 A45.000 J1	Indexes 45° at the rapid traverse of rotation speed.

In the above program, the loop for G25 command is N002 ~ N03.

Exe. block	Coordinate value (WCoordinate)
	Start pos.
N000	0.000
N001	90.000
N002	120.000
N003	180.000
N002	210.000
N003	270.000
N002	300.000
N003	0.000
N004	45.000



4.5.12. G 2 7 (REPEATING)

This repeating command (G27) repeats the program by specified times at place between specified blocks (Repeating start block ~ Repeating end block).

G27 command can be nested by maximum 8 times (G27 commanded between Repeating start block ~ Repeating end block specified by G27).

【Program Format】

G27 **P**__ **E**__ **L**__ **J**__

Boldface and italic type characters can be abbreviated.

G27	:	Repeating command			
P__	:	Repeating program Start block No.	Setting range	:	1 ~ 999
E__	:	Repeating program End block No.	Setting range	:	1 ~ 999
L__	:	Repeating frequency	Setting range	:	0 ~ 999
J__	:	Program jump destination	Setting range	:	-1 ~ 999
			J-1	:	Subprogram return command

Description

【Address P (START Block No.)】

- Address P is an essential setting address.

When there is no P-setting, the alarm of $\text{Err962 EDIT ILLEGAL G}$ (Illegal G-code) occurs.

- When the set value of Address E is more than that of Address P, the alarm of $\text{Err962 EDIT ILLEGAL G}$ occurs.

【Address E (End Block No.)】

- Address E is an essential set-address.

When there is no E-setting, the alarm of $\text{Err962 EDIT ILLEGAL G}$ (Illegal G-code) occurs.

- When the set value of Address E is less than that of Address P, also, the alarm of $\text{Err962 EDIT ILLEGAL G}$ occurs.

【Address L (Repeating Frequency)】

- Address L is an essential set-address.

When there is no L-setting, the alarm of $\text{Err962 EDIT ILLEGAL G}$ (Illegal G-code) occurs.

In case of L0, it is processed as 11.

Addresses J is the same as “Non-G code Type (Standard)”.

- Precautions on 2-axis spec.** When commanding G27, 2-axis specifications are limited to the following items.
- When commanding G27, it is inputted to only either axis. When any program is inputted to the axis that is different as G27 command axis, “Err962 EDIT ELLIAGAL G” occurs.

Program examples

Prg.G27-1... Though G27 is commanded to the program of A-axis, it is for both A and B axes.

```
N000 /A/G27P10E12L3
N001 /A/G24J0
N010 /A/A10.000F0
N011 /A/A5.000 /B/A15.000F0
N012 /A/A30.000
```

Prg.G27-2... Though G27 is commanded to the program of B-axis, it is for both A and B axes.

```
N000 /B/G27P10E12L3
N001 /B/G24J0
N010 /A/A10.000F0
N011 /A/A5.000 /B/A15.000F0
N012 /A/A30.000
```


Inadequate program example ... G27 command block is inadequate.

```
N000 /A/G27P10E12L3 /B/G27P20E25L5
N000 /A/G27P10E12L3 /B/A5F0
N000 /A/A5F0 /B/G27P10E12L3
```

Program examples

Program	Contents
N000 G24	WZRN
N001 G27 P50 E51 L3	After repeating N050~N051 blocks 3 times by G27 command, the program shifts to N002.
N002 G24	WZRN
N050 A20.000 F0	Indexes 20° at the rapid traverse of rotation speed.
N051 A40.000	Indexes 40° at the rapid traverse of rotation speed.



In the above programs, loops for G27 are N050 ~ N051.



Program

Program flow

(Value): Start input No.
: Operating block
▶ : Passing block



Program check

Start pos.	Exe. program	Stop position	
		G90 (Abso.)	G91 (Incr.)
A180.000	A 90	Rotates 270 ° in CW and stops at 90 ° pos.	Rotates 90 ° in CW and stops at 270 ° pos.
	A-90	Rotates 90 ° in CCW and stops at 90 ° pos.	Rotates 90 ° in CCW and stops at 90 ° pos.
	A 180	Not rotated. Note 1)	Rotates 180 ° in CW and stops at 0 ° pos.
	A-180	Not rotated. Note 1)	Rotates 180 ° in CCW and stops at 0 ° pos.
	A 0	Rotates 180 ° in CW and stops at WZRN position.	Not rotated. Note 1)
	A-0	Rotates 180 ° in CCW and stops at WZRN position.	Not rotated. Note 1)

All coordinate systems show stop positions.

Note 1. When the UNIDIRECTIONAL positioning is set, the approach amount of unidirectional positioning varies.

Program examples

(Executed programs ①, ②, ③ are compared with the above programs.)

G90 (Abso. command)	G91 (Incr. command)
G90 A90 	G91 A90
G90 A-90 	G91 A-90
G90 A0 	G91 A0

4.5.14. G 9 2 (WCRT SYS SET)

The work coordinate system setting command (G92) can set that the current position is changed to which position.

Precautions

1. The WZRN position set by G92 command can be changed by G92 command after that, or a manual WZRN position. The WZRN position data is not remained before change.

【Program Format】

G92 **A__** **J__**

Boldface and italic type characters can be abbreviated.

G92 : Work coordinate system
 setting command

A__ : Setting angle

Setting unit : deg
Setting range : 0 ~ 359.999

J__ : Program jump
 destination

Setting range : -1 ~ 999
J-1 : Subprogram return command

Description

【Address A (Setting Angle)】


- The set-value of WZRN position can be changed by setting that the currently stopped position is determined to which position.
- When setting over the set range, the alarm of 『 Err944 PROG A ERROR (Program A-address input error)』 occurs.

Address J is the same as “Non-G code Type (Standard)”.

Program examples


Program	Conents
N000 G24	WZRN
N001 G90 A90.000 F0	Indexes 90° pos., at rapid traverse on the basis of WZRN.
N002 G92 A0	Sets current pos. to 0° from WZRN pos. (Current pos. is regarded as WZRN.)

Exe. block	Coordinate value (WCoordinate)
	Start pos.
N000	0.000
N001	90.000
N002	0.000



Program	Conents
N000 G24	WZRN
N001 G90 A90.000 F0	Indexes 90° pos., at rapid traverse on the basis of WZRN.
N002 G92 A180	Sets current pos. to 180° from WZRN pos.
N003 A-270 J0	Indexes 270° pos., at rapid traverse in CCW on the basis of WZRN.

Exe. block	Coordinate value (WCoordinate)
	Start pos.
N000	0.000
N001	90.000
N002	180.000
N003	270.000



4.5.15. G 9 7 (BLKFIN NON-OUTPUT)

BLKFIN NON-OUTPUT command (G97) does not output BLKFIN on the usual program execution.

When operating the circular table by interlocking with the machine, this command is not used usually. This code is used for operating the circular table independently without operating environment equipment by BLKFIN output.

Precautions

1. Since the G97 does not output the BLKFIN for ST input from external equipment, when the external start signal is turned OFF at FLKFIN OFF, the external equipment waits the FIN signal, thus stopping as is.

【Program Format】

G97 **A** **F** **D** **J** Boldface and italic type characters can be abbreviated.

G97	:	BLKFIN NON-OUTPUT command		
A <u> </u>	:	Rotation angle	Setting unit	: deg
			Setting range	: ± 999.999 (In incremental) 0 ~ 359.999 (In absolute)
F <u> </u>	:	Rotation speed	Setting unit	: 0.01min ⁻¹
			Setting range	: 0, 3 ~ 9999
D <u> </u>	:	Equal dividing number	Setting range	: 0 ~ 999
J <u> </u>	:	Program jump	Setting range	: -1 ~ 999
		destination	J-1	: Subprogram return command

Description

Addresses A, F, D and J are the same as “Non-G code Type (Standard)”.

Precautions on 2-axis spec. When commanding G97, 2-axis specifications are limited to the following items.

- In the block commanding G97, when another axis is programmed without G code, G97 is set to both axes and finish signal is not outputted.
- If G97 is commanded to another axis in the block that commands G97,
 - ▮ Err962 EDIT ELLIAGAL G 』 occurs.


Inadequate program example

Prg.G97-2 ... G97 is commanded to each axis and G98 to another axis.

/A/G97A360F0/B/G98A90F0

/A/G98A360F0/B/G97A90F0

Timing chart



4.5.16. G 9 8 (Block finish output (BLKFIN)/optional block finish output (G99FIN))

The BLKFIN and G99FIN command (G98) outputs the BLKFIN and G99FIN.

【Program Format】

G98 **A**__ **F**__ **D**__ **J**__ Boldface and italic type characters can be abbreviated.

G98	:	BLKFIN/G99FIN output command		
A__	:	Rotation angle	Setting unit	: deg
			Setting range	: ±999.999 (Incremental) 0 ~ 359.999 (In absolute)
F__	:	Rotation speed	Setting unit	: 0.01min ⁻¹
			Setting range	: 0、3 ~ 9999
D__	:	Equal dividing number	Setting range	: 0 ~ 999
J__	:	Program jump destination	Setting range	: -1 ~ 999
			J-1	: Subprogram return command

Description

Addresses A, F, D and J are the same as “Non-G code Type (Standard)”.

Precautions on 2-axis spec. When commanding G98, 2-axis specifications are limited to the following items.

- If G97 is commanded to another axis in the block that commands G98,
『 Err962 EDIT ELLIAGAL G 』 occurs.
- If G99 is commanded to another axis in the block that commands G98,
『 Err962 EDIT ELLIAGAL G 』 occurs.

Inadequate program example

Prg.G98-1... G98 is commanded to each axis and G97 to another axis.

/A/G98A360F0/B/**G97**A90F0

/A/**G97**A360F0/B/G98A90F0

Prg.G98-2... G98 is commanded to each axis and G99 to another axis.

/A/G98A360F0/B/**G99**A90F0

/A/**G99**A360F0/B/G98A90F0

Concerned parameters

PRM027

Selects the timing of G99FIN OUTPUT.

0 : Outputs G99FIN in BLK execution start.

1 : Outputs G99FIN in BLK execution finish.

PRM028

In case of PRM029=2, though G99FIN OUTPUT and ZRN INPUT signals are used as handshake signals, the time to cause an alarm is set when ZRN signal is not received in time after outputting G99FIN.

During this set time, G99FIN is outputted continuously.

PRM029




Specifications of ZRN INPUT are set.

0 : Outer MZERO (Machine zero return) spec.


1 : Outer WZERO (Work zero return) spec.

2 : Handshake check spec.


Timing chart

In case of usual operation.In case of G98 command PRM027=0 (PRM029 2).In case of G98 command PRM027=1 (PRM029 2).

PRM027=1 PRM028=5.0 PRM029=2 When ZRN is inputted within 5 sec.



PRM027=1 PRM028=5.0 PRM029=2 When ZRN is inputted within 5 sec.



4.5.17. G 9 9 (Optional block finish output (G99FIN OUTPUT))

G99 command outputs G99FIN on the program execution. At this time, it does not output the BLKFIN.

【Program Format】

G99

A

F

D

J

Boldface and italic type characters can be abbreviated.

G99

:

G99FIN OUTPUT command

A

:

Rotation angle

Setting unit

:

deg

Setting range

:

± 999.999

(In incremental)

0 ~ 359.999

(In absolute)

F

:

Rotation speed

Setting unit

:

0.01min⁻¹

Setting range

:

0、 3 ~ 9999

D

:

Equal dividing number

Setting range

:

0 ~ 999

J

:

Program jump

Setting range

:

-1 ~ 999

J-1

:

Subprogram return command

destination

- Description
- Addresses A, F, D and J are the same as “Non-G code Type (Standard)”.
- Precautions on 2-axis spec.
- When commanding G99, 2-axis specifications are limited to the following items.
- If G99 is commanded to another axis in the block that commands G99, 『 Err962 EDIT ELLIAGAL G 』 occurs.

Program example
Prg.G99-1... G99 is commanded to each axis and G98 to another axis.

```
/A/G99A360F0/B/G98A90F0  
/A/G98A360F0/B/G99A90F0
```

- Concerned parameters
- PRM027

Selects the timing of G99FIN output.

0 : Outputs G99FIN in block execution finish.

1 : Outputs G99FIN in block execution start.
- PRM028





In case of PRM029=2, though G99FIN OUTPUT and ZRN INPUT signals are used as handshake signals, the time to cause an alarm is set when ZRN signal is not received in time after outputting G99FIN.

During this set time, G99FIN is outputted continuously.

PRM029

Specifications of ZRN INPUT are set.

- 0 : Outer MZERO (Machine zero return) spec.
- 1 : Outer WZERO (Work zero return) spec.
- 2 : Handshake check spec.

Timing chartIn case of G99 command PRM027=0 (PRM029 2).In case of G99 command PRM027=1 (PRM029 2).PRM027=1 PRM028=5.0 PRM029=2 When ZRN is inputted within 5 sec.PRM027=1 PRM028=5.0 PRM029=2 When ZRN is not inputted within 5 sec.

4.6. Dividing Feed Function


This is the function to divide the optional angle uniformly by optional dividing number.

4.6.1. Dividing feed


N000 G91 A120 D4 F0 Exe.
 N001 A120
 N002 A90 D6 Exe.
 N003 A30 J0

Divides angle of 120° into 4 and indexes 30° four times.

Divides angle of 90° into 6 and indexes 15° six times.



Timing chart



Precautions

N000 block operates four times before advancing to N001. Similarly, N002 block operates six times before advancing to N003.

It is necessary to start the operation in the dividing command block.

When the relationship between angle command (A) and dividing command (D) is less than a minimum shift unit as shown in the following formula,
 『 Err207 DIVIDE COMMAND ERROR 』 occurs.


Angle Command (A) / Dividing Command (D) < Minimum Shift Value (0.001°)

When the dividing command (D) is 0 or 1, the block shifts as non dividing command.

When the dividing shift command is not divided out within 3 digits of decimal point or less, the block shifts so that its error will be minimum value.

(See a right figure.)

Example N001 A80.000 D6



4.7. Subprogram Function

When there is a repeating index mode into the program, this program can be simply used as the subprogram, which can be called out of the main program.

4.7.1.

Subprogram structure

```
N***
.
.
N***
```

J-1


Commands J-1 (Return command) as sub-program completion.

4.7.2.

Subprogram example

```
N000 A90.000 F0
N001 J10
N002 A90.000
N003 J10
N004 G24 J0


N010 A10.000 F0
N011 A20.000
N012 A30.000 J-1
```



The program jumps by execution of N001 and after executing N010 ~ N012, the program proceeds to N002.

(In case of , it also is the same as the above.)

Timing chart



Precautions

An additional subprogram cannot be called (subroutine call) out of the subprogram. When the program is called, the alarm of 『 Err203 STACK OVER FLOW 』 occurs.

When J-1 (Return command) is executed without subroutine call, the alarm of 『 Err202 STACK UNDER FLOW 』 occurs.

When J-1 (Return command) is not executed on a final block executed after calling the subroutine, the alarm of 『 Err204 NOT RETURN ALARM 』 occurs.

5 Program Operation

5.1. Channel call

To call the program to be selected, select the channel.

5.1.1.

Channel call

The following describes the steps changing from channel No. “0” to “7”.



→ Since each MODE is changed in order by pushing **MODE**, push this button until 『EDIT』 is selected (LED lighting) several times.



The channel select screen is displayed in **CH** input.

CH00 7

Channel Select Screen

After inputting **ENT**, the program initial screen on the channel destination is displayed.

CH07 /A/G A
N000 F D J

Initial Screen in EDIT Selection

5.2. Block number call

Calls the block to be selected.

5.2.1.

Former block call



→ Calls the block just before current block.

5.2.2.


Next block call



→ Calls the next block of current block.

5.2.3.

Block number call



→ Specifies the block No. to [**] part and calls the number directly.

5.3. Program INPUT (for 1-axis)

The following explains the steps to input the program for 1-axis.

5.3.1.

Program examples

CH07

N000 G90 A270 F0


Exe.

N001 A-180 F500

Exe.

N002 G91 A-90 J0

Exe.



The absolute command functions the angle position command from the WZRN position (G90).

The table shifts to the angle position to be 270 ° from WZRN position. (A270)

The table rotates at the rapid traverse. (F0)

The table rotates to the angle position to be 180 ° from WZRN in reverse direction (A-180).

The table rotates at 5min⁻¹. (F500)

The incremental command functions as the relative command from the current position. (G91)

The table rotates 90 ° from the current position in reverse direction. (A-90)

After executing the program, the program returns to N000 block. (J0)










For N001 block, G90 (Absolute command) of N000 is continued.










































When there is no rotation speed command as well as N002, the rotation speed commanded at a former block is continued.




5.3.2.

Program input examples








The inputting steps of the above program examples are as follows:


- 1)  → Since each MODE is changed in order by pushing , push this button until 『 EDIT 』 is selected (LED lighting) several times.
- 2)    → Calls channel No. "7".
Block N000 is called when the channel No. is called.
- 3)   → The under bar is displayed under the character 『 G 』 when  is inputted.
After inputting , Address G flickers and the value can be set.

- 4)    → '90' is inputted in Address G and it lights.
At this time, character 'A/' flickers. ¹
- 5)   → When inputting 'A', the under bar is displayed under the character 'A'.
After inputting 'ENT', Address A flickers and the value can be set.
- 6)     → '270' is inputted in Address A and it lights.
- 7)   → When inputting 'F', the under bar is displayed under the character 'F'.
After inputting 'ENT', Address F flickers and the value can be set.
- 8)   → '0' is inputted in Address F and it lights.
- 9)  → Calls N001 block adding +1 to N000.
- 10)  
- 11)     
- 12)  
- 13)    
- 14) 
- 15)  
- 16)   
- 17)  
- 18)    
- 19)   → When inputting 'J', the under bar is displayed under the character 'J'.
After inputting 'ENT', Address J flickers and the value can be set.

- 20)   → '0' is inputted in Address J and it lights.
The program block is stored.
- 21)  → Stores the block of program.

When 'A/' flickers during program EDIT, it shows that the program is changed. While flickering of 'A/' , the changed program is not stored into the memory. The timing that the program is stored is when the following operations are performed:

- When block change is operated by  , .
- When block No. is called by  ,  , .
- When forcedly written by .
- When the mode is changed by .


Therefore, the data is stored into memory every block shift during program EDIT. However, the power is turned OFF while flickering of 'A/' or  is pushed, the program returns to the state before changing.

5.4. Program INPUT (for 2-axis)

The following explains the steps to input the program for 2-axis.

5.4.1. Program examples

CH07
 N000 G90 A270 F0 Exe.
 N001 A-180 F500 Exe.
 N002 G91 A-90 J0 Exe.



The following content is commanded to A-axis.

The absolute command functions the angle position command from the WZRN position (G90).

The table shifts to the angle position to be 270 ° from WZRN position. (A270)

The table rotates at the rapid traverse. (F0)

The following content is commanded to A-axis.

The absolute command functions the angle position command from the WZRN position (G90).

The table rotates 75 ° from the WZRN position in reverse direction. (A-75)

The table rotates at 5min⁻¹. (F500)

The following content is commanded to A-axis.

MZRN is commanded. (G23)







The following content is commanded simultaneously to B-axis.

MZRN is commanded. (G23)

After executing the program, the program returns to block N000. (J0)

5.4.2. Program input examples

The inputting steps of the above program examples are as follows:

- 1)  → Since each MODE is changed in order by pushing , push this button until  is selected (LED lighting) several times.
- 2)    → Calls channel No. "7".
 Block N000 is called when the channel No. is called.




→ The under bar is displayed under the character 『G』 when **G** is inputted.

After inputting **ENT**, Address G flickers and the value can be set.




→ Push **A/B** to display A-axis to screen.

When A-axis is specified, the LED on upper left on **A/B** lights.




→ 『90』 is inputted in Address G and it lights.

At this time, character 『/A/』 flickers. ¹



→ When inputting **A**, the under bar is displayed under the character 『A』.

After inputting **ENT**, Address A flickers and the value can be set.




→ 『270』 is inputted in Address A and it lights.




→ When inputting **F**, the under bar is displayed under the character 『F』.


After inputting **ENT**, Address F flickers and the value can be set.



→ 『0』 is inputted in Address F and it lights.


























→ Calls N001 block adding +1 to N000.



→ Push **A/B** to display B-axis to screen.

When B-axis is specified, the LED on upper left on **A/B** lights.










- 17)  → Calls N002 block that adds 1 to N001.
- 18)  → Push  to display A-axis.
- 19)  
- 20)   
- 21)   → When inputting , the under bar is displayed under the character 『J』.
After inputting , Address J flickers and the value can be set.
- 22)   → 『0』 is inputted in Address J and it lights.
The program block is stored.
- 23)  → Push  to display B-axis.
- 24)  
- 25)   
- 26)  → Stores the block of program.


When 『A/』 flickers during program EDIT, it shows that the program is changed.

While flickering of 『A/』, the changed program is not stored into the memory.

The timing that the program is stored is when the following operations are performed:

- When block change is operated by , .
- When block No. is called by , , .
- When forcedly written by .
- When the mode is changed by .

Therefore, the data is stored into memory every block shift during program EDIT.

However, the power is turned OFF while flickering of 『A/』 or , the program returns to the state before changing.

5.5. Program DELETE

The programs such as all programs, every channel, blocks, etc., can be deleted.

5.5.1.

ALL PRG DEL

Deletes all programs in the controller.

- 1)  + 
+ POWER ON

→ When power is turned ON, the ALL PRG DEL mode (CL-1) is applied.

CL-1

CL-1 Screen

- 2) 

→ When ALL PRG DEL is started, 『ALL PRG DEL』 flickers. When 『ALL PRG END』 is displayed, the ALL PRG DEL is finished.

When the ALL PRG DEL is finished, the controller START mode is applied continuously.



5.5.2.

PRG DEL in channel



The program is deleted at the channel unit.

- 1) 

→ Selects the 『EDIT』 of program EDIT.

- 2)  [**] 

→ Calls the channel to delete the program.

- 3)  + 
(Pushed for 2 sec.
or more.)

→ When the left keys are pushed for 2 seconds or more, 『CH**PRG DEL』 occurs. When the program is completely deleted, the program returns to the initial screen.










When all programs in the channel are deleted, the N000 of select channel is displayed.

When the program capacity of 『CH**PRG DEL』 displayed during program deletion is small, it may not be read because it is only displayed in the blink of an eye.

5.5.3.

1 BLOCK DEL

Deletes a selected block.

- 1)  → Selects the 『EDIT』 of program EDIT.
- 2)  [**]  → Calls the EDIT channel.
- 3)  [**]  → Calls the block to be deleted.
- 4)   → Block No. flickers by pushing . When pushing , 『CH** PRG DEL』 is displayed and the block is deleted.

The block after deleted block is moved to left.

At this time, the block No., of program that the block No., is specified is generated automatically.

Before BLK DEL		After BLK DEL	
N000	G90 A90.000 F0	N000	G90 A90.000 F0
N001	A180	N001	G27 P9 E11
N002	G27 P10 E12	N002	G24 J0
N003	G24 J0		
N010	G90 A15.000 F1000	N009	G90 A15.000 F1000
N011	A30.000 F2000	N010	A30.000 F2000
N012	A45.000 F0	N011	A45.000 F0

DEL

Jump destination No. automatically generated








BLK No. after DEL.

During block deletion, 『CH** PRG DEL』 is displayed.

5.5.4.

1 BLOCK DATA DEL

Deletes each data of select block.

- 1)  → Selects of 『EDIT』 program EDIT.
- 2)  [**]  → Calls the channel to be edited.
- 3)  [**]  → Call the block to be deleted.
- 4)  +  → When left keys are pushed for 2 seconds or more, 『CH** PRG DEL』 is displayed and the data in the block is cleared.
(Pushed for 2 sec. or more.)

『CH** PRG DEL』 is only displayed in the blink of an eye during program deletion.

5.6. Program copy









The program can be copied at between channels and on the single block.

5.6.1.

Program copy between channels

The programs can be copied at between channels.

Though all programs inside of channels can be copied, the part of n-line ~ n-line of block cannot be copied.

- 1)  → Select the 『EDIT』 of program EDIT.
 - 2)  [**]  → Select the channel to be an original copy.
 - 3)  + 
(Pushed for 2 second or more.) → When the left keys are pushed for 2 seconds or more, the screen of channel copy mode is displayed.
- Copy 00 - - 00
- Copy Mode Screen
- 4)  → The right channel No. that is copying destination is deleted and the value can be set.
 - 5) [**]  → Determines the channel No. of copy destination.
 - 6)  → Starts the copy at between channels. During copy, channels Nos., of copy source and copy destination flicker. After a long time, 『END』 is displayed and the program copy is completed.










All programs in the channels are deleted and the N000 of select channel is displayed.

When the program capacity of 『CH**PRG DEL』 displayed during program deletion is small, it may not be read because it is only displayed in the blink of an eye.

5.6.2.

1 BLOCK COPY

Copies and inserts the contents of selected block into the next block.

- 1)  → Select the 『EDIT』 of program EDIT.
- 2)  [**]  → Call the channel to be edited.
- 3)  [**]  → Call the block to be copied.
- 4)   → When pushing , the block No., flickers.
When pushing , the block of the same contents is copied into the next block.

Shifts the block after the block that is not copied to the back one by one.

At this time, the block No., of program contents that the block No., is specified is automatically generated.

Before block copy

```

N000 G90 A90.000 F0
N001 A180 . . . . . ← Addition
N002 G27 P10 E12
N003 G24 J0

N010 G90 A15.000 F1000
N011 A30.000 F2000
N012 A45.000 F0

```

After block copy

```

N000 G90 A90.000 F0
N001 A180.000
N002 A180.000 . . . . . Added block
N003 G27 P11 E13
N004 G24 J0 ← Automatically generated
              jump-destination No.

N011 G90 A15.000 F1000
N012 A30.000 F2000
N013 A45.000 F0

```

BLK No. after addition

The final block of channel is forcedly deleted.

When there is the program that the final block of channel is specified at the jump destination and the block is copied at front of its block, the alarm of 『Err961 BLOCK INS ERROR』 occurs. Thus, the block is not copied.

6 Operation

6.1. Emergency stop

6.1.1.

To perform EMERGENCY STOP

- . Push the EMERGENCY STOP button on the pendant.
- . During the emergency stop, 『 Err001 EMERGENCY STOP 』 is displayed on the screen and the table becomes the emergency stop state.
- . In the emergency stop state, an alarm is outputted. When the emergency stop button is pushed, the emergency stop mode is outputted to the external equipment.
- . During the emergency stop, the main power source of the servo amplifier is turned OFF and the circular table cannot be operated.

6.1.2.

To release EMERGENCY STOP

※ **Remove the cause of fault before releasing the emergency stop.**

- . When the EMERGENCY STOP button is turned to right, the button comes out.
- . When pushing **RESET** on the panel, the emergency stop is released. It can also be released with the external RESET (RST) button except the panel.
- . The alarm OUTPUT and emergency stop OUTPUT outputted during the emergency stop are turned OFF.
- . When the emergency stop is released, the main power is supplied to the servo amplifier and the circular table can be operated.

6.2. Auto run


The following explains the steps to operate the table by the program into the memory automatically.

6.2.1.

Program selection Select to the program to be operated automatically.




→ When pushing **MODE**, the mode is changed in order. Push this button several times until 『 EDIT 』 is selected (LED lighting).



→ Select an auto run execution program. When the channel is changed, the block of N000 is selected.

When executed except block No. N000.



→ Select the auto run execution block.

6.2.2.

Mode selection Select the AUTO mode to perform the auto run.



→ When pushing **MODE**, the mode is changed in order. Push this button several times until 『 AUTO 』 is selected (LED lighting).

6.2.3.

Program START Perform the auto run of program.

When the program is executed from the pendant.



+ ENABLE switch

→ Automatically operate the program by 1-block currently displayed.

The ENABLE switch is required only start.

Even if operation is released during automatic operation, it does not stop.

When the program is executed from the external signal.

Turn ON 【 ST 】 of → The operation content is the same as above.
external START signal.

During auto run, STATUS 『 RUN 』 LED goes out and 『 STOP 』 lights.

When the auto run by 1-block is completed, STATUS 『 RUN 』 LED goes out and 『 STOP 』 lights.

6.2.4.**To stop program temporarily during execution**

Stop the auto run temporarily during execution.

When the program is stopped temporarily from the pendant.



➔ Stop the program temporarily during operation.

When the program is stopped temporarily by external signal.

Turn OFF 【 SP 】 of ➔ The operation content is the same as above.
external STOP signal.

During TEMP. STOP, both LEDs of STATUS 『 RUN 』 and 『 STOP 』 light.

6.2.5.**To restart program during TEMP. STOP**

Restart the program stopped temporarily by STOP inputting mode.

When the program is restarted from the pendant panel.



+ ENABLE switch

➔ Remained program that the program is stopped because of TEMP. STOP is operated automatically.

When the program is restarted by the external signal.

Turn ON 【 SP 】 of ➔ Release the STOP signal from the external
external STOP signal. equipment.

Turn ON 【 ST 】 of ➔ The operation content is the same as above.
external START signal.

During auto run, STATUS 『 RUN 』 LED lights.

When the auto run by 1-block is completed, STATUS 『 RUN 』 LED goes out and 『 STOP 』 lights.

6.2.6.**Program interruption**

Interrupt the program during execution to stop the operation.

When the program is interrupted from the panel.



➔ Stop the operation during auto run to reset it.

When the program is interrupted by the external signal.

Turn ON 【 RST 】 of ➔ The operation is stopped during automatic
external RESET signal. operation to reset the machine.

After resetting, STATUS 『 RESET 』 LED lights.

The block of program returns to a top line (N000).

6.3. Manual run

The following explains the steps to operate the table manually by a MANUAL mode.

6.3.1.

Mode selection

Select the MANUAL mode to operate the table manually.



→ When pushing **MODE**, the mode is changed in order. Push this button several times until 『MANUAL』 is selected (LED lighting).

6.3.2.

Axis selection

In case of MAC mini iH2/iHT, the axis to be manually operated is selected.



→ **A/B** When pushing, A-axis and B-axis are changed.

The LED selecting the axis lights.

6.3.3.

Low speed JOG feed

A low speed JOG feed is actuated by a manual run.



+ENABLE switch

→ The table rotates in CW direction (Clockwise) with the button pushed.



+ENABLE switch

→ The table rotates in CCW direction (Counterclockwise) with the button pushed.

STATUS 『RUN』 LED lights during feed.


Precautions

- A low speed JOG federate is the set speed of PRM005.
However, since the set value of PRM003 (Rapid traverse) is determined as upper limit, the set value more than its value is restrained by the set value of PRM003.
- The machine can be manually operated only when the ENABLE switch is pushed.

6.3.4.

High speed JOG feed

A high speed JOG feed is actuated by a manual run.



➔ With two keys still pushed simultaneously, the table rotates in CW (Clockwise).

+ ENABLE switch



➔ With two keys still pushed simultaneously, the table rotates in CCW (Counterclockwise).

+ ENABLE switch

STATUS \square RUN \square LED lights during feed.

When releasing **HI** during high speed feed, the mode becomes the low speed JOG feed continuously. When pushing **HI** during a low speed feed, the mode becomes the high speed JOG feed.

Precautions

- The high speed JOF feed the set speed of PRM004.
However, since the set value of PRM003 (Rapid traverse) is determined as upper limit, the set value more than its value is restrained by the set value of PRM003.
- The machine can be manually operated only when the ENABLE switch is pushed.

6.3.5.

STEP feed

Shift the table every angle determined.



➔ The table shifts by the set angle in + direction by keying in at one shot.

+ ENABLE switch



➔ The table shifts by the set angle in - direction by keying in at one shot.

+ ENABLE switch

STATUS \square RUN \square LED lights during feed.

Precautions

- The step feed amount is set to PRM006 and an initial set value is 0.001 °.
- One shot time is 1 second or less.
When pushing the button for 1 second or more, the mode becomes the low speed JOG feed.
- The machine can be manually operated only when the ENABLE switch is pushed.

6.4. Override

The following explains the steps to apply the override for the speed of the auto run or manual feed.

6.4.1.

Override display

Display any override state for a command federate.



→ The percent (%) for the command speed is displayed on the right side of screen.

The override display becomes effective when “ AUTO ” or “ MANUAL ” mode is selected.

6.4.2.

Override change

Increase or reduce the override.



→ The override is added as often as **INS** is pushed.

When INCREASE is repeated, “ MAX ” is displayed and the mode becomes the rapid traverse.



→ The override is reduced as often as **DEL** is pushed.

The minimum set value of override is “ 20% ”.

When the override is except 100% with “ AUTO ” or “ MANUAL ” mode selected, LED of each mode flickers.

Precautions

- The INCREASE or DECREASE every button pushing is set to PRM014 and the initial set value is 5%.

Even if the override is changed, since the set value of PRM003 (Rapid traverse) is determined as upper limit, the set value more than its value is restrained by the set value of PRM003.

6.5. Manual pulse generator (Option)

The manual pulse generator can be used by the MANUAL mode.

The following explains the operating steps of manual pulse generator.

6.5.1.

Conf. display of manual pulse generator

Display to check that the manual pulse generator selects the axis as is.

Selected to A-axis → LED on A-axis of **A/B** flickers.

Selected to B-axis → LED on B-axis of **A/B** flickers.

Axis set to OFF. → LED on A-axis or B-axis (selected side) of **A/B** lights.

6.5.2.

Shifted by manual pulse generator

Shift the axis with the manual pulse generator.



→ Push **MODE** and selects 『 MANUAL 』.

Axis selection → Select the axis to be shifted with the manual pulse generator.

In case of 1-axis spec., A-axis is selected.

In case of 2-axis spec., A-axis or B-axis is selected.

Shift factor selection → Select the scale factor of feed with the manual pulse generator as follows:
When shifting at 0.001 ° unit, “ × 1 ” is selected, at 0.01 ° unit, “ × 10 ” is selected and at 0.1 ° unit, “ × 100 ” is selected.

Dial turned in CW → Selected axis is shifted in + direction according to the scale factor.

Dial turned in CCW. → Selected axis is shifted in - direction according to the scale factor.

Precautions

- A / B axes of 2-axis spec., are set by PRM117. The axis set as PRM117=1 is A-axis and the axis set as PRM117=2 is B-axis
- When operating the rotary table with the manual pulse generator, though the table may rotate in an improper motion, there is no problem.

7 Diagnostics

7.1. Diagnostic screen structure / Operation

The diagnostic screen can check the situations such as the coordinate system, I/O, servo, etc.

7.1.1. Diagnostic screen structure

Thirteen screens are prepared as shown bellow:

Coordinate system

- Commanded Work Coordinate Display (WP-R)
- Commanded Machine Coordinate Display (MP-R)
- Work Coordinate Encoder Data Value Display (WP-E)
- Machine Coordinate Encoder Data Value Display (MP-E)
- Remained Shift Display (RD-R)

I/O system

- Externally Connected INPUT State Display (AC-I)
- Table INPUT State Display (EA-I)
- Externally Connected OUTPUT State Display (AC-O)
- Table OUTPUT State Display (EA-O)

Servo system


- POS-DEV Display (P-DEV)
- Rotor Angle Display (ROTOR)
- MZRN Data Display (DA-ZP)
- Current % Display (CUR-LF)



7.1.2. Diagnostic screen display

The diagnostic screen is displayed in order.



→ As often as **DGN** is pushed, the diagnostic screen is changed every page.



1-axis spec.2-axis spec.

As shown the above, only A-axis is displayed at 1-axis spec. (MAC mini iH / iHF) . Both axes are displayed on a screen (A-axis on upper stage, B-axis on lower stage) at 2-axis spec. (MAC mini iH2 / iHT series)

This display method is common to a general diagnosis screen.

7.1.3.**I/O diagnostic display content confirmation**

On the diagnostic screen of I/O system, the I/O condition is displayed with “ 1 ”: ON , “ 0 ”: OFF. The under bar located under 1 ” or “ 0 ” shows the signal content.



→ Feeds the signal content to right. At this time, “ _ ” under the signal condition display (“ 1 ” , “ 0 ”) is shifted in order.

When keying in at the right edge, the signal is shifted to left.



→ Feeds the signal content to left. At this time, “ _ ” under the signal condition display (“ 1 ” , “ 0 ”) is shifted in order.

When keying in at the left edge, the signal is shifted to right.




→ The left top signal is selected.

7.2. Command work coordinate display (WP-R)

The angle commanded by the program is displayed on the coordinate system on the basis of WZRN position (0.000) .

7.2.1. Command work coordinate screen




In case of 2-axis spec., the content of A-axis is displayed on upper stage and that of B-axis on lower stage.

The block No. displayed becomes an execution block during operation and it becomes a next execution block during stop.

7.3. Command machine coordinate display (MP-R)

The angle commanded by the program is displayed on the coordinate system on the basis of WZRN position (0.000) .

7.3.1. Command machine coordinate screen



In case of 2-axis spec., the content of A-axis is displayed on upper stage and that of B-axis on lower stage.

The block No. displayed becomes an execution block during operation and it becomes a next execution block during stop.

7.4. Remained shift display (RD-R)

Remained shift is displayed for the command position.

7.4.1. Remained shift screen



In case of 2-axis spec., the content of A-axis is displayed on upper stage and that of B-axis on lower stage.


The block No. displayed becomes an execution block during operation and it becomes a next execution block during stop.

7.5. External connection INPUT condition display (AC-I)


The INPUT signal condition of external connection (CB3i cable) is displayed with “ 1 ”: ON , “ 0 ”: OFF.

7.5.1.

External connection INPUT screen



Detailed INPUT signal names



N+ and **N-** can select the INPUT signal and selected signal name is displayed on the lower left.

Mark “ * ” of INPUT signal name shows B-contact.

Since the INPUT signal is used together for A and B axes, it is not displayed every axis.


7.6. Table INPUT condition display (EA-I)

The INPUT signal condition of table is displayed with “ 1 ”: ON , “ 0 ”: OFF.

7.6.1.

Table INPUT screen

1-axis spec.



2-axis spec.




Table INPUT state display

ZRN/ External ZRN INPUT

*OT2/ Overtravel 2

*OT1/ Overtravel 1

*DEC/ MZRN signal

UNCLAMP/ Unclamp

CLAMP/ Clamp

An INPUT signal name can be displayed individually for A-axis and B-axis.


N+ , **N-** can select the INPUT signal name and the selected signal name is displayed on the right side of INPUT signal.

Mark “ * ” of INPUT signal name shows B-contact.

7.7. External connection OUTPUT condition display (AC-0)

The OUTPUT signal condition of external connection (CB3i cable) is displayed with “ 1 ”: ON, “ 0 ”: OFF.

7.7.1. External connection OUTPUT screen



N+ , **N-** can select OUTPUT signal name.

Mark “ * ” of OUTPUT signal name shows B-contact.

Since OUTPUT signal of A-axis is used together with B-axis, its signal is not displayed every axis.

7.8. Table OUTPUT condition display (EA-0)

The OUTPUT signal condition of table is displayed with “ 1 ”: ON , “ 0 ”: OFF.

7.8.1. Table OUTPUT screen

1 -axis spec.

Axis name(“ 1 ” :ON, “ 0 ” :OFF) Select signal name

A	0	1	1	0	SERVO	ON	EA-0
---	---	---	---	---	-------	----	------

2-axis spec.

A	0	1	1	0	SERVO	ON	EA-0
B	0	1	1	0	ZRNFIN		

Table OUTPUT condition display

ZRNFIN/Machine zero return finish
360FIN/Work zero position output
G99FIN/Optional block finish
BRAKE ON/ Brake ON
SERVO ON/ Live servo


Each OUTPUT signal name for A-axis and B-axis can be displayed.

In the OUTPUT signal name, the axis selected with the axis change key can be selected with **N+** , **N-** .

7.9. WCRNT encoder data display (WP-E)

The coordinate system based on WZRN POS (0.000) displays the angle on the current encoder data. This data differs from a command and it is calculated from the motor data of current position.

7.9.1. Work coordinate encoder data screen




In case of 2-axis spec., the content of A-axis is displayed on upper stage and that of B-axis on lower stage.

The block No. displayed becomes an execution block during operation and it becomes a next execution block during stop.

7.10. Machine coordinate encoder data display (MP-E)

The coordinate system based on MZRN POS (0.000) displays the angle on the current encoder data. This data differs from a command and it is calculated from the motor data of current position.

7.10.1. Machine coordinate encoder data screen




In case of 2-axis spec., the content of A-axis is displayed on upper stage and that of B-axis on lower stage.

The block No. displayed becomes an execution block during operation and it becomes a next execution block during stop.

7.11. POS-DEV display (P-DEV)

This mode displays the difference of the program command and an actual shift position.

7.11.1. POS-DEV screen



In case of 2-axis spec., the content of A-axis is displayed on upper stage and that of B-axis on lower stage.


The block No. displayed becomes an execution block during operation and it becomes a next execution block during stop.

When POS-DEV shows “ - ”, it means that feed is insufficient. When “ + ”, it means that the feed is passed.

7.12. Rotor angle display (ROTOR)

This mode displays that any rotor angle is detected from the basic pulse of motor encoder.

7.12.1. Rotor angle screen



In case of 2-axis spec., the content of A-axis is displayed on upper stage and that of B-axis on lower stage.


The block No. displayed becomes an execution block during operation and it becomes a next execution block during stop.

7.13. MZRN data display (DA-ZP)

This mode displays the angle from the deceleration dog detection in MZRN to basic pulse of motor encoder.

This displayed-value is updated as often as MZRN is repeated.

7.13.1. MZRN data screen




In case of 2-axis spec., the content of A-axis is displayed on upper stage and that of B-axis on lower stage.

The block No. displayed becomes an execution block during operation and it becomes a next execution block during stop.

7.14. Current % display (CUR-LF)

This mode displays the current load condition at % for motor rated current value.


7.14.1. Current % screen



In case of 2-axis spec., the content of A-axis is displayed on upper stage and that of B-axis on lower stage.

8 Program Examples

8.1. Unequal partition




Incremental

N000	G91 A45.000 F0	Incremental command
		45 ° rev. at rapid traverse
N001	A85.000	85 ° rev. at rapid traverse
N002	A92.000	92 ° rev. at rapid traverse
N003	A58.000	58 ° rev. at rapid traverse
N004	A80.000 J0	80 ° rev. at rapid traverse
		To top program of N000

Absolute

N000	G90 A45.000 F0	Absolute command
		Rev. to 45 ° pos at R/trvs.
N001	A130.000	Rev. to 130 ° pos at R/trvs.
N002	A222.000	Rev. to 222 ° pos at R/trvs.
N003	A280.000	Rev. to 280 ° pos at R/trvs.
N004	A0.000 J0	Rev. to 0 ° pos at R/trvs.
		To top program of N000

8.2. Equipartition



Block repeating

N000	G91 A45.000 F0 J0	Incremental command
		45 ° rev. at rapid traverse
		To top program of N000


This program is repeated 8 times.

Partition command

N000	G91 A360.000 F0 D8 J0	Rev. to 360 ° /8 at R/trvs.
		To top program of N000


For revolution of 360 ° /8(45 °), the ST signal is required every cycle. After operating 8 times, the program is finished.

8.3. Loop jumping functions




N000	G91 A-120.000 F0	Incremental command -120 ° rev. at R/trvs.
N001	A10.000	10 ° rev. at R/trvs.
N002	A20.000	20 ° rev. at R/trvs.
N003	G25 A30.000 J1	Escaped from loop after revolving 30 ° at rapid traverse when passed through WZERO position or stopped at its place. When not passed or stopped, the block jumps to N001 and loop is repeated.
N004	G90 A120.000 J0	Absolute command Revolved to 120 ° position at rapid traverse. To program top of N000

8.4. Repeating functions



N000	G27 P010 E012 L6 J0	Repeating command N010 ~ N012 are repeated 6 times. To program top of N000
N010	G91 A10.000 F0	Incremental command 10 ° rev. at R/trvs.
N011	A20.000	20 ° rev. at R/trvs.
N012	A30.000	30 ° rev. at R/trvs.

8.5. Subprograms



N000	G91 A20.000 F0 J10	Incremental command 20 ° rev. at rapid traverse. Subprogram jumps to N010.
N001	A30.000 J10	30 ° rev. at rapid traverse. Subprogram jumps to N010.
N002	A40.000 J10	40 ° rev. at rapid traverse. Subprogram jumps to N010.
N010	A20.000	20 ° rev. at rapid traverse.
N011	A30.000	30 ° rev. at rapid traverse.
N012	A40.000 J-1	40 ° rev. at rapid traverse. Because of subprogram end, returned to original place before jumping.

PARAMETER • EXPANSION MANUAL

■ Readers for This Manual

Readers for this manual are as follows:

- Persons who make trial run or servo adjustment
- Persons who adjust parameters
- Persons who control inside data

C o n t e n t s

1	Parameter	P1-1
1.1.	PARAMETER SETTING	P1-1
1.1.1.	Setting preparation	P1-1
1.1.2.	Setting steps	P1-2
1.2.	PARAMETER LIST	P1-3
1.3.	DETAILED PARAMETERS	P1-14
2	ORG MODE Selection	P2-1
2.1.	TO SET ORG MODE	P2-1
2.2.	DIRECTLY SETTING METHOD	P2-2
2.2.1.	Directly setting of ORG MODE	P2-2
2.3.	DETECTOR MARKER DETECTING METHOD (NON-DOG TYPE)	P2-3
2.3.1.	Detector marker detecting set	P2-3
2.4.	DOG TYPE ORG MODE SELECTION	P2-4
2.4.1.	Dog type ORG MODE Selection	P2-4
3	Pitch Error Compensation	P3-1
3.1.	OUTLINE	P3-1
3.2.	PARAMETER SETTING	P3-1
3.2.1.	Parameters	P3-1
3.2.2.	Parameter setting examples	P3-2
4	Expansion Channel	P4-1
4.1.	STRUCTURE	P4-1
4.2.	PARAMETER SETTING.....	P4-2
4.2.1.	Channel/block structure spec.	P4-2
4.2.1.1.	PRM390=1	P4-2
4.2.1.2.	PRM390=2	P4-2
4.2.2.	Block setting	P4-3
4.2.2.1.	Parameter setting examples	P4-4
5	External Channel Selection	P5-1
5.1.	BINARY MODE	P5-1
5.1.1.	Parameter setting.....	P5-1
5.1.2.	External I/O signals	P5-1
5.1.3.	Binary list	P5-2
5.1.4.	Timing	P5-2
5.2.	M-SIGNAL MODE	P5-3
5.2.1.	Parameter setting	P5-3
5.2.2.	External I/O signals	P5-3
5.2.3.	Timing	P5-4
6	Over Travel	P6-1
6.1.	PARALLEL DETECTING METHOD	P6-1
6.1.1.	Parameter setting	P6-1
6.1.2.	OT Detection	P6-1

6.1.3.	To release OVER TRAVEL	P6-1
6.1.4.	Forcedly shifting method	P6-2
6.2.	SERIAL DETECTING METHOD	P6-3
6.2.1.	Parameter setting	P6-3
6.2.2.	OT Detection	P6-3
6.2.3.	To release OVER TRAVEL	P6-4
6.2.4.	Forcedly shifting method	P6-4
7	Data Communication	P7-1
7.1.	DATA COMMUNICATION	P7-1
7.2.	PROGRAM DATA COMMUNICATION USING CONTROLLER FUNCTIONS	P7-2
7.2.1.	Program input	P7-2
7.2.2.	Interruption during program input	P7-3
7.2.3.	Program output.....	P7-3
7.2.4.	Interruption during program output	P7-3
7.3.	COMMUNICATING PARAMETER DATA USING CONTROLLER	P7-4
7.3.1.	Program input	P7-4
7.3.2.	Interruption during program input	P7-5
7.3.3.	Program output	P7-5
7.3.4.	Interruption during program output	P7-5
7.4.	COMMUNICATION DATA FORMAT	P7-6
7.4.1.	Program data	P7-6
7.4.2.	Parameter data	P7-6

1. Parameter

1.1. Parameter setting

The parameter setting mode differs by the methods combining with the circular table. Therefore, this mode is used for setting the data corresponding to the circular table and for using the various control functions in several ways.

1.1.1.

Setting preparation

Each parameter can be set only by PARAM (parameter) mode regardless of STATUS such as alarms, etc.

To prevent the mis-input of parameter, the parameter cannot be inputted unless a SET PERMISSION code is inputted.

When inputting the parameter, input the SET PERMISSION code into PRM110.

The content of PRM110 becomes the write inhibit state (PRM110=0) of an initial value when the mode is changed or power is turned OFF.

SET PERMISSION code

0 (STD Value)	All parameters cannot be set.
1	Parameters of PRM001 ~ 499 can be changed.
999	All parameters of PRM001 ~ 633 can be changed.

1.1.2. Setting steps

MODE (Push until PARAM is selected.)
ENT (Make PRM110 in setting state.)
1 or **9** **9** **9** (Input a settable code.)
ENT (Set a SET PERMISSION code.)

A:110 1
 PRM INPUT PERMISSION

PRM INPUT permission

Above is the steps for PRM INPUT PERMISSION and the PARAM LED of MODE flickers.

In case of 2-axis spec., push **A/B** and select the axis that sets the parameter before inputting the following data.

N [PRM No.] **ENT** (Specify the parameter set.)
ENT [Set value] **ENT** (Change to set value.)

Similarly, change the parameter required for change.

INPUT (Parameter setting register)

A:003 33.33
 RAPID TRAVERSE

Parameter setting

- As the parameter selection method of , the parameter can also be selected one by one with **N+** (Next selection) , **N-** (Former selection) .
- When inputting the set value of , the current set value flickers by pushing **ENT** first. When pushing **ENT** after inputting the set value, a newly set value lights.

Precautions

- When **INPUT** is not pushed after changing the parameter, the final parameter is not set.


When the mode is changed and power is turned OFF without pushing **INPUT**, the parameter set value returns to the value before changing.

1.2. Parameter list

- Mark in remarks' column shows that a set value cannot be changed.
- For mark in remarks' column, it is necessary to turn OFF power in order to make a changed parameter valid.
- In MAC mini iH2/iHT, when a standard set value differs per axis, the values of A-axis/B-axis are entered to the standard set values. In case of MAC mini iH/iHF (1-axis spec.), A-axis is set.
- The parameter that the parameter column is masked shows that it is common parameter in case of 2-axis spec.

No.	Name	STD Set-value		Set unit	Set range	Remarks
	Displayed Message	A-axis	B-axis			
000	ROM Version					
	ROM VER					
002	MZRN DECEL. Speed	0.70		min ⁻¹	0.00 ~ 1.00	
	MZRN LOW FEED					
003	Rapid Traverse (Max. rotation speed)	41.66	16.66	min ⁻¹	0.00 ~ 99.99	Note1
	RAPID TRAVERSE					
004	JOG HI Speed	41.66	16.66	min ⁻¹	0.00 ~ 99.99	Note1
	HI JOG FEED					
005	JOG HI Speed	1.00		min ⁻¹	0.00 ~ 99.99	
	LO JOG FEED					
006	Step Feed Amount	0.001		deg	0.000 ~ 10.000	
	STEP FEED AMOUNT					
007	MZRN Shift Amount	0.000		deg	-360.000 ~ 360.000	
	MZRN SHIFT AMOUNT					
008	MZRN Feed	41.66		min ⁻¹	0.00 ~ 99.99	Note1
	MZRN FEED					
009	Position Deviation Check Setting Time	0.30		SEC	0.00 ~ 1.00	
	POS-DEV CHECK TIMER					
010	Position Deviation Check Setting _Amount	0.100		deg	0.000 ~ 16.000	
	POS-DEV CHECK AMOUNT					
011	Gear Ratio 1/X	72	180		0,36,45 ~ 999	Note1
	GEAR RATIO 1/X					
013	Motor Rev. direction Flag	0			0,1	Note1
	MOTOR DIRECTION					
014	Override Step Amount	5		%	0 ~ 100	
	MOTOR DIRECTION					
015	Deviation Check Amount in Clamp	0.020		deg	0.000 ~ 16.000	
	POS-DEV CHECK CLAMP					
016	MZRN Direction	0			0,1	
	MZRN DIRECTION					
017	MZRN · WZRN in Short Cut Direction	0	1		0,1,2	
	ZRN SHORT CUT DIR					
018	Optional Angle Assignment in Short Cut Return Direction	0.000		deg	0.000 ~ 359.999	
	ZRN DIR OPT POS					
020	BLKFIN Output Flag in G08, G09	0			0,1	
	BLKFIN FLAG (G08)					

No.	Name	STD Set-value		Set Unit	Set Range	Remarks
	Displayed Message	A-axis	B-axis			
021	BLKFIN Output Flag in G07	0			0,1	
	BLKFIN FLAG (G07)					
022	Object Signal of BLKFIN OUTPUT	0			0,1	
	BLKFIN TRIGGER					
023	Alarm Scan Cycle of Unclamp Signal	0.00		SEC	0.00 ~ 10.00	
	ALARM SCAN UNCLUMP					
024	Alarm Scan Cycle of Clamp Signal	0.00		SEC	0.00 ~ 10.00	
	ALARM SCAN CLAMP					
025	360FIN Output Spec.	0			0,1	
	360FIN OUTPUT SPEC					
026	360FIN Output Area.	0.000		deg	0.000 ~ 1.000	PRM25=1
	360FIN OUTPUT AREA					
027	360FIN OUTPUT SPEC	0			0,1,2	
	G99FIN OPR SPEC					
028	G99FIN Check Timer	0.00		SEC	0.00 ~ 9.99	
	G99FIN CHECK TIMER					
029	External ZRN Input Spec.	0			0,1,2	
	EXT ZRN SPEC					
030	SP Signal Function Spec.	0			0,1	
	SP/EXT SP FUNC SPEC					
031	External MZRN Function	0			0,1,2,3	
	MZRN BY THE EXT ST					
032	Clamp Spec.	0			0,1	
	CLAMP SPEC					
033	External Channel Spec.	0			0,1	
	EXT CH SPEC					
034	360FIN Output Contact Flag	1			0,1	
	360FIN CONTACT FLAG					
035	BLKFIN Timer	0.50		SEC	0.00 ~ 1.00	
	BLKFIN TIMER					
036	360FIN Timer	0.50		SEC	0.00 ~ 1.00	
	360FIN TIMER					
037	Timer from Unclamp to Rev. Start	0.00		SEC	0.00 ~ 1.00	
	ST TIMER FROM UCL					
038	Clamp Signal Flag	0			0,1	Note1
	CLAMP SIGNAL FLAG					
039	Clamp Output Contact Flag	0			0,1	
	BRAKE CONTACT FLAG					
040	Rev. Direction in Continuous Start (G22)	0			0,1	
	REV DIR (G22)					
041	Rev. Feed in Continuous Start (G22)	5.00		min ⁻¹	0.00 ~ 99.99	
	REV FEED (G22)					
042	BLK/G99 FIN Output Start Delay Flag (G21)	0			0,1	
	BLK/G99 DELAY (G21)					
043	BLK/G99 FIN Output Start Delay Timer (G21)	0.00		SEC	0.00 ~ 1.00	
	BLK/G99 DELAY TIMER					
044	Servo Control Flag	0			0,1	Note1
	SERVO CONTROL FLAG					

No.	Name	STD Set-value		Set Unit	Set Range	Remarks
	Displayed Message	A-axis	B-axis			
046	Panel ST Key Input Flag in AUTO Mode	0			0,1	
	ST KEY IN AUTO					
047	WZERO Position Setting every Channel  Each channel setting : PRM300 ~ PRM389	0			0,1	
	SETUP WZERO POS					
100	Software Limit Specification	0			0 , 1 , 2	
	S/W LIMIT SPEC					
101	Software Limit MIN	0.000		deg	0.000 ~ 359.999	
	S/W LIMIT OF MIN					
103	Software Limit MAX	0.000		deg	0.000 ~ 359.999	
	S/W LIMIT OF MAX					
105	Unidirectional Positioning Spec.	0	1		0 , 1 , 2	
	UNIDIRECTIONAL SPEC					
106	Unidirectional Positioning Approach Amount	0.000	1.000	deg	0.000 ~ 359.999	
	UNIDIRECTIONAL ANGLE					
110	Parameter INPUT Permission Flag	0			0 , 1 , 999	
	PRM INPUT PERMISSION					
112	Channel Select Flag CH SELECT FLAG	0			0 , 1	
117	Axis Type	iH / iHF : 0 iH2 / iHT : 1			0 , 1	
	AXIS TYPE					
121	Over Travel Detecting Type	0			0 , 1	
	OT ADMIN TYPE					
122	MZERO Position Setting Method	0			0 , 1 , 2	
	ORG MODE SELECT					
123	MZERO Position Establishing Flag	1			0 , 1	
	ORG POS COMPLETE					
200	Zero Pulse Mask Amount	0.000		deg	0.000 ~ 9.999	
	Z-PULSE MASK AMOUNT					
203	Backlash Compensation Amount	0.010			0.000 ~ 1.000	
	BACKLASH COMP AMOUNT					
206	OV RUN Contact Type	0	1		0 , 1	
	OV RUN CONTACT TYPE					
208	Pitch Error Com.01 (000 ° < 015 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 01					
209	Pitch Error Com.02 (015 ° < 030 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 02					
210	Pitch Error Com.03 (030 ° < 045 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 03					
211	Pitch Error Com.04 (045 ° < 060 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 04					
212	Pitch Error Com.05 (060 ° < 075 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 05					
213	Pitch Error Com. 06 (075 ° < 090 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 06					
214	Pitch Error Com. 07 (090 ° < 105 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 07					

No.	Name	STD Set-value		Set Unit	Set Range	Remarks
	Displayed Message	A-axis	B-axis			
215	Pitch Error Com. 08 (105 ° < 120 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 08					
216	Pitch Error Com. 09 (120 ° < 135 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 09					
217	Pitch Error Com. 10 (135 ° < 150 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 10					
216	Pitch Error Com. 09 (120 ° < 135 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 09					
217	Pitch Error Com. 10 (135 ° < 150 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 10					
218	Pitch Error Com. 11 (150 ° < 165 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 11					
219	Pitch Error Com. 12 (165 ° < 180 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 12					
220	Pitch Error Com. 13 (180 ° < 195 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 13					
221	Pitch Error Com. 14 (195 ° < 210 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 14					
222	Pitch Error Com. 15 (210 ° < 225 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 15					
223	Pitch Error Com. 16 (225 ° < 240 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 16					
224	Pitch Error Com. 17 (240 ° < 255 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 17					
225	Pitch Error Com. 18 (255 ° < 270 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 18					
226	Pitch Error Com. 19 (270 ° < 285 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 19					
227	Pitch Error Com. 20 (285 ° < 300 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 20					
228	Pitch Error Com. 21 (300 ° < 315 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 21					
229	Pitch Error Com. 22 (315 ° < 330 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 22					
230	Pitch Error Com. 23 (330 ° < 345 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 23					
231	Pitch Error Com. 24 (345 ° < 360 °)	0.000		deg	-32.766 ~ +32.766	
	PITCH ERROR 24					
240	RS232C Communication Speed RS232C BAUD RATE	2			0 , 1 , 2 , 3	
242	RS232C Data Length RS232C DATA HEAD	0			0 , 1	
243	RS232C Parity Bit RS232C PARITY BIT	0			0 , 1 , 2	
244	RS232C Stop Bit RS232C STOP BIT	0			0 , 1	
245	Servo Parameter Check Function in Power ON SERVO PRM CHECK FUNC	0			0 , 1 , 2	

No.	Name	STD Set-value		Set Unit	Set Range	Remarks
	Displayed Message	A-axis	B-axis			
250	Imposition Width	10		0.001deg	0 ~ 32767	
	IMPOSITION WIDTH					
251	Constant 1 in Acceleration/Deceleration	150		msec	0 ~ 1000	
	ACC/DEC CONSTANT 1					
252	Constant 1 in Acceleration/Deceleration	1		msec		
	ACC/DEC CONSTANT 2					
253	Enable Switch Flag	0			0 , 1	
	ENABLE SW FLAG					
255	MZRN Dead Slow Speed Percent	0		%	0 ~ 100	
	MZRN 2TH FL RATE					
256	360 ° FIN Chattering Prevention Timer	0.0		SEC	0.0 ~ 1.0	
	360FIN CHATTERING					
257	MZRN Mode	15		SEC		
	HMODE					
258	MZRN Time-out	100		SEC		
	MZRN TIME-OUT					
300	WZERO Position Every Channel (CH00)	0.000		deg	0.000 ~ 359.999	
	WZERO POSITION CH00					
389	WZERO Position Every Channel (CH89)	0.000		deg	0.000 ~ 359.999	
	WZERO POSITION CH89					
390	Channel/Block Structure Spec.	0			0 , 1 , 2	
	CH/BLOCK CHECKIG SPEC					
400	Number of Blocks every Channel (CH00)	0		BLOCK	0 ~ 1000	
	BLOCKS OF CH00					
489	Number of Blocks every Channel (CH89)	0		BLOCK	0 ~ 1000	
	BLOCKS OF CH89					

Servo parameter

- Mark in remarks' column shows that a set value cannot be changed.
- For mark in remarks' column, it is necessary to turn OFF power in order to make a changed parameter valid.
- AUTO in remarks' column shows that the value is automatically set by other parameter. The set value cannot be directly changed on the parameter item of AUTO.
- The same standard set value of servo parameter is set to both A-axis/B-axis.

No.	Name	STD Set-value	Set Unit	Set Range	Remarks
	Displayed Message				
500	Function Select Basic Switch 0	0011	hex		AUTO
	P000 BASIC SW0				
501	Function Select Basic Switch 1	0000	hex		
	P001 APPLICATION SW1				
502	Function Select Basic Switch 2	0000	hex		
	P002 APPLICATION SW2				
506	Function Select Basic Switch 6	0002			
	P006 APPLICATION SW6				
507	Function Select Basic Switch 7	0002			
	P007 APPLICATION SW7				
508	Function Select Basic Switch 8	0000			
	P008 APPLICATION SW8				
510	Speed Loop Gain	400	0.1Hz	10 ~ 2000	
	P100 SPEED LOOP GAIN				
511	Speed Loop Integration Time Constant	2000	0.01msec	15 ~ 51200	
	P101 SLG INTEGRATION				
512	Position Loop Gain	400	0.1/sec	10 ~ 2000	
	P102 POS LOOP GAIN				
513	Moment Ratio of Inertial	350	%	0 ~ 20000	Note1
	P103 INERTIA RATIO				
514	2 nd Speed Loop Gain	400	0.1/sec	10 ~ 2000	
	P104 2TH S-LOOP GAIN				
515	Constant in 2 nd Speed Loop Integration	2000	0.01msec	15 ~ 51200	
	P105 2TH SLG INTE				
516	2 nd Position Loop Gain	400	0.1/sec	10 ~ 2000	
	P106 2TH POS L-GAIN				
517	Bias	0	min ⁻¹	0 ~ 450	
	P107 BIAS				
518	Bias Adding Width	7	POS COM	0 ~ 250	
	P108 BIAS ADD WIDTH				
519	Feed Forward	0	%	0 ~ 100	
	P109 FEED-FORWARD				
520	Constant in Feed Forward Filter	0	0.01msec	0 ~ 6400	
	P10A F-F FILTER				
521	Gain Application Switch	0000	hex		
	P10B GAIN APP SW				
522	Mode Switch (Torque Command)	200	%	0 ~ 800	
	P10C MODE-SW(TORQUE)				
523	Mode Switch (Speed Command)	0	min ⁻¹	0 ~ 10000	
	P10D MODE-SW(SPEED)				

No.	Name	STD Set-value	Set Unit	Set Range	Remarks
	Displayed Message				
524	Mode Switch (Acceleration)	0	10min ⁻¹	0 ~ 3000	
	P10E MODE-SW(ACC)				
525	Mode Switch (Deviation Pulse)	0	POS COM	0 ~ 10000	
	P10F MODE-SW(DEV)				
526	Auto Tuning Switch	0012	hex		
	P110 AUTO TUNING SW				
527	Speed Feedback Compensation	100	%	1 ~ 500	
	P111 SPEED-FEEDBACK				
528	Command Filter Gain	500	0.1/sec	10 ~ 20000	
	P119 CMD FILTER GAIN				
529	Command Filter Gain Compensation	1000	0.1%	500 ~ 2000	
	P11A F-GAIN COMP				
530	Command Filter Bias (CW)	100	0.1%	0 ~ 10000	
	P11E CMD F-BIAS(CW)				
531	Position Integration Time Constant	0	0.1msec	0 ~ 50000	
	P11F POS INTEGRATION				
532	3 rd Speed Loop Gain	400	0.1/sec	10 ~ 20000	
	P12B 3TH S-LOOP GAIN				
533	3 rd Loop Integration Time Constant	2000	0.1Hz	15 ~ 51200	
	P12C 3TH SLG INTE				
534	3 rd Position Loop Gain	400	0.1msec	10 ~ 20000	
	P12D 3TH POS L-GAIN				
535	4 th Speed Loop Gain	400	0.1/sec	10 ~ 20000	
	P12E 4TH S-LOOP GAIN				
536	4 th Loop Integration Time Constant	2000	0.1Hz	15 ~ 51200	
	P12F 4TH SLG INTE				
537	4 th Position Loop Gain	400	0.1msec	10 ~ 20000	
	P130 4TH POS L-GAIN				
538	Gain Change Time 1	0	1msec	0 ~ 65535	
	P131 GAIN CHANGE T1				
539	Gain Change Time 2	0	1msec	0 ~ 65535	
	P132 GAIN CHANGE T2				
540	Gain Change Wait Time 1	0	1msec	0 ~ 65535	
	P135 GAIN WAIT T1				
541	Gain Change Wait Time 2	0	1msec	0 ~ 65535	
	P136 GAIN WAIT T2				
542	Auto Gain Change Switch 1	0	hex		
	P139 AUTO GAIN FUNC1				
543	Command Filter Bias (CCW)	1000	0.1%	0 ~ 10000	
	P144 CMD F-BIAS(CCW)				
544	Prediction Control Select Switch	0	hex		
	P150 PREDICTION CTL				
545	Prediction Control Select Switch	100	%	0 ~ 300	
	P151 PREDICTION GAIN				
546	Prediction Control Dignity Ratio	100	%	0 ~ 300	
	P152 DIGNITY RATIO				
547	Servo Rigidity	60	%	0 ~ 500	
	P1A0 SERVO RIGIDITY				
548	Servo Rigidity 2	60	%	0 ~ 500	
	P1A1 SERVO RIGIDITY2				
549	Speed Feedback Filter Time Constant	30	0.01msec	30 ~ 3200	
	P1A2 SPEED F/B FLT				

No.	Name	STD Set-value	Set Unit	Set Range	Remarks
	Displayed Message				
550	Speed Feedback Filter Time Constant 2	30	0.01msec	30 ~ 3200	
	P1A3 SPEED F/B FLT2				
551	Torque Command Filter Time Constant 2	10	0.01msec	0 ~ 2500	
	P1A4 TQ FILTER2				
552	Control Assistance Switch	0	hex		
	P1A7 CTL ASSISTANCE				
553	Auxiliary Integration Gain	60	Hz	0 ~ 500	
	P1A9 AUX INTE GAIN				
554	Position Ratio Gain	60	Hz	0 ~ 500	
	P1AA POS RATIO GAIN				
555	Feed Integration Gain	60	Hz	0 ~ 500	
	P1AB FEED INTE GAIN				
556	Feed Ratio Gain	380	Hz	0 ~ 2000	
	P1AC FEED RATIO GAIN				
560	Position Control Type Select Switch	256	hex		
	P200 POS-CTL SELECT				
561	Multi-turn Limit Setting	71	rev	0 ~ 65535	AUTO
	P205 MULCH TURN LMT				
562	Position Control Function Switch	0	hex		
	P207 POS-CTL FUNC SW				
563	Position Command ACC/DECL Bias	0	1-COM unit/sec	0 ~ 65535	
	P209 POS REF BIAS				
564	Electric Gear Ratio (Numerator)	184320		1 ~ 1073741824(2 ³⁰)	AUTO
	P20E ELE-GEAR(NUM)				
565	Electric Gear Ratio (Denominator)	5625		1 ~ 1073741824(2 ³⁰)	AUTO
	P210 ELE-GEAR(DEN)				
566	PG Dividing Ratio	1000	pulse/rev	16 ~ 1073741824(2 ³⁰)	AUTO
	P212 PG DIVID				
567	Backlash Compensation Amount	0	COM UNIT	-32767 ~ 32767	
	P214 BACKLASH				
568	Backlash Compensation Time Constant	0	0.01msec	0 ~ 65535	
	P215 BACKLASH TC				
569	Position Command ACC/DEC Time Constant	0	0.1msec	0 ~ 65535	
	P216 POS-REF A/D				
570	Pos Command Moving Average Time	0	0.01msec	0 ~ 10000	
	P217 P-REF MOVE TIME				
571	Speed Command Input Gain	600	0.01V/ RTD SP	150 ~ 3000	
	P300 SPEED REF GAIN				
572	Internal Setting Speed 1	100	min ⁻¹	0 ~ 10000	
	P301 INT SET SPEED1				
573	Internal Setting Speed 2	200	min ⁻¹	0 ~ 10000	
	P302 INT SET SPEED2				
574	Internal Setting Speed 3	300	min ⁻¹	0 ~ 10000	
	P303 INT SET SPEED3				
575	JOG Feed	500	min ⁻¹	0 ~ 10000	
	P304 JOG FEED				
576	Soft Start Acceleration Time	0	msec	0 ~ 10000	
	P305 SOFT ACC TIME				
577	Soft Start Deceleration Time	0	msec	0 ~ 10000	
	P306 SOFT DEC TIME				

No.	Name	STD Set-value	Set Unit	Set Range	Remarks
	Displayed Message				
578	Speed Command Filter Time Constant	40	0.01msec	0 ~ 65535	
	P307 SPEED REF FLT				
579	Speed F/B Filter Time Constant	0	0.01msec	0 ~ 65535	
	P308 SPEED F/B FLT				
580	Vibration Detecting Switch	0			
	P310 VIBRATION SW				
581	Vibration Detecting Sensitivity	100	%	50 ~ 500	
	P311 VIBRATION SENS				
582	Vibration Detecting Level	50	min ⁻¹	0 ~ 5000	
	P312 VIBRATION LEVEL				
583	Torque Command Input Gain	30	0.1V/ RTD TRQ	10 ~ 100	
	P400 TORQUE REF GAIN				
584	Torque Command Filter Time Constant	100	0.01msec	0 ~ 65535	
	P401 TORQUE REF FLT				
585	Clockwise Torque Limitation	800	%	0 ~ 800	
	P402 CW TORQUE LMT				
586	Reverse Torque Limit	800	%	0 ~ 800	
	P403 CCW TORQUE LMT				
587	External Torque Limit on CW Side	100	%	0 ~ 800	
	P404 CW EXT T-LMT				
588	External Torque Limit on CCW Side	100	%	0 ~ 800	
	P405 CCW EXT T-LMT				
589	Emergency Stop Torque	800	%	0 ~ 800	
	P406 EM SP TORQUE				
590	Speed Limit in Torque Control	10000	min ⁻¹	0 ~ 10000	
	P407 TORQUE-CL S-LMT				
591	Torque Function Switch	0000	hex		
	P408 TORQUE FUNC SW				
592	1 st Stage Notch Filter Frequency	2000	Hz	50 ~ 2000	
	P409 1TH NOTCH FLT				
593	1 st Stage Notch Filter Q-value	70	0.01	50 ~ 1000	
	P40A 1TH NOTCH FLT Q				
594	2 nd Stage Notch Filter Frequency	2000	Hz	50 ~ 2000	
	P40C 2TH NOTCH FLT				
595	2 nd Notch Filter Q-value	70	0.01	50 ~ 1000	
	P40D 2TH NOTCH FLT Q				
596	2 nd Stage Secondary Torque Command Filter Frequency	2000	Hz	50 ~ 2000	
	P40F 2TH TQ FLT				
597	2 nd Stage Secondary Torque Command Filter Q-value	70	0.01	70 ~ 1000	
	P410 2TH TQ FLT Q				
598	3 rd Torque Command Filter Time Constant	2000	Hz	50 ~ 2000	
	P411 3TH TQ FLT				
599	1 st Stage Secondary Torque Command Filter Time Constant	100	0.01msec	0 ~ 65535	
	P412 1TH 2-TQ FLT				
600	1 st Stage Tertiary Torque Command Filter Time Constant	100	0.01msec	0 ~ 65535	
	P413 1TH 3-TQ FLT				

No.	Name	STD Set-value	Set Unit	Set Range	Remarks
	Displayed Message				
601	1 st Stage Quartic Torque Command Filter Time Constant	100	0.01msec	0 ~ 65535	
	P414 1TH 4-TQ FLT				
602	Vibration Suppression Damping Ratio in Stop	100	%	10 ~ 100	
	P420 V-CTL RATIO				
603	Vibration Suppression Start Ratio in Stop	1000	msec	0 ~ 65535	
	P421 V-CTL START				
604	Gravity Compensation Torque	0	0.01%	-20000 ~ 20000	
	P422 GRAVITY COMP TQ				
605	Sweep Torque Command Amplitude	15	%	1 ~ 800	
	P456 TQ AMPLITUDE				
606	Zero Clamp Level	10	min ⁻¹	0 ~ 10000	
	P501 ZERO CLAMP LV				
607	Revolution Detecting Level	20	min ⁻¹	1 ~ 10000	
	P502 ZERO SPEED LV				
608	Speed Correspondence Signal Detecting Width	10	min ⁻¹	0 ~ 100	
	P503 SPEED CMP WIDTH				
609	Brake Command, Servo OFF Delay Time	0	10msec	0 ~ 50	
	P506 BK SV-OFF DELAY				
610	Brake Command Output Speed Level	100	min ⁻¹	0 ~ 10000	
	P507 BK REF SPEED LV				
611	Servo OFF Brake Command Waiting Time	50	10msec	10 ~ 100	
	P508 SV-OFF BK DWL				
612	Momentary Hold Time	20	msec	20 ~ 1000	
	P509 BLACKOUT HOLD				
613	Input Signal Selection 1	2100	hex		
	P50A INPUT ALT1				
614	Input Signal Selection 2	6543	hex		
	P50B INPUT ALT2				
615	Input Signal Selection 3	8888	hex		
	P50C INPUT ALT3				
616	Input Signal Selection 4	8888	hex		
	P50D INPUT ALT4				
617	Output Signal Selection 1	3211	hex		
	P50E OUTPUT ALT1				
618	Output Signal Selection 2	0	hex		
	P50F OUTPUT ALT2				
619	Output Signal Selection 3	0	hex		
	P510 OUTPUT ALT3				
620	Output Signal Reverse Setting	0	hex		
	P512 OUTPUT REVERSE				
621	Input Signal Selection 5	6543	hex		
	P515 INPUT ALT5				
622	Warning Level of Excessive Position Deviation	100	%	10 ~ 100	
	P51E POS DEV WARNING				
623	Alarm Level of Excessive Position Deviation	40000	COM UNIT	1 ~ 107341823(2 ³⁰ -1)	
	P520 POS DEV ALARM				
625	Near Signal Width	40000	COM UNIT	1 ~ 107341824(2 ³⁰)	
	P524 NEAR SIG WIDTH				
626	Alarm Level of Excessive POS-DEV in Servo ON	40000	COM UNIT	1 ~ 107341823(2 ³⁰ -1)	
	P526 SVON P-D ALARM				

No.	Name	STD Set-value	Set Unit	Set Range	Remarks
	Displayed Message				
627	Warning Level of Excessive POS-DEV in Servo ON	100	%	10 ~ 100	
	P528 SVON P-D WARNING				
628	Feed Limit Level in Servo ON	10000	min ⁻¹	0 ~ 10000	
	P528 SVON FEED LEVEL				
629	Monitor Display in Power ON	FFF			
	P52F MONITOR DISPLAY				
630	Gain Limit	2000	0.1Hz	10 ~ 20000	
	P540 GEIN LIMIT				
631	Analog Monitor 1 Offset Voltage	0	0.1V	-10000 ~ 10000	
	P550 ANALOG MONITOR1				
632	Analog Monitor 2 Offset Voltage	0	0.1V	-10000 ~ 10000	
	P551 ANALOG MONITOR2				
633	Regeneration Resistance Capacity	0	10W		
	P600 REG RES CAPA				

Note1 This item may change in a setting value with attachment rotary tables. Although the setting value is indicated for every model below, detailed data should also combine the attached sheet parameter change list of rotary table equipments, and please confirm it. (mark in a table shows an "initial value".)

Moreover, A axis of an initial-setting value is rotary table form. It is a MRM160R type parameter value, and B axis is set as the parameter value of a TTM181 tilting axis.

Initial value			PRM 003	PRM 004	PRM 008	PRM 011	PRM 013	PRM 038	PRM 044	PRM 513	
			A axis	41.66	41.66	41.66	72	0	1	0	350
			B axis	16.66	16.66	16.66	180	0	1	0	350
MRM	120	R	50.00	50.00	50.00	60	※	※	※	※	
		L					1				
	200	R	33.33	33.33	33.33	90	※	※	※	※	
		L					1				
	250	R	33.33	33.33	33.33	90	※	※	※	250	
		L					1				
TMX	160		※	※	※	※	1	※	※	※	
	200		33.33	33.33	33.33	90					
	250		25.00	25.00	25.00	120					
TBM	160/200		33.33	33.33	33.33	90	1	※	※	※	
	250		25.00	25.00	25.00	120					
	320		16.66	16.66	16.66	180					
TUM	200		33.33	33.33	33.33	90	※	※	※	※	
	251		25.00	25.00	25.00	120					
	320		16.66	16.66	16.66	180					
TMM	2100		83.33	83.33	83.33	36	1	0	※	※	
	3100		50.00	50.00	50.00	60		※			
	2160		33.33	33.33	33.33	90					
	3160		25.00	25.00	25.00	120					
RSM	100	R	83.33	83.33	83.33	36	※	0	1	※	
		L					1				
	160 200	R	33.33	33.33	33.33	90	※	※	※	※	
		L					1				
TTM	101	A axis	※	※	※	※	※	※	※	※	※
		B axis	25.00	25.00	25.00	120	※	※	※	※	
	120 181	A axis	33.33	33.33	33.33	90	※	※	※	※	※
		B axis	※	※	※	※	※	※	※	※	
	251	A axis	25.00	25.00	25.00	120	※	※	※	※	※
		B axis	8.33	8.33	8.33	240	※	※	※	※	

1.3 Detailed parameters


The set value in 【 】 on description for each parameter explanation shows the standard set value.

PRM000 [NAME] ROM Version
[MESSAGE] ROM VER

Description The system program version of controller is inputted.

PRM002 [NAME] MZRN DECEL. speed
[MESSAGE] MZRN LOW FEED
【DATA UNIT】 : min^{-1} 【DATA RANGE】 : 0.00 ~ 1.00

Description Sets the feedrate for detecting MZRN dog.



Concerned parameters PRM008 , PRM255

PRM003 [NAME] Rapid Traverse (Max. rotation speed)
[MESSAGE] RAPID TRAVERSE
【DATA UNIT】 : min^{-1} 【DATA RANGE】 : 0.00 ~ 99.99

Description Sets the max. rotation speed of circular table.

In the following case, the table rotates at max. rotation speed.

- When F0 is specified to the program feedrate or max. rotation speed is specified.
- When MAX value is specified at OVERRIDE.
- When WZRN is performed.
- When MZRN is performed after MZERO POS is established (PRM123=1).

PRM004[N A M E] JOG HI Speed

[M E S S A G E] HI JOG FEED

【DATA UNIT】 : min⁻¹ 【DATA RANGE】 : 0.00 ~ 99.99

Description Sets the feedrate when the rapid traverse (**INS** + **HIJOG**, or **DEL** + **HIJOG**) is manually commanded.

Precautions

1. Even if the feed is set over PRM003, it is clamped at the upper limit value of PRM003.

PRM005[N A M E] JOG LO Speed

[M E S S A G E] LO JOG FEED

【DATA UNIT】 : min⁻¹ 【DATA RANGE】 : 0.00 ~ 99.99

Description Sets the feedrate when LO JOG FEED (**INS**, or **DEL**) is manually commanded. The LO JOG FEED is actuated when its key is continuously pushed for 1 second or more.

Precautions

1. Even if the feed is set over PRM003, it is clamped at the upper limit value of PRM003.
2. When the feed direction key is pushed for 1 second or less, the table is fed at the step feed.

PRM006[N A M E] Step Feed Amount

[M E S S A G E] STEP FEED AMOUNT

【DATA UNIT】 : deg 【DATA RANGE】 : 0.000 ~ 10.000

Description Sets the step feed amount of manual operation. When **INS** or **DEL** is pushed for 1 second or less, the table is fed at step feed. The step feedrate is PRM004 (JOG HI FEED) .

Precautions


1. Even if the feed is set over PRM003, it is clamped at the upper limit value of PRM003.
2. When the feed direction key is pushed for 1 second or more, the table is fed at the LO JOG feed.

PRM007[N A M E] MZRN Shift Amount

[M E S S A G E] MZRN SHIFT AMOUNT

【DATA UNIT】 : deg 【DATA RANGE】 : -360.000 ~ 360.000


Description MZRN POS. can be optionally shifted in DATA RANGE. MZRN SHIFT is positioned at the feed of PRM003 as a serial operation.



PRM008

[NAME] MZRN Feed
 [MESSAGE] MZRN FEED
 【DATA UNIT】 : min^{-1} 【DATA RANGE】 : 0.00 ~ 99.99

Description Sets the MZRN FEED when PRM123=2 is set (DEC DOG MZRN).



☞ Concerned parameters PRM002 , PRM007

PRM009

[NAME] Position Deviation Check Setting Time
 [MESSAGE] POS-DEV CHECK TIMER
 【DATA UNIT】 : sec 【DATA RANGE】 : 0.00 ~ 1.00

Explained together at the following item of PRM010.


PRM010

[NAME] Position Deviation Check Setting Amount
 [MESSAGE] POS-DEV CHECK AMOUNT
 【DATA UNIT】 : deg 【DATA RANGE】 : 0.000 ~ 16.000

Description The POS-DEV CHECK is started when the circular table is stopped in the imposition area.

The POS-DEV CHECK mode is the function to check that there is no error to the value set to PRM010 for the commanded value by checking the stop coordinate after positioning (PRM009 time elapsing).

PRM009 set time is used together with the time to table clamp from table entering time in the imposition.

**PRM011**

[NAME] Gear Ratio 1/X
 [MESSAGE] GEAR RATIO 1/X
 【DATA RANGE】 : 0 , 36 , 45 ~ 999

Description Sets the gear ratio between the circular table and the motor.

☞ Concerned parameters PRM564 , PRM565 (AUTO SET)

PRM013 [NAME] Motor Rev. direction Flag
 [MESSAGE] MOTOR DIRECTION
 【DATA RANGE】 : 0, 1

Description Changes the rev. direction of motor (table).


【 0 】 : CW (Clockwise when viewed from motor shaft)
 1 : CCW (Counterclockwise when viewed motor shaft)

PRM014 [NAME] Override Step Amount
 [MESSAGE] OVERRIDE STEP AMOUNT
 【DATA UNIT】 : % 【DATA RANGE】 : 0 ~ 100

Description When pushing **OVR** + **DEL** or **OVR** + **INS** simultaneously, the value of override can be increased or decreased. At this time, one increase or decrease amount is set.

PRM015 [NAME] Deviation Check Amount in Clamp
 [MESSAGE] POS-DEV CHECK CLAMP
 【DATA UNIT】 : deg 【DATA RANGE】 : 0.000 ~ 16.000

Description The system checks the position deviation in table clamp and it allows 『Err.019 POS-DEV OVER CL 』 to issue when the table is shifted over the set value by an external force. The parameter is set at \pm value on the basis of a stop command position.




PRM016

[NAME] MZRN Direction
 [MESSAGE] MZRN DIRECTION
 【DATA RANGE】 : 0 , 1

Description Sets the MZRN direction of table.

- 【 0 】 : + Direction (Clockwise when viewed from table top.)
 1 : - Direction (Counterclockwise when viewed from table top.)

MZRN Direction



As shown in left figure, the table rotates in the rev. direction set to PRM016 even if MZRN start position is in any position.

Precautions

1. PRM016 is set as “Plus” when the table rotates in CW direction.
2. Unless PRM017=1 (SHORT CUT MZRN) is set, MZRN is performed as set for this parameter.

Concerned parameter PRM017

PRM017

[NAME] MZRN • WZRN in Short Cut Direction
 [MESSAGE] ZRN SHORT CUT DIR
 【DATA RANGE】 : 0 , 1 , 2

Description Sets whether MZRN or WZRN of table is performed or not in short cut direction, or the table returns to the zero position in the short cut direction by regarding the angle optionally set as boundary.

【 0 】 : The table returns to MZRN position in the direction set to PRM016 when returning from any position. It returns to WZRN position in the plus direction certainly.
 (A-axis standard)

See Rev. direction of PRM016.

【 1 】 : The table returns to ZRN position in the short cut direction of CW at 180 ° or more and of CCW at below 180 ° by regarding the position of 180.000 ° as the boundary.
 (B-axis standard)

2 : Optionally sets the boundary angle to be returned to ZRN position in the short cut direction.

MZRN direction in case of PRM017=1

Start pos.	MCRDT SYS 179.999 ° or less	MCRDT SYS 180.000 ° or more
RTRY DIR		

MZRN direction in case of PRM017=2

Set V	PRM018=45.000	
Start pos.	MCRDT SYS 45.000 ° or more	MCRDT SYS 45.000 ° or more
RTY DIR		

WZRN direction (PRM016 set value is no concerned.)

Set V	PRM017=0	PRM017=1		PRM017=2 , PRM018=90.000	
Start pos.	Regardless of position	WCRDT SYS 179.999 ° or less	WCRDT SYS 180.000 ° or more	WCRDT SYS 89.999 ° or less	WCRDT SYS 90.000 ° or more
RTY DIR					

Precautions

1. In case of PRM17=1, 2, MZRN direction of PRM016 becomes invalid.
For this reason, since a positioning error occurs by ZRN direction, it is recommended to use an unidirectional positioning mode.



Concerned parameters PRM016 , PRM018

PRM018[NAME] Optional Angle Assignment in Short Cut Return Direction

[MESSAGE] ZRN DIR OPT POS

【DATA UNIT】 : deg

【DATA RANGE】 : 0.000 ~ 359.999

Description Determines the ZRN rev. direction by regarding an optional angle as boundary. In case of PRM018 > Current stop position, ZRN direction is CCW.

In case of PRM018 ≤ Current stop position, ZRN direction is CW.

However, in this rev. direction, CW rotation is regarded as plus direction.



See the MZRN and WZRN rev. directions of PRM017.

Precautions

1. When PRM017=2 is not set, even if the angle is set, it is invalid.
2. The optional angle is reflected on the machine coordinate system in MZRN and on the work coordinate system in WZRN.



Concerned parameter PRM017

PRM020[NAME] BLKFIN Output Flag in G08, G09

[MESSAGE] BLKFIN FLAG (G08)

【DATA RANGE】 : 0 , 1


Description Sets that BLKFIN is outputted at any timing in G80, G09.

【 0 】 : Outputs BLKFIN when G08 BLK EXE is started.

(BLKFIN does not output when G09 BLK EXE is finished.)

1 : Outputs FLKFIN when G09 BLK EXE is finished.

(BLKFIN does not output when G08 BLK EXE is started.)



The FLKFIN OUTPUT time in PRM020=1 becomes PRM035 setting time when the start signal is turned OFF within PRM035 time. When the start signal is not turned OFF even if PRM035 time elapses, the BLKFIN is outputted continuously until the start signal is turned OFF. (Part enclosed by dot line)

PRM021[NAME] BLKFIN Output Flag in G07


[MESSAGE] BLKFIN FLAG (G07)

【DATA RANGE】 : 0 , 1

Description Sets that the BLKFIN OUTPUT mode of exclusive G07 (in lead cutting) in addition to an usual BLKFIN OUTPUT is outputted at any timing.

【 0 】 : Outputs BLKFIN when G07 BLK EXE is finished.

1 : Outputs BLKFIN when G07 BLK EXE is started.



The FLKFIN OUTPUT time in PRM021=1 becomes PRM035 setting time when the start signal is turned OFF within PRM035 time. When the start signal is not turned OFF even if PRM035 time elapses, the BLKFIN is outputted continuously until the start signal is turned OFF. (Part enclosed by dot line)

PRM022[NAME] Object Signal of BLKFIN OUTPUT




[MESSAGE] BLKFIN TRIGGER

【DATA RANGE】 : 0 , 1

Description Sets that the BLKFIN except G07、 G08 , G09 is outputted by any check.

【 0 】 : Clamp check signal monitoring (Valid only in PRM032=0)

1 : Position deviation monitoring

PRM022=0 (PRM038=1)PRM022=0 (PRM038=0)PRM022=1

In PRM022=1, since BLKFIN signal is outputted by a position deviation amount, the BLKFIN signal can be outputted sooner than the type of PRM022=0.

However, there is any time without clamping after BLKFIN SIG OUTPUT (See left figure).

Precautions

1. In PRM022=0 (Clamp Check Signal Monitoring) setting, the check signal differs by the value set to PRM038. When PRM038=0, the table clamp is monitored by the clamp check signal and PRM038=1, monitored by the unclamp check signal.
In case of PRM032=1 (Clamp unused) , POS-DEV amount is monitored forcedly.



Concerned parameter PRM038


PRM023[NAME] Alarm Scan Cycle of Unclamp Signal

[MESSAGE] ALARM SCAN UNCLUMP

【DATA UNIT】 : sec

【DATA RANGE】 : 0.00 ~ 10.00

Description The unclamp signal is monitored usually to set the detecting times for incorrect signals such as unclamp signal OFF during operation, unclamp signal ON during table clamp, etc. When the unclamp check signal fails over this set time, the alarm of 『 ERR016 BRAKE FAILURE 』 occurs.

**Precautions**

1. When PRM032=1(Clamp unused) or PRM038=1, this mode becomes invalid.
2. In case of PRM023=0, the table is monitored by the unclamp check signal for only when operation START/STOP.



Concerned parameters PRM032 , PRM038


PRM024[NAME] Alarm Scan Cycle of Clamp Signal

[MESSAGE] ALARM SCAN CLAMP

【DATA UNIT】 : sec

【DATA RANGE】 : 0.00 ~ 10.00

Description The clamp signal is monitored usually to set the detecting times for incorrect signals such as clamp signal ON during operation, clamp signal OFF during table clamp, etc. When the clamp check signal fails over this set time, the alarm of 『 ERR016 BRAKE FAILURE 』 occurs.

**Precautions**

1. When PRM032=1 (Clamp unused) or PRM038=0, this mode becomes invalid.
2. In case of PRM024=0, the table is monitored by the unclamp check signal for only when operation START/STOP.



Concerned parameter PRM038

PRM025

[NAME] 360FIN Output Spec.
 [MESSAGE] 360FIN OUTPUT SPEC
 【DATA RANGE】 : 0 , 1

Description Selects the output format of 360FIN signal.

【 0 】 : One Shot OUTPUT


Outputs 360FIN signal by a time set to PRM036 when the table stops at WZERO position or passes through its position.

1 : Continuous OUTPUT

This mode monitors a current position usually, outputs 360FIN signal when the table is in set range (PRM026) and turns OFF the OUTPUT when the table is not in the set range.

For detailed CONT. OUTPUT, see PRM026.

PRM025=0 In passing through WZERO POS. PRM025=0 In stopping at WZERO POS.

**Precautions**

- To make this parameter valid, turn OFF power once.



Concerned parameters PRM026 , PRM034


PRM026

[NAME] 360 ° FIN Output Area
 [MESSAGE] 360FIN OUTPUT AREA
 【DATA UNIT】 : deg 【DATA RANGE】 : 0.000 ~ 1.000 (PRM025=1)


Description Sets the OUTPUT AREA to output 360FIN continuously in PRM025=1.

The PRM026 is set at \pm range on the basis of WZERO position.

PRM025=1



Timing chart in operation as shown in left figure.



PRM027

[NAME] G99FIN Output Spec.



[MESSAGE] G99FIN OPR SPEC

【DATA RANGE】 : 0 , 1 , 2

Description Sets that G99FIN is outputted at any timing when G98 and G99 commands are executed with the program.

This G99FIN can also be outputted continuously during solenoid excitation.

- 【 0 】 : Outputs G99FIN when BLK EXE is finished.
 1 : Outputs G99FIN when BLK EXE is started (for 99FIN check.).
 2 : Outputs G99FIN during solenoid excitation.

PRM027=0PRM027=2**Precautions**

1. For G21L99 command, this parameter is invalid. When G21L99 is commanded, G99FIN is outputted when it is started.
2. PRM027=1 is set for only MAC mini iH series.



Concerned parameters PRM028 , PRM029

PRM028[NAME] G99FIN Check Timer

[MESSAGE] G99FIN CHECK TIMER


【DATA UNIT】 : sec

【DATA RANGE】 : 0.00 ~ 9.99


Description Sets a time checked to ZRN signal input that is the check signal when handshake (Checked by signal delivery) is executed with the external equipment.

When G98, G99 and G21L99 command blocks are executed, G99FIN is outputted and its G99FIN OUTPUT is turned OFF when the INPUT of ZRN signal (PRM029= "2") is checked. When the ZRN signal that is the G99 check signal is not inputted within this set time, 『Err.217 G99FIN TIME-OUT』 occurs.

PRM027=1, PRM028 0, PRM029=2



PRM027=1, PRM028 0, PRM029=2 In case of table rotation.

**Precautions**

1. For G21L99 command, this parameter is invalid. When G21L99 is commanded, G99FIN is outputted when it is started.
2. When PRM028=0 or PRM029 2 is established when PRM027=1 is set, 『Err.217 G99FIN TIME-OUT』 occurs.



Concerned parameters PRM027, PRM029

PRM029[NAME] External ZRN Input Spec.

[MESSAGE] EXT ZRN SPEC

【DATA RANGE】 : 0, 1, 2

Description Selects the specification of ZRN INPUT SIGNAL.

【0】 : External MZRN

Performs MZRN by inputting ZRN in MANUAL mode.

- 1 : External WZRN
Performs WZRN by inputting ZRN in MANUAL mode.
- 2 : G99 CHECK SIGNAL (Only PRM027=1: VALID)
This parameter is used for receiving the CHECK SIGNAL to G99FIN OUTPUT of PRM02.
When inputting ZRN for PRM028 time, G99FIN OUTPUT is OFF.
For details of this item, see PRM028.

Precautions

1. Since this function requires ZRN INPUT, only MAC mini iH series functions effectively.



Concerned parameters PRM027 , PRM028

PRM030

[NAME] SP Signal Function Spec.
[MESSAGE] SP/EXT SP FUNC SPEC
【DATA RANGE】 : 0 , 1

Description Selects the function when **STOP** key of panel or pendant and an external SP signal are received during operation (AUTO、 SINGLE) .

【 0 】 : For SP INPUT, the table stops temporarily.
In STATUS, “ RUN ” + “ STOP ” light.

1 : For SP INPUT, STOP + Program RESET are performed.
In STATUS, “ RESET ” lights.

PRM031

[NAME] External MZRN Function
[MESSAGE] MZRN BY THE EXT ST
【DATA RANGE】 : 0 , 1 , 2 , 3

Description Sets whether MZRN is performed or not by the external start signal.

【 0 】 : MZRN External Start INVALID

Just after power ON (STATUS: NOT READY), MZRN can be performed by **MZERO** key operation on the panel or pendant, or an external ZRN mode.

1 : MZRN External Start available Type 1

The first External Start input signal, just after power turns on, implements MZRN. And then after Machine return to the origin, it automatically switches to AUTO mode. Additionally, in this type of MZRN, MANUAL mode still outputs the signals of both BLKFIN and ZRNFIN.

In case of 4th and 5th axes, both axes return to the origin at once.

2 : MZRN External Start available Type 2

The first External Start input signal, just after power turns on, implements MZRN. And then after Machine return to the origin, it automatically switches to AUTO mode. Additionally, in this type of MZRN, MANUAL mode still outputs the signals of both BLKFIN and ZRNFIN.

In case of 4th and 5th axes, the 4th axis returns to the origin first and then the 5th axis returns to the origin afterward.

3 : MZRN External Start available Type 3

The first External Start input signal, just after power turns on, implements MZRN. And then after Machine return to the origin, it automatically switches to AUTO mode. Additionally, in this type of MZRN, MANUAL mode still outputs the signals of both BLKFIN and ZRNFIN.

In case of 4th and 5th axes, the 5th axis returns to the origin first and then the 4th axis returns to the origin afterward.

Precautions

1. When other measures, such as by Panel and External origin return, completes MZRN, this function becomes invalid.



Concerned parameter PRM029

PRM032

[NAME] Clamp Spec.
 [MESSAGE] CLAMP SPEC
 【DATA RANGE】 : 0 , 1

Description Selects whether the clamp mechanism of table is used or not.

【 0 】 : Clamp mechanism used

1 : Clamp mechanism unused

When the clamp mechanism is unused, the table becomes an unclamped state usually.

PRM033

[NAME] External Channel Spec.
 [MESSAGE] EXT CH SPEC
 【DATA RANGE】 : 0 , 1

Description Selects the method to select the program channel No. from external channels.

【 0 】 : Rotary SW mode

1 : M-signal mode



Concerned parameters PRM112



See the item of 『 EXT CH SPEC 』.

PRM034


[N A M E] 360FIN Output Contact Flag
 [M E S S A G E] 360FIN CONTACT FLAG
 【DATA RANGE】 : 0 , 1

Description Selects the contact spec., of 360FIN OUTPUT SIGNAL.


0 : B-contact

【 1 】 : A-contact

PRM034=0(B-contact spec.) In passing WZERO




PRM034=1(A-contact spec.) In passing WZERO

**PRM035**


[N A M E] BLKFIN Timer
 [M E S S A G E] BLKFIN TIMER
 【DATA UNIT】 : sec 【DATA RANGE】 : 0.00 ~ 1.00

Description Sets the output time of BLKFIN OUTPUT signal outputted in BLKFIN by the program operation under AUTO mode.


Start signal one shot type: PRM035 0



Start signal type turned OFF by BLKFIN: PRM035 0



Start signal type turned OFF by BLKFIN: PRM035 = 0



Precautions

1. In the BLKFIN OUTPUT, though a output time is the time set to PRM035 when the start signal is OFF in PRM035 time, when its signal is not OFF even if the time of PRM035 elapses, the BLKFIN is outputted continuously until the start signal is OFF.
2. When the parameter is used at PRM035 = 0, consider at the external equipment so that a next start signal will not be inputted during PRM035 output.
If the start signal is inputted during BLKFIN output, its BLKFIN may be regarded as FIN SIGNAL, there is a possibility that an incorrect operation is caused.
3. When the start signal is inputted at one shot and PRM035=0 is set, the BLKFIN OUTPUT is ON/OFF immediately. For this reason, since the BLKFIN OUTPUT may not be read at the remote machine, set a proper output time.

PRM036[NAME] 360FIN Timer

[MESSAGE] 360FIN TIMER

【DATA UNIT】 : sec

【DATA RANGE】 : 0.00 ~ 1.00

Description Sets the output time of 360FIN OUTPUT signal when the table stops at MZERO position or passes through its position.

For timer operation, see the figure for PRM025=0.

Precautions

1. In case of PRM025=1, 2, the timer of this parameter becomes invalid.



Concerned parameters PRM025

PRM037[NAME] Timer from Unclamp to Shift Start

[MESSAGE] ST TIMER FROM UCL

【DATA UNIT】 : sec

【DATA RANGE】 : 0.00 ~ 1.00

Description Sets the time from an unclamp motion to motor start.

Its time is used for adjusting the operation timing of the mounted machine and the table.

Precautions

1. When the brake is effective, the system is operated in order of Brake Unclamp, Servo ON, Check of Servo ON OK/NG. It takes the time of about 100msec to finish the check of item . Consequently, even if PRM037 > PRM035 is set, it is nonsense.

PRM038[NAME] Clamp Signal Flag

[MESSAGE] CLAMP SIGNAL FLAG

【DATA RANGE】 : 0 , 1

Description Selects whether the clamp check signal to check the clamp motion is used or not.

Even if the clamp check signal is not used, an unclamp check signal is usually checked.

0 : Unused

【 1 】 : Used

PRM039


[N A M E] Clamp Output Contact Flag
 [M E S S A G E] BRAKE CONTACT FLAG
 【DATA RANGE】 : 0 , 1

Description Selects the clamp motion spec., by solenoid output.

0 : Excitation CLAMP

【 1 】 : Excitation UNCLAMP

PRM039=0 (Excitation CLAMP)



PRM039=1 (Excitation UNCLAMP)

**PRM040**

[N A M E] Rev. Direction in Continuous Start (G22)
 [M E S S A G E] REV DIR (G22)
 【DATA RANGE】 : 0 , 1

Description Sets the rev. direction when G22 (CONT. START) of program operation is commanded.

【 0 】 : CW (Clockwise)

1 : CCW (Counterclockwise)

Precautions

1. When “ 0 ” or “ 0 ” is set into Address A in program G22 commanded, the program command takes precedence and this setting becomes invalid.

PRM041

[N A M E] Rev. Feed in Continuous Start (G22)
 [M E S S A G E] REV FEED (G22)
 【DATA UNIT】 : min^{-1} 【DATA RANGE】 : 0.00 ~ 99.99

Description Sets the feedrate when the feedrate is not set into the program in G22 commanded (CONT. START).

Precautions

1. When Address F is set in program G22 commanded, the program command takes precedence and this setting becomes invalid.

PRM042

[N A M E] BLK/G99 FIN Output Start Delay Flag (G21)
 [M E S S A G E] BLK/G99 DELAY (G21)
 【DATA RANGE】 : 0 , 1

Description Sets whether the BLKFIN or G99FIN outputted when the program operation of G21 is started is delayed or not.





【 0 】 : Invalid

1 : Valid

PRM043

[NAME] BLK/G99 FIN Output Start Delay Timer (G21)
 [MESSAGE] BLK/G99 DELAY TIMER
 【DATA UNIT】 : sec 【DATA RANGE】 : 0.00 ~ 1.00

Description Sets the delay time of output set to PRM042.

PRM042=0 BLKFIN OUTPUTPRM042=1, PRM043 0 BLKFIN OUTPUTPRM042=0 G99KFIN OUTPUTPRM042=1, PRM043 0 G99FIN OUTPUT**PRM044**

[NAME] Servo Control Flag
 [MESSAGE] SERVO CONTROL FLAG
 【DATA RANGE】 : 0, 1

Description Sets whether motor power is excited or not during clamp.

- 【 0 】 : Motor OFF in clamp
 1 : Motor ON usually regardless of clamp

In this motor control, sequence differs by set value of PRM032.

	PRM032=0	PRM032=1
In Start	Motor ON in clamp.	Motor ON in clamp, after that, clamp OFF.
In Stop	Clamp ON in motor ON, and also, motor ON during stop.	Motor ON as is.
In Alarm Occurring	Motor OFF in alarm occurring, after resetting alarm, motor ON in clamp ON as is.	Motor OFF in alarm occurring, after resetting alarm, motor ON in clamp OFF as is.
In Motion Start	Motion start after setting PRM037 in clamp OFF.	

Precautions

1. Position deviation in clamp is held as POS-DEV AMOUNT.
2. In motor ON usually, when POS-DEV AMOUNT is not "0" and the table is clamped, the system attempts to return the POS-DEV to "0". As a result, current flows continuously to the motor, thus heating the motor.

PRM046

[N A M E] Panel ST Key Input Flag in AUTO Mode
 [M E S S A G E] ST KEY IN AUTO
 【DATA RANGE】 : 0 , 1

Description Selects the VALID/INVALID of **ST** key input on the panel or pendant under AUTO mode.

【 0 】 : Valid (In the start INPUT, **ST** key input on the panel or pendant and ST of external INPUT are valid.)

1 : Invalid (In the start INPUT in AUTO mode, only ST of external INPUT is valid.)

PRM047

[N A M E] WZERO Position Setting every Channel
 [M E S S A G E] SETUP WZERO POS
 【DATA RANGE】 : 0 , 1

Description Sets the specification of WZERO position when the manual WZERO position is set or G92 is executed.

【 0 】 : Common WZERO position for all channels

1 : Can set WZERO position every channel.

The following shows each operation content on PRM47.

		PRM047=0	PRM047=1
Setting of manual WZERO position ORG + INPUT		Coordinate position stopped currently is updated to WZERO position. However, parameter does not change.	Current coordinate position is updated to WZERO position and parameter for channel during selection is also updated.
Program G92 command		WZERO position of OPT POS by Address A of G92 is updated. However, parameter does not change.	WZERO position is updated parameter for channel for selection is updated.
Change of CH		No change	Parameter for WZERO is read.
Change of PRM047	0 1	No change	
	1 0		
			No change

Precautions

- When changing PRM047 to “ 1 ” “ 0 ”, the WZERO position of channel during selection in change becomes a common WZERO position.



Concerned parameters PRM300 ~ PRM389 (WZERO setting position every channel)

PRM100 [N A M E] Software Limit Specification
 [M E S S A G E] S/W LIMIT SPEC
 【DATA RANGE】 : 0 , 1 , 2

Description Selects the specification of software to limit a machine operation range by the software.

【 0 】 : Invalid

1 : Check during operation

When the position coordinate during operation reaches a software limit MIN (PRM101) and software limit MAX (PRM103) on the machine coordinate system, an alarm occurs.

2 : Check before operation

The shifting destination coordinate is checked before operation in the program operation. When the coordinate reaches a software limit MIN (PRM101) and software limit MAX (PRM103) on the machine coordinate system, an alarm occurs.

During manual feed, this mode is the same as check during operation (PRM100=1).



Concerned parameters PRM101 , PRM103

PRM101 [N A M E] Software Limit MIN
 [M E S S A G E] S/W LIMIT OF MIN
 【DATA UNIT】 : deg 【DATA RANGE】 : 0.000 ~ 359.999

Description Sets the machine coordinate position to limit a minus side when the software limit is valid (PRM100=1 or 2).



Concerned parameters PRM100 , PRM103





PRM103 [N A M E] Software Limit MAX
 [M E S S A G E] S/W LIMIT OF MAX
 【DATA UNIT】 : deg 【DATA RANGE】 : 0.000 ~ 359.999

Description Sets the machine coordinate position to limit a plus side when the software limit is valid (PRM100=1 or 2).



Concerned parameters PRM100 , PRM101

About software limit

Description PRM101=0.000 , PRM103=180.000PRM101=180.000 , PRM103=0.000PRM101=270.000 , PRM103=90.000PRM101=90.000 , PRM103=270.000**Precautions**

1. The software limit mode becomes valid for only after MZRN is finished.
2. When operating in the plus direction or checking before operation, 『 Err.213 SOFTWARE LIMIT + (SOFTWARE LIMIT + Side) 』 occurs.
3. When operating in the plus direction or checking before operation, 『 Err.214 SOFTWARE LIMIT - (SOFTWARE LIMIT - Side) 』 occurs.
4. Though the above parameters PRM101=90.000 , PRM103=270.000 can be set, the alarm occurs even if operated in any direction after MZRN is finished.

PRM105 [NAME] Unidirectional Positioning Spec.
 [MESSAGE] UNIDIRECTIONAL SPEC
 【DATA RANGE】 : 0, 1, 2


Description Sets that the table in program operation is positioned from any direction.

【 0 】 : Invalid
 (A-axis standard)


【 1 】 : + Direction positioning
 (B-axis standard) The table is usually positioned from the plus direction. When positioning from the minus direction, the table passes through a commanded position (Passing angle: PRM105) once, it reverses in the plus direction and approaches the commanded position.

2 : - Direction positioning
 The table is usually positioned from the minus direction. When positioning from the plus direction, the table passes through a commanded position (Passing angle: PRM105) once, it reverses in the minus direction and approaches the commanded position.

PRM105=1



PRM105=2



Concerned parameter PRM106

PRM106 [NAME] Unidirectional Positioning Approach Amount
 [MESSAGE] UNIDIRECTIONAL ANGLE
 【DATA UNIT】 : deg 【DATA RANGE】 : 0.000 ~ 359.999

Description Sets the over travel (Approach) amount when returning after passing through a target value once with the unidirectional positioning VALID (PRM105=1 or 2).

Concerned parameter PRM105

PRM110 [NAME] Parameter INPUT Permission Flag
 [MESSAGE] PRM INPUT PERMISSION
 【DATA RANGE】 : 0, 1, 999

Description Sets the WRITE PERMISSION SPEC. when the parameter is set.

- 【 0 】 : Impossible parameter setting
 1 : Parameter setting of PRM001 ~ PRM499 is permitted.
 Parameters relative to servo after PRM500 cannot be set.
 999 : Permits all parameter settings.

Precautions

1. Do not change the servo parameter usually.

PRM112 [N A M E] Channel Select Flag
 [M E S S A G E] CH SELECT FLAG
 【DATA RANGE】 : 0 , 1

Description Sets the method to select the channel.

【 0 】 : Selects the channel by the panel keys of controller.

1 : Selects the channel by the external INPUT signal.

The channel select INPUT signals (CHSEL0 , 1 , 2 , 3 , CHSET) of a general purpose INPUT select each channel.

Precautions

1. When the channel selection is set by the external INPUT signal, it is necessary to select the mode of PRM033 together.



Concerned parameter PRM033



For detailed contents, see the 『 External Channel Selection 』 .

PRM117 [N A M E] Axis Type
 [M E S S A G E] AXIS TYPE
 【DATA RANGE】 : 0 , 1

Description The specification of a controller is set up.

【 0 】 : In 1-axis spec. : MAC mini iH / iHF(Initial-setting value)

1 : In 2-axis spec. : MAC mini iH2 / iHT(Initial-setting value)



Concerned parameters PRM240 , PRM242 , PRM243 , PRM244

PRM121 [N A M E] Over Travel Detecting Type
 [M E S S A G E] OT ADMIN TYPE
 【DATA RANGE】 : 0 , 1

Description Selects the specification of over travel detecting signal.

【 0 】 : Parallel detecting method

OT is detected individually. OVRUN1 is used for the over travel signal of + side and OVRUN2 for the over travel signal of - side. When OT is detected, it is recognized that the received signal is in + side or - side. For this reason, an error occurs always during OT detecting.

Unless the OT detecting mode is released, the error occurs immediately even if it is reset.

1 : Serial detecting method

Inputs the OT detected value into only OVRUN1 at serial connection.

The serial detecting function recognizes + side or - side by the shifting direction commanded when OT is detected. The direction of OT detected once is stored until OT is undetected and the table cannot be shifted in additional direction.



For details, see 『 Over Travel 』 .

PRM122

[N A M E] MZERO Position Setting Method
 [M E S S A G E] ORG MODE SELECT
 【DATA RANGE】 : 0 , 1 , 2

Description Selects the setting method of MZERO position.

【 0 】 : Direct setting method


After rotating the table to the position to be MZERO, the MZERO position is established by the parameter.

1 : Detector marker detecting method (Non-dog type)

After shifting the machine to just before shift by 1 rev. of motor from the position to be MZERO and stopping it with the marker (C-phase) of detector on MZRN motion, the MZERO position is established.

2 : Dog type ZRN position setting method

After detecting the DEC DOG with a proximity SW, decelerating and stopping it with the marker (C-phase) of detector, the MZERO position is established.

 For details, see 『 MZERO Setting 』 .

Precautions

1. To make this parameter valid, it is necessary to turn OFF the power once.

PRM123

[N A M E] MZERO Position Establishing Flag
 [M E S S A G E] ORG POS COMPLETE
 【DATA RANGE】 : 0 , 1

Description Determines that the MZERO position is established or unestablished.

0 : MZERO position Unestablished

MZERO position is unestablished.

In case of PRM123=0, ZERO POS setting is required.

【 1 】 : MZERO position Established

MZERO position is established.

In case of PRM122=0, the parameter is manually set and PRM122=1,2, parameters are automatically set.

 For details, see 『 MZERO Setting 』 .

Precautions


1. To make this parameter valid, it is necessary to turn OFF the power once.

PRM200[N A M E] Zero Pulse Mask Amount

[M E S S A G E] Z-PULSE MASK AMOUNT

【DATA UNIT】 : deg 【DATA RANGE】 : 0.000 ~ 9.999

Description Sets the angle area that ignores zero pulse (Absolute reference of motor encoder) to determine the motor in MZRN.

**Precautions**

1. This parameter is not used in PRM122=0.

PRM203[N A M E] Backlash Compensation Amount

[M E S S A G E] BACKLASH COMP AMOUNT

【DATA UNIT】 : deg 【DATA RANGE】 : 0.000 ~ 9.999

Description Sets the backlash compensation amount of machine.

Precautions

1. In usual power ON / OFF, since the backlash direction is remembered, this parameter is not influenced.
2. To make this parameter valid, it is necessary to turn OFF the power once.

PRM206[N A M E] OV RUN Contact Type

[M E S S A G E] OV RUN CONTACT TYPE

【DATA RANGE】 : 0 , 1

Description Sets the contact specifications of OVRUN1、 2 (Over Travel INPUT) .

【 0 】 : A-contact
(A-axis standard)

【 1 】 : B-contact
(B-axis standard)

Precautions

1. To make this parameter valid, it is necessary to turn OFF the power once.

**PRM208 ~
PRM231**[NAME] Pitch Error Compensation

[MESSAGE] PITCH ERROR 01 ~ PITCH ERROR 24

【DATA UNIT】 : deg

【DATA RANGE】 : -32.766 ~ +32.766

Description Sets the pitch error compensation amount (Actually-measured value - Theoretical value) every 15 ° that divides one revolution (360 °) of table to 24-equipartition on the basis of MZERO position.

NO.	NAME	DESCRIPTION
PRM208	PITCH ERR COM 01	Compensates for 0 ° < 15 ° of machine coordinate system.
PRM209	PITCH ERR COM 02	Compensates for 15 ° < 30 ° of machine coordinate system.
PRM210	PITCH ERR COM 03	Compensates for 30 ° < 45 ° of machine coordinate system.
PRM211	PITCH ERR COM 04	Compensates for 45 ° < 60 ° of machine coordinate system.
PRM212	PITCH ERR COM 05	Compensates for 60 ° < 75 ° of machine coordinate system.
PRM213	PITCH ERR COM 06	Compensates for 75 ° < 90 ° of machine coordinate system.
PRM214	PITCH ERR COM 07	Compensates for 90 ° < 105 ° of machine coordinate system.
PRM215	PITCH ERR COM 08	Compensates for 105 ° < 120 ° of machine coordinate system.
PRM216	PITCH ERR COM 09	Compensates for 120 ° < 135 ° of machine coordinate system.
PRM217	PITCH ERR COM 10	Compensates for 135 ° < 150 ° of machine coordinate system.
PRM218	PITCH ERR COM 11	Compensates for 150 ° < 165 ° of machine coordinate system.
PRM219	PITCH ERR COM 12	Compensates for 160 ° < 180 ° of machine coordinate system.
PRM220	PITCH ERR COM 13	Compensates for 180 ° < 195 ° of machine coordinate system.
PRM221	PITCH ERR COM 14	Compensates for 195 ° < 210 ° of machine coordinate system.
PRM222	PITCH ERR COM 15	Compensates for 210 ° < 225 ° of machine coordinate system.
PRM223	PITCH ERR COM 16	Compensates for 225 ° < 240 ° of machine coordinate system.
PRM224	PITCH ERR COM 17	Compensates for 240 ° < 255 ° of machine coordinate system.
PRM225	PITCH ERR COM 18	Compensates for 255 ° < 270 ° of machine coordinate system.
PRM226	PITCH ERR COM 19	Compensates for 270 ° < 285 ° of machine coordinate system.
PRM227	PITCH ERR COM 20	Compensates for 285 ° < 300 ° of machine coordinate system.
PRM228	PITCH ERR COM 21	Compensates for 300 ° < 315 ° of machine coordinate system.
PRM229	PITCH ERR COM 22	Compensates for 315 ° < 330 ° of machine coordinate system.
PRM230	PITCH ERR COM 23	Compensates for 330 ° < 345 ° of machine coordinate system.
PRM231	PITCH ERR COM 24	Compensates for 345 ° < 360 ° (0 °) of machine coordinate system.

Precautions

1. The pitch error compensation becomes effective after MZRN.
2. MZRN is not compensated.
3. Since a minimum set unit is 0.001deg, the pitch error compensation less than this value is impossible.
4. The pitch error is compensated for only the target coordinate during program operation and it does not compensate in the middle way of trace.
5. When stopping at ALARM and STOP, the compensation is not performed.
6. In set angle area (15 °), the set pitch error is compensated even if stopped at any positions.



For details, see 『 Pitch Error Compensation 』.

PRM240

[N A M E] RS232C Communication Speed
 [M E S S A G E] RS232C BAUD RATE
 【DATA RANGE】 : 0 , 1 , 2 , 3

Description Sets the communication speed of comm. protocol.

0 : 2400 bps
 1 : 4800 bps
 【 2 】 : 9600 bps
 3 : 19200 bps

Precautions

1. To make this parameter valid, it is necessary to turn OFF the power once.



Concerned parameters PRM242 , PRM243 , PRM244

PRM242

[N A M E] RS232C Data Length
 [M E S S A G E] RS232C DATA HEAD
 【DATA RANGE】 : 0 , 1

Description Sets the data length of communication protocol.

【 0 】 : 7 bit
 1 : 8 bit

Precautions

1. To make this parameter valid, it is necessary to turn OFF the power once.



Concerned parameters PRM240 , PRM243 , PRM244

PRM243

[N A M E] RS232C Parity Bit
 [M E S S A G E] RS232C PARITY BIT
 【DATA RANGE】 : 0 , 1

Description Sets the parity bit of communication protocol.

【 0 】 : Even
 1 : Uneven
 2 : None

Precautions

1. To make this parameter valid, it is necessary to turn OFF the power once.



Concerned parameters PRM240 , PRM242 , PRM244

PRM244

[N A M E] RS232C Stop Bit
 [M E S S A G E] RS232C STOP BIT
 【DATA RANGE】 : 0 , 1

Description Sets the stop bit of communication protocol.

【 0 】 : 2 bit
 1 : 1 bit

Precautions

1. To make this parameter valid, it is necessary to turn OFF the power once.



Concerned parameters PRM240 , PRM242 , PRM243

PRM245

[N A M E] Servo Parameter Check Function in Power ON
 [M E S S A G E] SERVO PRM CHECK FUNC
 【DATA RANGE】 : 0 , 1 , 2

Description Selects the specifications of servo parameter to be checked when the power for the controller is turned ON.

【 0 】 : Communication YES / Parameter check YES

Checks that the servo parameter content stored in previous power OFF is correct in power ON.

When there is incorrect content by the servo parameter check, the parameter No. is communicated on the start screen in power ON and it is automatically corrected into the stored servo parameter.

1 : Communication NO / Parameter check YES

Checks that the servo parameter content stored in previous power OFF is correct in power ON.

Even if there is incorrect content by the servo parameter check, the parameter No. is not communicated and it is automatically corrected into the stored servo parameter.

2 : Parameter check NO

The servo parameter in power ON is not checked.

Even if the parameter does not correspond to the stored servo parameter, it is not corrected.

Precautions

1. To make this parameter valid, it is necessary to turn OFF the power once.
2. This parameter functions from power OFF to next power ON. Therefore, the servo parameter can be changed during power ON.

PRM250[NAME] Imposition Width


[MESSAGE] IMPOSITION WIDTH

【DATA UNIT】 : 0.001deg

【DATA RANGE】 : 0 ~ 32767

Description When the slippage of machine position stopped by program operation and a commanded position (absolute value of position deviation amount) is smaller than the imposition width, it is regarded as the case that the machine reaches the commanded position, thereby setting the imposition width of positioning completion.

However, the table rotates at the commanded position in place of the positioning-completed width.


**PRM251**[NAME] Constant 1 in Acceleration/Deceleration

[MESSAGE] ACC/DEC CONSTANT 1

【DATA UNIT】 : msec

【DATA RANGE】 : 0 ~ 1000

Description Sets the T1-time of ACC/DEC.



Concerned parameter PRM252

PRM252[NAME] Constant 2 in Acceleration/Deceleration

[MESSAGE] ACC/DEC CONSTANT 2

【DATA UNIT】 : msec

【DATA RANGE】 : 1

Description Sets the T2-time of ACC/DEC.

Precautions

1. Since the TC2 of constant 2 in ACC/DEC is fixed to 1msec., it becomes the linear acceleration/deceleration actually.



Concerned parameter PRM251

PRM253

[N A M E] Enable Switch Flag
 [M E S S A G E] ENABLE SW FLAG
 【DATA RANGE】 : 0 , 1

Description Sets the VALID/INVALID of ENABLE SW mounted on the pendant.

0 : INVALID

【 1 】: VALID

Precautions

1. In case of no pendant spec., though a standard set value becomes “0”, in case of pendant spec., the standard set value becomes “1”.

PRM255

[N A M E] MZRN Dead Slow Speed Percent
 [M E S S A G E] MZRN 2TH FL RATE
 【DATA UNIT】 : % 【DATA RANGE】 : 0 ~ 100

Description Sets the percent of 2nd stage deceleration speed in MZRN.

The percent for value set to PRM002 is provided.

See the explanatory drawing of PRM002 for operation.




Concerned parameter PRM002

PRM256

[N A M E] 360 ° FIN Chattering Prevention Timer
 [M E S S A G E] 360FIN CHATTERING
 【DATA UNIT】 : SEC 【DATA RANGE】 : 0.0 ~ 1.0

Description Though 360FIN is outputted when PRM025 = 1 is set, this CONT. OUTPUT is started after checking that the table exists for PRM256-time in PRM026-set area. Thus, this timer is provided to prevent the chattering in area.



Concerned parameters PRM025 , PRM026

PRM257 [NAME] MZRN Mode
 [MESSAGE] HMODE
 【DATA UNIT】 : sec

Description Sets the value relative to MZRN. However, since the value is fixed, it cannot be changed.

PRM258 [NAME] MZRN Time-out
 [MESSAGE] MZRN TIME-OUT
 【DATA UNIT】 : sec





Description Sets the time to make the time-out when MZRN is not finished because of any reason in MZRN. However, the time is fixed, it cannot be changed.

PRM300 ~ PRM389 [NAME] WZERO Position Every Channel
 [MESSAGE] WZERO POSITION CH00 ~ WZERO POSITION CH89
 【DATA UNIT】 : deg 【DATA RANGE】 : 0.000 ~ 359.999

Description Sets the WZERO position every channel based on MZERO position.
 Maximum 90 channels can be set to PRM300 ~ PRM389.

Common WZERO position = 135.000 in PRM047=0 and

WZERO positions when PRM300(CH00)=45.000 PRM315(CH15) = 315.000 are set.

Condi- tions	PRM047=0 WZERO POS INVALID every channel		PRM047=1 WZERO POS VALID every channel	
	CH00	CH15	CH00	CH15
WZERO POS				

Precautions

- When 『Sets WZERO POS every channel.』 of PRM047=1 is selected, WZERO position every channel becomes valid.



Concerned parameter PRM047

PRM390

[N A M E] Channel/Block Structure Spec.
 [M E S S A G E] CH/BLOCK CONFIG SPEC
 【DATA RANGE】 : 0 , 1 , 2

Description Selects the spec., of channel/block structure.

When the expansion channel function is used, the function to check whether the existed program fails or not for the newly set Channel/Block structure is selected to USED/UNUSED.


【 0 】 : Standard channel/block structure

CH00 : 500 block, CH01 ~ CH15 : 100 block structure

1 : When Channel/Block are optionally set with the expansion channel function, the program is checked.

2 : When Channel/Block are optionally set with the expansion channel function, the program is not checked.

 Concerned parameters PRM400 ~ 489

 For details, see 『 Expansion Channel 』 .


**PRM400 ~
PRM489**

[N A M E] Number of Blocks every Channel
 [M E S S A G E] BLOCKS OF CH00 ~ BLOCKS OF CH89
 【DATA UNIT】 : BLOCK 【DATA RANGE】 : 0 ~ 1000

Description When channels or blocks are changed with the expansion channel function, the number of blocks is set every channel.

Precautions

1. In PRM390=1 or 2, this parameter becomes valid.
2. The channel that the number of blocks is set to “0” and the channel after its channel cannot be selected.

 Concerned parameter PRM390

 For details, see 『 Expansion Channel 』 .

Parameters relative to servo control

Though the parameters relative to servo for the controller are described below, do not change the parameters.

PRM506[N A M E] Function Select Switch 6

[M E S S A G E] P006 APPLICATION SW6

【DATA UNIT】 : hex 【DATA RANGE】 : 000 ~ 409

Description Selects the analog monitor content of servo motor.

Corresponds to the parameter Pn006 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

Pn006.0 Analog monitor 1 signal selection

Pn006.1 00 : Motor rev. speed : DC1V/1000min⁻¹

01 : Speed command : DC1V/1000min⁻¹

【02】: Torque command : DC1V/100%

03 : Position deviation : DC0.05V/1 command unit

04 : Pos. amp. deviation : DC0.05V/1 encoder pulse unit

05 : Pos. command speed : DC1V/1000min⁻¹

06 : Reservation

07 : Reservation

08 : Pos. FIN command : (POS FIN : 5V、 POS UNFIN : 0V)

09 : Speed feed forward : DC1V/100%

Pn006.2 Analog monitor 1 signal factor selection

【00】: 1-time

01 : 10-time

02 : 100-time

03 : 1/10-time

04 : 1/100-time

Remarks

Analog monitor 1 OUTPUT voltage =

{ (-1) × Signal select (PRM506.0) × Signal factor (PRM506.2) } +OFFSET voltage (PRM631)



Concerned parameter PRM631

PRM507[N A M E] Function Select Switch 7

[M E S S A G E] P007 APPLICATION SW7

【DATA UNIT】 : hex 【DATA RANGE】 : 000 ~ 409

Description

Selects the analog monitor content of servo motor.

Corresponds to the parameter Pn007 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

Pn007.0 Analog monitor 1 signal selection

Pn007.1 00 : Motor rev. speed : DC1V/1000min⁻¹01 : Speed command : DC1V/1000min⁻¹

【02】: Torque command : DC1V/100%

03 : Position deviation : DC0.05V/1 command unit

04 : Pos. amp. deviation : DC0.05V/1 encoder pulse unit

05 : Pos. command speed : DC1V/1000min⁻¹

06 : Reservation

07 : Reservation

08 : Positioning finish command : (Positioning finish : 5V、 Positioning unfinished : 0V)

09 : Speed feed forward : DC1V/100%

Pn07.2 Analog monitor 1 signal factor selection

【00】: 1-time

01 : 10-time

02 : 100-time

03 : 1/10-time

04 : 1/100-time

Remarks

Analog monitor 1 OUTPUT voltage =

{ (-1) × Signal select (PRM507.0) × Signal factor (PRM507.2) } +OFFSET voltage (PRM632)



Concerned parameter PRM632

PRM508[N A M E] Function Select Switch 8

[M E S S A G E] P008 APPLICATION SW8

【DATA UNIT】 : hex 【DATA RANGE】 : 0 ~ 1

Description

Selects the analog monitor content of servo motor.

Corresponds to the parameter Pn008 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

Pn008.0 ALARM/WARNING selection of battery voltage drop

【0】: Battery voltage drop is regarded as ALARM (A.830).

1 : Battery voltage drop is regarded as WARNING (A.930).

Pn008.1 Single phase of three-phase INPUT mode

【0】: Three-phase INPUT mode is used by three-phase INPUT mode.

Pn008.2 Warning detection selection

【0】: Detects WARNING.

PRM510

[N A M E] Speed Loop Gain
 [M E S S A G E] P100 SPEED LOOP GAIN
 【DATA UNIT】 : 0.1Hz 【DATA RANGE】 : 10 ~ 20000

Description Sets the responsibility of servo motor to control speed.
 Corresponds to the parameter Pn100 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM511

[N A M E] Speed Loop Integration Time Constant
 [M E S S A G E] P101 SLG INTEGRATION
 【DATA UNIT】 : 0.01msec 【DATA RANGE】 : 15 ~ 51200

Description This is the user constant to determine the responsibility of speed loop.
 Corresponds to the parameter Pn101 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

Precautions

1. When the responsibility of speed loop is low, since the position loop on outside becomes a delay factor, overshoot occurs or vibration speed command occurs. Therefore, it is recommended to set the value as higher as possible at area that the machine system does not vibrate. As a result, the servo system is stable and the responsibility is increased.

PRM512

[N A M E] Position Loop Gain
 [M E S S A G E] P102 POS LOOP GAIN
 【DATA UNIT】 : 0.1/sec 【DATA RANGE】 : 10 ~ 20000

Description The responsibility of position loop is determined by the position loop gain.
 Corresponds to the parameter Pn102 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

Precautions

1. When the position loop gain can be set to high value, the responsibility becomes high and the positioning time becomes short. However, it is impossible to increase the position loop gain over a natural frequency.

PRM513

[N A M E] Moment Ratio of Inertia
 [M E S S A G E] P103 INERTIA RATIO
 【DATA UNIT】 : % 【DATA RANGE】 : 1 ~ 20000

Description When fixture carried in rotary table , the case where work is large, and the center of gravity have shifted, vibration and roar sound may occur in rotary table .

$$\text{Inertia ratio} = \frac{\text{Load inertia of motor shaft conversion (J}_L\text{)}}{\text{Rotor inertia of servo motor (J}_M\text{)}} \times 100(\%)$$

Corresponds to the parameter Pn103 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM514

[N A M E] 2nd Speed Loop Gain
 [M E S S A G E] P104 2TH S-LOOP GAIN
 【DATA UNIT】 : 0.1Hz 【DATA RANGE】 : 10 ~ 20000

Description Sets the responsibility of servo motor when speed is controlled.
 Corresponds to the parameter Pn104 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM515

[N A M E] Constant in 2nd Speed Loop Integration
 [M E S S A G E] P105 2TH SLG INTE
 【DATA UNIT】 : 0.01msec 【DATA RANGE】 : 15 ~ 51200

Description Sets the responsibility of servo motor when speed is controlled.
 Corresponds to the parameter Pn105 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM516


[N A M E] 2nd Position Loop Gain
 [M E S S A G E] P106 2TH POS L-GAIN
 【DATA UNIT】 : 0.1/sec 【DATA RANGE】 : 10 ~ 20000

Description Sets the responsibility for position control.
 Corresponds to the parameter Pn106 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM517

[N A M E] Bias
 [M E S S A G E] P107 BIAS
 【DATA UNIT】 : min⁻¹ 【DATA RANGE】 : 0 ~ 450


Description The time established for positioning can be shortened by giving the bias for the speed command part.
 Corresponds to the parameter Pn107 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

 Concerned parameters PRM518

PRM518

[N A M E] Bias Adding Width
 [M E S S A G E] P108 BIAS ADD WIDTH
 【DATA UNIT】 : 0.001deg 【DATA RANGE】 : 0 ~ 250


Description The bias adding width is the value that indicates the timing adding the bias at a deviation pulse. When the deviation pulse exceeds the set value of bias adding width, the bias is added.
 Corresponds to the parameter Pn108 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

 Concerned parameter PRM517

Bias function

When the pulse of deviation counter exceeds the bias adding width (PRM518), this function adds the bias amount (PRM517) to the output (speed command: SP CMD) of deviation counter and it stops the adding bias value when reaching the bias adding width. For this reason, the counted pulse of deviation counter is reduced, thus shortening a positioning time.

When the bias amount is largest, the motor rotation becomes unstable. Since an optimum value varies by load, gain and bias adding width, adjust the value, watching the reply. When the bias function is not used, set PRM517 to "0".



PRM519

[NAME] Feed Forward

[MESSAGE] P109 FEED-FORWARD

【DATA UNIT】 : %

【DATA RANGE】 : 0 ~ 100

Description The positioning time is shortened by compensating the FEED FORWARD for the position control.

Corresponds to the parameter Pn109 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM520

[NAME] Constant in Feed Forward Filter

[MESSAGE] P10A F-F FILTER

【DATA UNIT】 : 0.01msec

【DATA RANGE】 : 0 ~ 6400

Description The positioning time is shortened by compensating the FEED FORWARD for the position control.

Corresponds to the parameter Pn10A of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM522

[NAME] Mode Switch (Torque Command)

[MESSAGE] P10C MODE-SW(TRQUE)

【DATA UNIT】 : %

【DATA RANGE】 : 0 ~ 800

Description When the torque is commanded over PRM522, the speed loop becomes "Proportional Control".

This mode controls to overshoot or undershoot the motor speed because the torque in ACC/DEL is saturated.

Corresponds to the parameter Pn10C of servo pack SGDS made by YASKAWA ELECTRIC CORP.



Concerned parameters PRM521 (Valid in Pn10B.0=0)

PRM527

[N A M E] Speed Feedback Compensation
 [M E S S A G E] P111 SPEED FEEDBACK
 【DATA UNIT】 : % 【DATA RANGE】 : 1 ~ 500

Description When using the speed feedback compensation function, the speed loop gain or position loop gain is increased, thus shortening the positioning setting time.
 Corresponds to the parameter Pn111 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM528

[N A M E] Command Filter Gain
 [M E S S A G E] P119 CMD FILTER GAIN
 【DATA UNIT】 : 0.1/sec 【DATA RANGE】 : 10 ~ 20000

Description Corresponds to the parameter Pn119 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM529

[N A M E] Command Filter Gain Compensation
 [M E S S A G E] P11A F-GAIN COMP
 【DATA UNIT】 : 0.1/sec 【DATA RANGE】 : 500 ~ 2000

Description Corresponds to the parameter Pn11A of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM530

[N A M E] Command Filter Bias (CW)
 [M E S S A G E] P11E F-BIAS(CW)
 【DATA UNIT】 : 0.1% 【DATA RANGE】 : 0 ~ 10000

Description Corresponds to the parameter Pn11E of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM531

[N A M E] Position Integration Time Constant
 [M E S S A G E] P11F POS INTEGRATION
 【DATA UNIT】 : 0.1% 【DATA RANGE】 : 0 ~ 50000

Description Corresponds to the parameter Pn11F of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM532

[N A M E] 3rd Speed Loop Gain
 [M E S S A G E] P12B 3TH S-LOOP GAIN
 【DATA UNIT】 : 0.1/sec 【DATA RANGE】 : 10 ~ 20000

Description Corresponds to the parameter Pn12B of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM533

[N A M E] 3rd Loop Integration Time Constant
 [M E S S A G E] P12C 3TH SLG INTE
 【DATA UNIT】 : 0.1Hz 【DATA RANGE】 : 15 ~ 51200

Description Corresponds to the parameter Pn12C of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM534[N A M E] 3rd Position Loop Gain

[M E S S A G E] P12D 3TH POS L-GAIN

【DATA UNIT】 : 0.1msec 【DATA RANGE】 : 10 ~ 20000

Description Corresponds to the parameter Pn12D of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM535[N A M E] 4th Speed Loop Gain

[M E S S A G E] P12E 4TH S-LOOP GAIN

【DATA UNIT】 : 0.1/sec 【DATA RANGE】 : 10 ~ 20000

Description Corresponds to the parameter Pn12E of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM536[N A M E] 4th Loop Integration Time Constant

[M E S S A G E] P12F 4TH SLG INTE

【DATA UNIT】 : 0.1Hz 【DATA RANGE】 : 15 ~ 51200

Description Corresponds to the parameter Pn12F of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM537[N A M E] 4th Position Loop Gain

[M E S S A G E] P130 4TH POS L-GAIN

【DATA UNIT】 : 0.1msec 【DATA RANGE】 : 10 ~ 20000

Description Corresponds to the parameter Pn130 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM538[N A M E] Gain Change Time 1

[M E S S A G E] P131 GAIN CHANGE T1

【DATA UNIT】 : 1msec 【DATA RANGE】 : 0 ~ 65535

Description Corresponds to the parameter Pn131 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM539[N A M E] Gain Change Time 2

[M E S S A G E] P132 GAIN CHANGE T2

【DATA UNIT】 : 1msec 【DATA RANGE】 : 0 ~ 65535

Description Corresponds to the parameter Pn132 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM540[N A M E] Gain Change Wait Time 1

[M E S S A G E] P135 GAIN WAIT T1

【DATA UNIT】 : 1msec 【DATA RANGE】 : 0 ~ 65535

Description Corresponds to the parameter Pn135 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM541

[N A M E] Gain Change Wait Time 2
 [M E S S A G E] P136 GAIN WAIT T2
 【DATA UNIT】 : 1msec 【DATA RANGE】 : 0 ~ 65535

Description Corresponds to the parameter Pn136 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM543

[N A M E] Command Filter Bias (CCW)
 [M E S S A G E] P144 CMD F-BIAS(CCW)
 【DATA UNIT】 : 0.1% 【DATA RANGE】 : 0 ~ 10000

Description Corresponds to the parameter Pn144 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM545

[N A M E] Prediction Control ACC/DECEL Gain
 [M E S S A G E] P151 PREDICTION GAIN
 【DATA UNIT】 : % 【DATA RANGE】 : 0 ~ 300

Description Performs the prediction control using an inputted position command.
 Corresponds to the parameter Pn151 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM546

[N A M E] Prediction Control Dignity Ratio
 [M E S S A G E] P152 DIGNITY RATIO
 【DATA UNIT】 : % 【DATA RANGE】 : 0 ~ 300

Description Performs the prediction control using a future position command.
 Corresponds to the parameter Pn152 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM547

[N A M E] Servo Rigidity
 [M E S S A G E] P1A0 SERVO RIGIDITY
 【DATA UNIT】 : % 【DATA RANGE】 : 0 ~ 500

Description Corresponds to the parameter Pn1A0 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM548

[N A M E] Servo Rigidity 2
 [M E S S A G E] P1A1 SERVO RIGIDITY2
 【DATA UNIT】 : % 【DATA RANGE】 : 0 ~ 500

Description Corresponds to the parameter Pn1A1 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM549

[N A M E] Speed Feedback Filter Time Constant
 [M E S S A G E] P1A2 SPEED F/B FLT
 【DATA UNIT】 : 0.01msec 【DATA RANGE】 : 30 ~ 3200

Description Corresponds to the parameter Pn1A2 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM550[N A M E] Speed Feedback Filter Time Constant 2

[M E S S A G E] P1A3 SPEED F/B FLT2

【DATA UNIT】 : 0.01msec

【DATA RANGE】 : 30 ~ 3200

Description Corresponds to the parameter Pn1A3 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM551[N A M E] Torque Command Filter Time Constant 2

[M E S S A G E] P1A4 TQ FILTER2

【DATA UNIT】 : 0.01msec

【DATA RANGE】 : 0 ~ 2500

Description Corresponds to the parameter Pn1A4 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM553[N A M E] Auxiliary Integration Gain

[M E S S A G E] P1A9 AUX INTE GAIN

【DATA UNIT】 : Hz

【DATA RANGE】 : 0 ~ 500

Description Corresponds to the parameter Pn1A9 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM554[N A M E] Position Ratio Gain

[M E S S A G E] P1AA POS RATIO GAIN

【DATA UNIT】 : Hz

【DATA RANGE】 : 0 ~ 500

Description Corresponds to the parameter Pn1AA of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM555[N A M E] Feed Integration Gain

[M E S S A G E] P1AB FEED INTE GAIN

【DATA UNIT】 : Hz

【DATA RANGE】 : 0 ~ 500

Description Corresponds to the parameter Pn1AB of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM556[N A M E] Feed Ratio Gain

[M E S S A G E] P1AC FEED RATIO GAIN

【DATA UNIT】 : Hz

【DATA RANGE】 : 0 ~ 2000

Description Corresponds to the parameter Pn1AC of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM563[N A M E] Position Command ACC/DECL Bias

[M E S S A G E] P209 POS REF BIAS

【DATA UNIT】 : 1-command unit/sec

【DATA RANGE】 : 0 ~ 65535

Description Corresponds to the parameter Pn209 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM567[N A M E] Backlash Compensation Amount

[M E S S A G E] P214 BACKLASH

【DATA UNIT】 : Command unit 【DATA RANGE】 : -32767 ~ 32767

Description Sets a backlash compensation amount.

Corresponds to the parameter Pn214 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM568[N A M E] Backlash Compensation Time Constant

[M E S S A G E] P215 BACKLASH TC

【DATA UNIT】 : 0.01msec 【DATA RANGE】 : 0 ~ 65535

Description Corresponds to the parameter Pn215 of servo pack SGDS made by YASKAWA ELECTRIC CORP.**PRM569**[N A M E] Position Command ACC/DEC Time Constant

[M E S S A G E] P216 POS-REF A/D

【DATA UNIT】 : 0.01msec 【DATA RANGE】 : 0 ~ 65535

Description Corresponds to the parameter Pn216 of servo pack SGDS made by YASKAWA ELECTRIC CORP.**PRM571**[N A M E] Speed Command Input Gain

[M E S S A G E] P300 SPEED REF GAIN

【DATA UNIT】 : 0.01V/Rated speed 【DATA RANGE】 : 150 ~ 3000

Description The feed forward function shortens the positioning time. When the feed forward is too applied, overshoot and under shoot occur.
Corresponds to the parameter Pn300 of servo pack SGDS made by YASKAWA ELECTRIC CORP.**PRM575**[N A M E] JOG Feed

[M E S S A G E] P304 JOG FEED

【DATA UNIT】 : min⁻¹ 【DATA RANGE】 : 0 ~ 10000**Description** Sets the motor rotary speed when the motor is rotated under the operation mode by panel operator or digital operator.
Corresponds to the parameter Pn304 of servo pack SGDS made by YASKAWA ELECTRIC CORP.**PRM576**[N A M E] Soft Start Acceleration Time

[M E S S A G E] P305 SOFT ACC TIME

【DATA UNIT】 : msec 【DATA RANGE】 : 0 ~ 10000

Description The step type "Speed Command" INPUT mode rotates the servo motor smoothly at a constant acceleration speed inside of servo pack. At this time, the time from motor-stopped state to max. motor rotary speed is set.
Corresponds to the parameter Pn305 of servo pack SGDS made by YASKAWA ELECTRIC CORP.**PRM577**[N A M E] Soft Start Deceleration Time

[M E S S A G E] P306 SOFT DEC TIME
 【DATA UNIT】 : msec 【DATA RANGE】 : 0 ~ 10000

Description The step type “Speed Command” INPUT mode rotates the servo motor smoothly at a constant deceleration speed inside of servo pack. At this time, the time from max. motor rotary speed to motor stop state is set.
 Corresponds to the parameter Pn306 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM578 [N A M E] Speed Command Filter Time Constant

[M E S S A G E] P307 SPEED REF FLT
 【DATA UNIT】 : 0.01msec 【DATA RANGE】 : 0 ~ 65535

Description Primary delay filter is applied to the analog speed command to make the speed command smooth.
 If a large value is set, responsibility becomes wrong.
 Corresponds to the parameter Pn307 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM579 [N A M E] Speed F/B Filter Time Constant

[M E S S A G E] P308 SPEED F/B FLT
 【DATA UNIT】 : 0.01msec 【DATA RANGE】 : 0 ~ 65535

Description The primary delay filter is set to the speed feedback of speed loop. At this time, the feedback becomes smooth and vibration also becomes small.
 If a large value is set, it becomes a delay factor, thus resulting in a poor responsibility.
 Corresponds to the parameter Pn308 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM584 [N A M E] 1st No. 1 Torque Command Filter Time Constant

[M E S S A G E] P401 TORQUE REF FLT
 【DATA UNIT】 : 0.01% 【DATA RANGE】 : 0 ~ 65535

Description This parameter is changed when the machine vibrates because of servo drive damage.
 When parameter number is smaller, good responsible control can be made.
 This corresponds to parameter Pn401 of SGDS of YASKAWA ELECTRIC CO.

PRM585 [N A M E] Clockwise Torque Limitation

[M E S S A G E] P402 CW TORQUE LMT
 【DATA UNIT】 : % 【DATA RANGE】 : 0 ~ 800

Description Limits a max. value of OUTPUT torque on CW side.
 Corresponds to the parameter Pn402 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM586

[N A M E] Reverse Torque Limit
 [M E S S A G E] P403 CCW TORQUE LMT
 【DATA UNIT】 : % 【DATA RANGE】 : 0 ~ 800

Description Limits the max. value of OUTPUT torque on reverse side.
 Corresponds to the parameter Pn403 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM587

[N A M E] External Torque Limit on CW Side
 [M E S S A G E] P404 CW EXT T-LMT
 【DATA UNIT】 : % 【DATA RANGE】 : 0 ~ 800

Description Limits the max. value of OUTPUT torque on CW side preset at the external contact INPUT.
 Corresponds to the parameter Pn404 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM588

[N A M E] External Torque Limit on CCW Side
 [M E S S A G E] P405 CCW EXT T-LMT
 【DATA UNIT】 : % 【DATA RANGE】 : 0 ~ 800

Description Limits the max. value of OUTPUT torque on CCW side preset at the external contact INPUT.
 Corresponds to the parameter Pn405 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM592

[N A M E] 1st Stage Notch Filter Frequency
 [M E S S A G E] P409 1TH NOTCH FLT
 【DATA UNIT】 : Hz 【DATA RANGE】 : 50 ~ 2000

Description Sets a machine frequency.
 Corresponds to the parameter Pn409 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM593

[N A M E] 1st Stage Notch Filter Q-value
 [M E S S A G E] P40A 1TH NOTCH FLT
 【DATA UNIT】 : 0.01 【DATA RANGE】 : 50 ~ 1000

Description Because the machine vibration is restricted, if overshoot occurs, adjust it with Q-value.
 Corresponds to the parameter Pn40A of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM594

[N A M E] 2nd Stage Notch Filter Frequency
 [M E S S A G E] P40C 2TH NOTCH FLT
 【DATA UNIT】 : Hz 【DATA RANGE】 : 50 ~ 2000

Description Sets a machine vibration frequency.
 Corresponds to the parameter Pn40C of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM595

[N A M E] 2nd Notch Filter Q-value

[M E S S A G E] P40D 2TH NOTCH FLT
 【DATA UNIT】 : 0.01 【DATA RANGE】 : 50 ~ 1000

Description When overshoot occurs even if machine vibration is restricted, adjust it with Q-value.
 Corresponds to the parameter Pn40D of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM602 [N A M E] Vibration Suppression Damping Ratio in Stop
 [M E S S A G E] P420 V-CTL RATIO
 【DATA UNIT】 : % 【DATA RANGE】 : 10 ~ 100

Description This function reduces the servo gain during stop in order to suppress vibration during stop.
 This function is effective for the vibration during stop. However, it does not correspond to the vibration during shift.
 Corresponds to the parameter Pn420 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM603 [N A M E] Vibration Suppression Start Ratio in Stop
 [M E S S A G E] P421 V-CTL START
 【DATA UNIT】 : msec 【DATA RANGE】 : 0 ~ 65535

Description The inside servo gain is performed at the rate of PRM602 after the time of this timer elapses from Position Command =0.
 Corresponds to the parameter Pn421 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM604 [N A M E] Gravity Compensation Torque
 [M E S S A G E] P422 GRAVITY COMP TQ
 【DATA UNIT】 : 0.01% 【DATA RANGE】 : -20000 ~ 20000

Description Corresponds to the parameter Pn422 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM605 [N A M E] Sweep Torque Command Amplitude
 [M E S S A G E] P456 TQ AMPLITUDE
 【DATA UNIT】 : % 【DATA RANGE】 : 1 ~ 800

Description Corresponds to the parameter Pn456 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM607 [N A M E] Revolution Detecting Level
 [M E S S A G E] P502 ZERO SPEED LV
 【DATA UNIT】 : min⁻¹ 【DATA RANGE】 : 0 ~ 10000

Description Sets the rev. speed to detect the revolution when judged as during motor rotation.
 Corresponds to the parameter P502 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM608 [N A M E] Speed Correspondence Signal Detecting Width
 [M E S S A G E] P503 SPEED CMP WIDTH
 【DATA UNIT】 : min^{-1} 【DATA RANGE】 : 0 ~ 100

Description When the difference of a speed command and a actually rotated speed of motor is less than the set value, the speed correspondence output is issued.
 Corresponds to the parameter P503 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM612 [N A M E] Momentary Hold Time
 [M E S S A G E] P509 BLACKOUT HOLD
 【DATA UNIT】 : msec 【DATA RANGE】 : 20 ~ 1000

Description When the power voltage supply to the servo pack is momentarily OFF, the servo pack detects this blackout and turns OFF the servo. At this time, a momentary OFF time is set. When this time is less than the set time, operation is continued as is. When it is more than the set time, the servo is turned OFF.
 Corresponds to the parameter P509 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM622 [N A M E] Warning Level of Excessive Position Deviation
 [M E S S A G E] P51E POS DEV WARNING
 【DATA UNIT】 : % 【DATA RANGE】 : 10 ~ 100

Description This is the factor of calculation when an excessive position deviation alarm occurs.
 Corresponds to the parameter Pn51E of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM623 [N A M E] Alarm Level of Excessive Position Deviation
 [M E S S A G E] P520 POS DEV ALARM
 【DATA UNIT】 : Command unit 【DATA RANGE】 : $1 \sim 107341823(2^{30}-1)$

Description This is the factor for calculation when the excessive position deviation alarm occurs.
 Corresponds to the parameter P520 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM625 [N A M E] Near Signal Width
 [M E S S A G E] P524 NEAR SIG WIDTH
 【DATA UNIT】 : Command unit 【DATA RANGE】 : $1 \sim 107341824(2^{30})$

Description Sets the width for near output to show where the servo motor is in near SHIFT CCOMPIATION point.
 Corresponds to the parameter P524 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM626

[N A M E]

Alarm Level of Excessive POS-DEV in Servo ON

[M E S S A G E]

P526 SVON P-D ALARM

【DATA UNIT】 : Command unit

【DATA RANGE】 : 1 ~ 107341823($2^{30}-1$)**Description**

Issues an alarm when the POS-DEV pulse exceeds this set value in servo ON.
Corresponds to the parameter P526 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM627

[N A M E]

Warning Level of Excessive POS-DEV in Servo ON

[M E S S A G E]

P528 SVON P-D WARNING

【DATA UNIT】 : %

【DATA RANGE】 : 10 ~ 100

Description

Issues a warning mode when the POS-DEV pulse exceeds this set value in servo ON.
Corresponds to the parameter P528 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM628

[N A M E]

Feed Limit Level in Servo ON

[M E S S A G E]

P529 SVON FEED LEVEL

【DATA UNIT】 : min^{-1}

【DATA RANGE】 : 0 ~ 10000

Description

Limits speed at this set mode when the servo is ON with position deviation pulses saved.
Corresponds to the parameter P529 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM630

[N A M E]

Gain Limit

[M E S S A G E]

P540 GAIN LIMIT

【DATA UNIT】 : 0.1Hz

【DATA RANGE】 : 10 ~ 20000

Description

Corresponds to the parameter P540 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM631

[N A M E]

Analog Monitor 1 Offset Voltage

[M E S S A G E]

P550 ANALOG MONITOR1

【DATA UNIT】 : 0.1V

【DATA RANGE】 : -10000 ~ 10000

Description

Offsets the analog monitor content with PRM506.
Corresponds to the parameter P550 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

PRM632

[N A M E]

Analog Monitor 2 Offset Voltage

[M E S S A G E]

P551 ANALOG MONITOR2

【DATA UNIT】 : 0.1V

【DATA RANGE】 : -10000 ~ 10000

Description

Offsets the analog monitor content with PRM507.
Corresponds to the parameter P551 of servo pack SGDS made by YASKAWA ELECTRIC CORP.

2 ORG MODE Selection

2.1. To set ORG MODE

How to set MZERO that is the machine reference of circular table is divided into the following three methods.

- Direct setting method MZRN position 【PRM122=0】
After rotating the table to the position to be MZERO, MZRN position is established.
- Detector marker detecting method (Non-dog type) 【PRM122=1】
After shifting the machine to the place just before shifting by one revolution of motor from the place to be MZERO, the MZRN position is established at the place where the machine is stopped with the detector marker (C-phase) on MZRN motion.
- Dog type ZERO POS setting method 【PRM122=2】
The proximity SW detects a deceleration dog and the MZRN position is established at the place where the machine is stopped with the detector marker (C-phase) on MZRN motion after decelerating.

These MZRN position setting methods are changed with parameters.

When MZRN is required, the controller displays “ Err.400 MZERO POS UN-SETUP ” .

The case required for MZRN is as follows:

- The encoder cable is removed from the motor.
- With the back-up battery gone out, the power of controller is turned OFF.
- The set value of PRM123 is set to “0”.
- The set value of gear ratio of PRM011 is changed.

2.2. Directly setting method

The following explains the steps to set ORG POS directly.

2.2.1.

Directly setting of ORG MODE



→ Push **MODE** to select 『MANUAL』.



+ ENABLE switch or manual pulse generator

→ Shift the table manually to the angle to be MZRN position.



→ Push **MODE** to select 『PARAM』.



→ Set “1” to PRM110 so that any parameter can be written.



→ Call the ORG POS COMPLETE parameter.



→ Set the set value of parameter to “1” to establish the ORG POS.



→ **INPUT** is pushed and a power supply is turned off.

When setting the MZERO position directly, set the ORG POS COMPLETE parameter to “0”.

With ORG POS COMPLETE parameter set to “1”, when MZERO position is established, STATUS 『READY』 LED lights.

When setting PRM123=1 of ORG POS COMPLETE, “Err.091 POWER OFF ALARM” is displayed and power is turned OFF.

A setup of PRM123 cannot perform A axis and B axis simultaneously. After 1 axis setup, please carry out power supply OFF/ON and also set up another axis.

2.3. Detector marker detecting method (Non-dog type)

The following explains the steps to set the ORG MODE SELECT with the marker of motor encoder.

2.3.1

Detector marker detecting set



→ Push **MODE** to select 『 MANUAL 』.



+ ENABLE switch or manual pulse generator

→ Shift the table by one revolution of motor to the place just before the position to be MZRN position.



+ ENABLE switch

→ Detect MZERO with the marker at deceleration speed (PRM002).

When the marker detecting is performed on shift motion, the table stops immediately and ORG POS COMPLETE parameter set value is automatically set to “1”, thus establishing MZERO position.

When setting ORG MODE SELECT directly, set the ORG POS COMPLETE parameter to “0”.

When the ORG POS COMPLETE parameter is automatically set to “1”, STATUS 『 READY 』 LED lights.

When MZERO is established by MZRN, “ Err.091 POWER OFF ALARM ” and POWER OFF are required and displayed.

Angle by one revolution of motor differs by gear ratio.

Gear ratio	1/36	1/60	1/72	1/90	1/120	1/180	1/360
Angle by one revo. of motor (°)	10	6	5	4	3	2	1

2.4. Dog type ORG MODE Selection

The following explains the steps to set the MZERO position with the marker of motor encoder at DECEL. Dog.

2.4.1

Dog type ORG MODE Selection



→ Push **MODE** to select 『MANUAL』.



+ ENABLE switch

→ Perform MZRN.

When the DECEL. dog is detected, the table becomes deceleration speed and the table stops immediately with the marker after DECEL. Dog non-detecting and the ORG POS COMPLETE parameter is set to “1”, thus establishing MZERO position.

When setting ORG MODE SELECT directly, set the ORG POS COMPLETE parameter to “0”.

When the ORG POS COMPLETE parameter is automatically set to “1”, STATUS 『READY』 LED lights.

When MZERO is established by MZRN, “Err.091 POWER OFF ALARM” and POWER OFF are required and displayed.

3 Pitch Error Compensation

3.1 Outline

Setting the pitch error data can compensate the pitch error at 0.001° unit for a symmetric axis.

The PITCH ERROR can be set as a compensation reference position of MZERO position every given interval (15°).

3.2 Parameter setting


The PITCH ERROR mode divides one revolution of circular table into 24 and the parameter is allocated in order at section every 15° . Thus, the compensation value is set for the parameter of section required for pitch error.

3.2.1.

Parameters

The parameter is allocated on the basis of MZERO position every 15° block clockwise as shown in the following figure.

The parameter is set by the difference data (Actually measured value - Theoretical value) for the pitch error.



Offset No.	PRM No.	Offset No.	PRM No.
(1)	PRM208	(13)	PRM220
(2)	PRM209	(14)	PRM221
(3)	PRM210	(15)	PRM222
(4)	PRM211	(16)	PRM223
(5)	PRM212	(17)	PRM224
(6)	PRM213	(18)	PRM225
(7)	PRM214	(19)	PRM226
(8)	PRM215	(20)	PRM227
(9)	PRM216	(21)	PRM228
(10)	PRM217	(22)	PRM229
(11)	PRM218	(23)	PRM230
(12)	PRM219	(24)	PRM231

3.2.2. Parameter setting examples

The following explains the parameter setting method according to the following reference examples.

Measured example) Data measured every 5 ° .


SFT Ang.	Mesu. V	SFT Ang.	Mesu. V	SFT Ang.	Mesu. V	SFT Ang.	Mesu. V
0.000	0.000	90.000	90.015	180.000	180.001	270.000	269.985
5.000	5.000	95.000	95.015	185.000	185.000	275.000	274.986
10.000	10.001	100.000	100.014	190.000	190.000	280.000	279.988
15.000	15.001	105.000	105.014	195.000	194.999	285.000	279.988
20.000	20.002	110.000	110.012	200.000	199.999	295.000	294.989
25.000	25.004	115.000	115.009	205.000	204.998	300.000	299.989
30.000	30.005	120.000	120.010	210.000	209.997	305.000	304.990
35.000	35.005	125.000	125.009	215.000	214.995	310.000	309.993
40.000	40.006	130.000	130.007	220.000	219.994	315.000	314.992
45.000	45.005	135.000	135.007	225.000	224.993	320.000	319.994
50.000	50.007	140.000	140.006	230.000	229.990	325.000	324.993
55.000	55.008	145.000	145.005	235.000	234.988	330.000	329.994
60.000	60.008	150.000	150.004	240.000	239.988	335.000	334.996
65.000	65.009	155.000	155.002	245.000	244.986	340.000	340.000
70.000	70.010	160.000	160.001	250.000	249.987	345.000	344.998
75.000	75.012	165.000	165.002	255.000	254.987	350.000	350.001
80.000	80.012	170.000	170.000	260.000	259.985	355.000	354.999
85.000	85.014	175.000	175.000	265.000	264.986	360.000	360.000



When set on basis of pos. every 15 ° from meas. example data. (Colored data)

Pitch error No.	PRM No.	Offset	Pitch error No.	PRM No.	Offset	Pitch error No.	PRM No.	Offset
1	208	0.000	9	216	+0.010	17	224	-0.012
2	209	+0.001	10	217	+0.007	18	225	-0.013
3	210	+0.005	11	218	+0.004	19	226	-0.015
4	211	+0.005	12	219	+0.002	20	227	-0.012
5	212	+0.008	13	220	+0.001	21	228	-0.010
6	213	+0.012	14	221	-0.001	22	229	-0.006
7	214	+0.015	15	222	-0.003	23	230	-0.004
8	215	+0.014	16	223	-0.007	24	231	+0.001

After compensating pitch error




When setting average value every 15 ° from meas. example data.

Example)PRM209 Set value =(Error of shift angle 15 ° + Error of shift angle 20 ° + Error of shift angle degree 25 °)/3
 $(0.001+0.002+0.004)/3=0.0023=0.002$

Pitch error No.	PRM No.	Offset	Pitch error No.	PRM No.	Offset	Pitch error No.	PRM No.	Offset
1	208	0.000	9	216	+0.009	17	224	-0.013
2	209	+0.002	10	217	+0.006	18	225	-0.014
3	210	+0.005	11	218	+0.002	19	226	-0.014
4	211	+0.007	12	219	+0.001	20	227	-0.011
5	212	+0.009	13	220	0.000	21	228	-0.008
6	213	+0.013	14	221	-0.001	22	229	-0.006
7	214	+0.015	15	222	-0.005	23	230	-0.002
8	215	+0.012	16	223	-0.010	24	231	0.000

After compensating pitch error



4 Expansion Channel

4.1 Structure

The channel of controller changes the number of channels optionally and variably and it can set maximum 90 channels.

Maximum 1000 blocks of 1 channel can be set. Thus, the programs that cannot be created can also be stored.

However, the program storable block capacity of the controller is 2000 blocks. Thus, it is necessary to set the number of blocks so that the program blocks inside of all channels are within a total 2000-block.

The following shows the channel and block structure when the expansion channel is used.

Standard setting (before shipping)

CH00 : 500 blocks CH01 ~ CH15 : 100 blocks

		CH00		
CH01	CH02	CH03	CH04	CH05
CH06	CH07	CH08	CH09	CH10
CH11	CH12	CH13	CH14	CH15

One measured volume shows 100 blocks.

Expansion example 1

CH00 ~ CH09 : 50 blocks CH10 ~ CH13 : 250 blocks CH14 ~ CH23 : 50 blocks

CH00	CH01	CH02	CH03	CH04	CH05	CH06	CH07	CH08	CH09
		CH10					CH11		
		CH12					CH13		
CH14	CH15	CH16	CH17	CH18	CH19	CH20	CH21	CH22	CH23

One measured volume shows 50 blocks.

Expansion example 2

CH00 ~ CH01 : 1000 blocks

		CH00		
		CH01		

One measured volume shows 100 blocks.

As shown above, since the block capacity can be freely divided if blocks are within 2000 blocks, the block capacity can be used maximum by setting the blocks according to the program capacity.

4.2. Parameter setting

To use the expansion channel, it is necessary to set each parameter.

The parameter has the channel structure of expansion channel of use or change and program handling content, and block setting mode every channel.

4.2.1. Channel/block structure spec.

The channel/block structure specifications are set with PRM390 .
PRM390 is selected from the following specifications.

- 0 : CH00 : 500 blocks, CH01 ~ CH15 : 100 block structure
- 1 : When channel/block are optionally set, program check is performed.
- 2 : When channel/block are optionally set, program check is not performed.

Precautions

1. When the expansion channel is set, take care because old programs, etc., overflowed out of the channel are deleted. It is recommended to back up the programs before using the expansion channel.

4.2.1.1. PRM390=1

When this setting is performed and the following case occurs, $\text{Err.951 CH BLOCK SET ERROR}$ occurs.

- When blocks are reduced on newly setting, and existed blocks are more than a newly set value.
- When the newly set blocks exceed a total 2000-block.

When parameters on these conditions are stored and $\text{Err.951 CH BLOCK SET ERROR}$ occurs, any block is not changed.

4.2.1.2. PRM390=2

When this setting is performed and the following case occurs, the alarm is not displayed and the program is deleted.

- When the newly set program is less than the final program block, all blocks in the channel are deleted.
- When the newly set block is "0", its block is deleted together with the channel.

4.2.2. Block setting

The channels in case the expansion channel is used and the blocks used with the channel are set with parameters.

Parameters are a total of 90 parameters of PRM400 ~ PRM489. Each parameter corresponds to one by one of channels and the blocks used with its channel are set to the parameter.

To set parameters, the following conditions are required.

- The channel is to be used by a continuous number.
- The number of blocks is 1000.
- A total number of blocks is to 2000 blocks.

When these conditions are unsatisfied, a correct expansion channel is not set or any alarm occurs.

The comparison list for parameters and channels is as follows:

PRM No.		CH No.	PRM No.		CH No.	PRM No.		CH No.
PRM400	⇔	CH00	PRM430	⇔	CH30	PRM460	⇔	CH60
PRM401	⇔	CH01	PRM431	⇔	CH31	PRM461	⇔	CH61
PRM402	⇔	CH02	PRM432	⇔	CH32	PRM462	⇔	CH62
PRM403	⇔	CH03	PRM433	⇔	CH33	PRM463	⇔	CH63
PRM404	⇔	CH04	PRM434	⇔	CH34	PRM464	⇔	CH64
PRM405	⇔	CH05	PRM435	⇔	CH35	PRM465	⇔	CH65
PRM406	⇔	CH06	PRM436	⇔	CH36	PRM466	⇔	CH66
PRM407	⇔	CH07	PRM437	⇔	CH37	PRM467	⇔	CH67
PRM408	⇔	CH08	PRM438	⇔	CH38	PRM468	⇔	CH68
PRM409	⇔	CH09	PRM439	⇔	CH39	PRM469	⇔	CH69
PRM410	⇔	CH10	PRM440	⇔	CH40	PRM470	⇔	CH70
PRM411	⇔	CH11	PRM441	⇔	CH41	PRM471	⇔	CH71
PRM412	⇔	CH12	PRM442	⇔	CH42	PRM472	⇔	CH72
PRM413	⇔	CH13	PRM443	⇔	CH43	PRM473	⇔	CH73
PRM414	⇔	CH14	PRM444	⇔	CH44	PRM474	⇔	CH74
PRM415	⇔	CH15	PRM445	⇔	CH45	PRM475	⇔	CH75
PRM416	⇔	CH16	PRM446	⇔	CH46	PRM476	⇔	CH76
PRM417	⇔	CH17	PRM447	⇔	CH47	PRM477	⇔	CH77
PRM418	⇔	CH18	PRM448	⇔	CH48	PRM478	⇔	CH78
PRM419	⇔	CH19	PRM449	⇔	CH49	PRM479	⇔	CH79
PRM420	⇔	CH20	PRM450	⇔	CH50	PRM480	⇔	CH80
PRM421	⇔	CH21	PRM451	⇔	CH51	PRM481	⇔	CH81
PRM422	⇔	CH22	PRM452	⇔	CH52	PRM482	⇔	CH82
PRM423	⇔	CH23	PRM453	⇔	CH53	PRM483	⇔	CH83
PRM424	⇔	CH24	PRM454	⇔	CH54	PRM484	⇔	CH84
PRM425	⇔	CH25	PRM455	⇔	CH55	PRM485	⇔	CH85
PRM426	⇔	CH26	PRM456	⇔	CH56	PRM486	⇔	CH86
PRM427	⇔	CH27	PRM457	⇔	CH57	PRM487	⇔	CH87
PRM428	⇔	CH28	PRM458	⇔	CH58	PRM488	⇔	CH88
PRM429	⇔	CH29	PRM459	⇔	CH59	PRM489	⇔	CH89

4.2.2.1. Parameter setting examples

Example 1) PRM400(CH00)=1000 PRM401(CH01)=500 PRM402(CH02)=300

CH00				
CH01				
CH02			Empty area	

One measured volume shows 100 blocks.

Example 2) PRM400(CH00) ~ PRM489(CH89)=20

00	01	02	22	23	24
25	26	27	47	48	49
50	51	52	72	73	74
75	76	77	85	86	87	88	89	Empty area							

One measured volume shows 20 blocks.

Example 3) PRM400(CH00) ~ PRM401(CH01)=500 PRM402=0 PRM403=1000

CH00				
CH01				
		Empty area		

One measured volume shows 100 blocks.

This setting is performed, all blocks after setting PRM402=0 become invalid.

Example 4) PRM400(CH00) ~ PRM401(CH01)=1000 PRM402=1

When pushing **INPUT**, “ Err.951 CH BLOCK SET ERROR ” occurs.

Example 5) PRM400(CH00)=1000 PRM401(CH01)=1001

After inputting PRM401, (After pushing **ENT**) “ Err.950 PRM RANGE OVER ” occurs.

5 External Channel Selection

The program channel of controller can be selected by external input mode.

This external channel selecting methods are as follows:

- Binary mode (CH00 ~ max. CH15)
- M-signal mode (CH00 ~ max. CH89)

External channels can be changed when STATUS is STOP or RESET mode.

5.1 Binary mode

Binary is a binary number.

Each input signal is allocated to the digit of binary number and the program channel is selected by its combination.

When selecting the external channel by the binary, even if the expansion channel is set, only CH00 ~ max. CH15 can be selected. (The channels of CH16 or more cannot be selected.)

5.1.1.

Parameter setting

When the external channel is selected with the binary mode, set parameters as shown below.

PRM033=0 (External channel is selected by binary mode.)

PRM112=1 (External channel is selected.)

5.1.2.

External I/O signals

I/O signals relative to external channel selection of binary mode are as follows:

Input signals to show channel Nos.

- CHSEL0 Binary signal (2^0): B0
- CHSEL1 Binary signal (2^1): B1
- CHSEL2 Binary signal (2^2): B2
- CHSEL3 Binary signal (2^3): B3

INPUT signal changed to content selected with channel No.

- CHSET Channel Set

OUTPUT signal to show a channel No. change finish.

- BLKFIN Block finish signal

5.1.3. Binary list


CH NO.	B3	B2	B1	B0
	8	4	2	1
00				
01				
02				
03				
04				
05				

CH NO.	B3	B2	B1	B0
	8	4	2	1
06				
07				
08				
09				
10				
11				

CH NO.	B3	B2	B1	B0
	8	4	2	1
12				
13				
14				
15				

Mark shows INPUT state (ON).

5.1.4. Timing



External channel select INPUT signal is to be continuous 100msec., or more by considering the chattering.

External channel INPUT signal is to be continuous 500msec., or more by considering the chattering.

After inputting CHSET signal, FIN OUTPUT is to be started at 500msec.

BLK FIN OUTPUT time is to be time of PRM035.

Precautions

1. Channel does not change even if CHSET INPUT is turned ON, during BLKFIN and G99FIN OUTPUT.
2. When INPUT time of CHSET is 500msec or less, the channel does not change.
3. The timing to change the channel is after 500msec., from CHSEL INPUT start.

5.2. M-signal mode

Each INPUT signal adds the value one by one, adds/subtracts the value 10 by 10 and clears the value to 00. The program channel can be selected by their combination.

When the external channel is selected by the M-signal mode, CH00 ~ max. CH89 for the extension channel setting can be selected.

5.2.1.

Parameter setting

When the external channel is selected by M-signal mode, set the parameter as shown below:

PRM033=1 (External channel is selected by M-signal mode.)

PRM112=1 (External channel is selected.)

5.2.2.

External I/O signals

I/O signals relative to the external channel selection of M-signal mode are as follows:


Input signals to show the channel No.

- CHSEL0 ZERO Signal
Channel No. cleared to 0.
- CHSEL1 PLUS1 Signal
Channel No. added one by one.
- CHSEL2 PLUS10
Channel No. added ten by ten.
- CHSEL3 MINUS10
Channel No. subtracted ten by ten.

OUTPUT signal to show channel No. change finish.

- BLKFIN Block finish signal

5.2.3. Timing



An external channel select INPUT signal is to be continuous 100msec., or more by considering the chattering.

After inputting the external channel selection, FIN OUTPUT is to be started at 100msec.

Since a BLK FIN OUTPUT is turned OFF after checking the channel selection INPUT OFF, the time of PRM035 is not outputted.

Precautions

Channel does not change even if the external channel selection INPUT is ON during BLKFIN and G99FIN OUTPUT.

The channel does not change even if other channel is inputted during external channel selection input.

When the interval of 100msec or more is not checked after external channel selection OFF, the channel is not changed.

The timing to change the channel is after 100msec., from EXCHSEL INPUT start.

6. Over Travel

When an OVER TRAVEL signal 1 or 2 (OVRUN1, OVRUN2) detects an OVER TRAVEL state, an alarm No. 031 or 032 lights and this mode stops the control axis in emergency and immediately. The OVER TRAVEL is detected by a serial detecting method.

- Parallel detecting method (Standard)
- Serial detecting method

6.1. Parallel detecting method

OVRUN1 of over travel signal on + side and OVRUN2 on - side detect OVER TRAVEL (OT) individually. When OT is detected, + side or - side is checked by an input signal content.

As a result, during OT detection, error occurs even if a RESET button is pushed unless OT is released.

6.1.1.

Parameter setting

When the OVER TRAVEL is detected, parameters are set as follows:

PRM121=0 (Serial detecting method)


PRM206=1 (Contact spec. of OVRUN is to be B-contact.)

6.1.2.

OT Detection

When OVER TRAVEL 1 is detected during operation, Ⓔ Err.031 OVER TRAVEL + occurs and the machine stops in emergency by the dynamic brake. When OVER TRAVEL 2 is detected, Ⓔ Err.032 OVER TRAVEL - occurs and the machine stops in emergency by the dynamic brake similarly.

In case of parallel detecting method, the alarm is determined by detected INPUT signals (OVRUN1, OVRUN2) regardless of operational direction in over travel detection.



6.1.3

To release OVER TRAVEL

The safety direction when Ⓐ Err.031 OVER TRAVEL + occurs is usual “ - side” and the releasing method to the safety direction is as follows.

However, the table does not shift in “ + ” direction even if **INS** is pushed.

Set the mode to MANUAL.

Shift the table in “ - direction” with **DEL** of JOG key.

When JOG operation is performed, pushing **HI**, the table rotates at rapid traverse.

The safety direction when Ⓐ Err.032 OVER TRAVEL - occurs is usual “ + side” and the releasing method to the safety direction is as follows.

However, the table does not shift in “ - ” direction even if **DEL** is pushed.

Set the mode to MANUAL.

Shift the table in “ + direction” with **INS** of JOG key.

When JOG operation is performed, pushing **HI**, the table rotates at rapid traverse.

6.1.4.

Forcedly shifting method

When Ⓐ Err.031 OVER TRAVEL + occurs, the forced shift in + direction is as follows:

Set the mode to MANUAL.

When pushing **INS** with **OVR** pushed, the table shifts in “ + direction” of danger direction.

The forced shift of Ⓐ Err.032 OVER TRAVEL - is as follows:

Set the mode to MANUAL.

When pushing **DEL** with **OVR** pushed, the table shifts in “ - direction” of danger direction.

The feedrate when the forced shift is performed is fixed at 0.5min⁻¹.

Precautions

1. Do not use this forced shift mode usually.
Because this forced shift is performed in a danger direction, when performing the operation unavoidably, check that the table does not interfere or collide with any obstruction.

6.2 Serial detecting method

The plus (+) side and minus (-) side of OVER TRAVEL (OT) are determined by an operational direction in OT detecting with OVRUN1 of over travel signal.

For this reason, when resetting after detecting the alarm, the alarm is released once and the alarm occurs again in next operation.

6.2.1.

Parameter setting

When the OVER TRAVEL is detected, parameters are set as follows:

PRM121=1 (Serial detecting method)

PRM206=1 (Contact spec. of OVRUN is to be B-contact.)

6.2.2.

OT Detecting


During OVER TRAVEL 1 detecting, when the table rotates in + direction or has already been rotated, the alarm of 『 Err.031 OVER TRAVEL + 』 occurs and the table is stopped immediately by the dynamic brake.

During OVER TRAVEL 1 detecting, when the table rotates in - direction or has already been rotated, the alarm of 『 Err.031 OVER TRAVEL + 』 occurs.

Similarly, the table is stopped immediately by the dynamic brake.

If power is turned OFF during OT detecting, “ Err.031 ” or “ Err.032 ” is determined by a first actuation. T

When pushing **DEL** during OT detecting at + side, 『 Err.032 OVER TRAVEL - 』 occurs in reverse as usual travel. When pushing **INS** during OT detecting at - side, 『 Err.031 OVER TRAVEL + 』 occurs in reverse as usual travel. Therefore, release the over travel carefully.



In motion in figure, 『 Err.031 OVER TRAVEL + 』 occurs.

In motion in figure, 『 Err.032 OVER TRAVEL - 』 occurs.

6.2.3. To release OVER TRAVEL

The safety avoidance direction when 『 Err.031 OVER TRAVEL + 』 occurs is usual “ - side” and the releasing method to the safety avoidance direction is as follows.

However, the table does not shift in “ + ” direction even if **INS** pushed.

Push **[RESET]** button to reset Err.031.

Set the mode to MANUAL.

Shift the table in “ - direction” with **DEL** of JOG key.

When JOG operation is performed, pushing **HI**, the table rotates at rapid traverse.

The safety avoidance direction when 『 Err.032 OVER TRAVEL - 』 occurs is usual “ + side” and the releasing method to the safety avoidance direction is as follows.

However, the table does not shift in “ - ” direction even if **DEL** pushed.

Push **[RESET]** button to reset Err.032.

Set the mode to MANUAL.

Shift the table in “ + direction” with **INS** of JOG key.

When JOG operation is performed, pushing **HI**, the table rotates at rapid traverse.

6.2.4. Forcedly shifting method

When 『 Err.031 OVER TRAVEL + 』 occurs, the forced shift in + direction is as follows:

Push **[RESET]** to reset Err.031.

Set the mode to MANUAL.

When pushing **INS** with **OVR** pushed, the table shifts in “ + direction” of danger direction.

The forced shift of 『 Err.032 OVER TRAVEL - 』 is as follows:

Push **[RESET]** to reset Err.032.

Set the mode to MANUAL.

When pushing **DEL** with **OVR** pushed, the table shifts in “ - direction” of danger direction.

The feedrate when the forced shift is performed is fixed at 0.5min⁻¹.

Precautions

1. Do not use this forced shift mode usually.
Because this forced shift is performed in a danger direction, when performing the operation unavoidably, check that the table does not interfere or collide with any obstruction.

7. Data Communication

7.1. Data communication

Controller handles program data, parameter data, and WZERO position data.

To enable the management of these data, the controller is equipped to communicate with external equipment.

There are following two types of data communication.

- Data communication by controller function
The communication function of the controller enables “Program”, and “Parameter” to communicate with external equipment.
This function however communicates programs by channel, and do not handle WZERO position data communication.
- Data communication by private communication software: “UPDOWNLOAD”
This private communication software enables to communicate “Programs”, “Parameters”, and “WZERO position” to external equipment.
The functions of this software are as follows:
 - Batch communication of programs
 - Communication every channel in programs
 - Parameter communication
 - WZERO position communication
 - Batch communication of all data (programs, parameters, and WZERO position)

This private communication software enables to communicate data without various operations on the controllers.

For an exclusive communication software, refer to 『 Explanation for Exclusive Communication Software 』.

- KITAGAWA can offer the exclusive communication software optionally.

7.2. Program data communication using controller functions

This section explains the procedures for program input/output communications, with external equipment, using the communication functions in the controller.

7.2.1

Program input

This is to write a program from external equipment into a selected channel.



→ Push **MODE** to select “EDIT”.



[**]



→ Call out a desired channel to input a program.
(Only a channel number is displayed on the upper left of a screen.)



→ A screen to display the program INPUT mode appears.

CH05 IN PRG

(Example: CH05 program input mode)



→ Clear the program existing in the specified channel, by key-in: “CH** PRG DEL” is displayed.

Then, the screen to display a standby program INPUT mode is displayed.

CH05 IN 000

(Example: CH05 standby program input)

Data transmission from
external equipment

→ Program input ends when the block numbers are counted up from “000” to the last block number. The end is displayed on the screen.

CH05 IN END

(Example: CH05 program input ended)

Input the program to be transmitted in accordance with the data format explained in the later section of this instruction manual.

The indicating display remains until next key-in is performed.

Precautions

1. Previous program is lost at the beginning of program forwarding. Save program data backup before input operation.

7.2.2.**Interruption during program input**

This is to stop program input in process.



- Program input is interrupted, and the display goes back to original EDIT screen.

CH05 /A/G90A90.000
N000 F0 D J

(Example: EDIT screen for CH05)

The program forwarded is stored before the interruption.

Previous program is cleared at the beginning of program forwarding.

7.2.3.**Program output**

This is to output a program in a selected channel to an external equipment.

External equipment
standby for download

- Prepare the external equipment ready to receive transmitted data.



- Push **MODE** to select "EDIT".



[**]



- Call out a desired channel to transmit the program to. (Only a channel number is displayed on the upper left of a screen.)



- The screen to display the program output mode is displayed.

CH05 OUT PRG

(Example: CH05 program output mode)



- With the key-in, program output in the channel is executed, and the number of block being output is displayed as "CH** out 000".
The completion of program output is displayed on the screen.

CH05 OUT END

(Example: CH05 program output ended)

7.2.4.**Interruption during program output**

This is to stop program output in process.



- By pushing this key, program output is interrupted, and the display is put back to EDIT screen.

The programs forwarded to external equipment before the interruption are outputted.

7.3. Communicating parameter data using controller

This section explains the procedures for parameter input/output communications, with external equipment, using the communication function equipped on the controller.

7.3.1.

Parameter input

This is to write parameters from an external equipment.

Emergency stop state → Push emergency stop button, or input external emergency stop command to bring emergency stop state.



→ Push **MODE** to select “PARAM”.



→ Set “999” to PRM110 to bring all parameter rewritable state.



→ The status is displayed being parameter input mode.

PARAMETER IN

(Parameter input mode)



→ The display shows the state being in the parameter download standby state.

PRM IN 000

(Parameter input standby)

Data transmission from external equipment

→ When the parameter numbers are counted up from “000” to the last number, the parameter input ends, and the display prompts to turn the power off.

**PRM IN END
POWER OFF**

(Parameter input ended)

Input the program to transmit according to the data format explained in the later section of this instruction manual.

Key in **INPUT** after parameter input is not necessary.

Precautions

1. Previous parameters are overwritten at the beginning of parameter forwarding. Save parameter data backup before input operation.
2. After rewriting the parameters, turn off the power and reboot.

7.3.2. Interruption during parameter input

This is to stop parameter input in process.



- Parameter input is interrupted, and stops with contents and number at the time of interruption displayed.

PRM IN 123

(Example: Interrupted at PRM123 being input)

The parameters forwarded before the interruption are replaced.

Even in case of Interruption, “Err.091 POWER OFF PRM” is displayed, therefore, proceed with power off operation.

Inputting **INPUT** after parameter input is unnecessary.

The display indicating the interruption of input remains until any key other than **CAN** is pushed

7.3.3. Parameter output

This is to write parameter from external equipment.

External equipment
standby for data
download

- Prepare the external equipment standby for communication data download.



- Push **MODE** to select “PARAM”.



- On the screen, the state being in the parameter output mode is indicated.

PARAMETER IN

(Parameter output mode)



- When parameter output is started and parameter numbers are counted up to the last number, then parameter output end is displayed on the screen.

PRM OUT END

(Parameter output ended)

7.3.4. Interruption during parameter output

This is to stop parameter output in process.



- By pushing this key, parameter output is interrupted, and the display is put back to PRM110 screen.


The parameters forwarded to the external equipment before the interruption are output.

7.4. Communication data format

This section shows data formats for data transmission using the communicating function of the controller.

7.4.1. Program data


The program data format is as follows.



- ① % Code to denote the data begin here
- ② CRLF Linefeed code
- ③ CH01 Channel data
- ④ N000G90··· Program data
- ⑤ % Code to denote the data end here

7.4.2. Parameter data

The parameter data format is as follows.



- ① % Code to denote the data begin here
- ② CRLF Linefeed code
- ③ P000A01··· Parameter data
- ④ % Code to denote the data end here

MAINTENANCE MANUAL

■ Readers for This Manual

Readers for this manual are as follows:

- Persons who adjust trial run or servo adjustment
- Persons who adjust parameters
- Persons who perform maintenance work

C o n t e n t s

1	Alarms	I1-1
1.1.	KINDS OF ALARMS	I1-1
1.2.	ALARM LIST	I1-2
1.2.1.	Alarm rank 0	I1-2
1.2.2.	Alarm rank 2	I1-4
1.2.3.	Alarm rank 8.....	I1-5
1.2.4.	Alarm rank 9	I1-6
1.2.5.	Servo alarm	I1-7
1.3.	ALARM CAUSES AND COUNTERMEASURES	I1-10
2	RAM Clear	I2-1
2.1.	ALL DATA CLEAR OF PROGRAMS AND PARAMETER DATA	I2-2
2.2.	ALL DATA CLEAR OF PROGRAMS	I2-3
2.3.	ALL DATA CLEAR OF PARAMETER	I2-4
2.4.	INITIALIZATION OF SYSTEM INFORMATION	I2-5
3	Adjustment	I3-1
3.1.	SERVO ADJUSTMENT	I3-1
3.2.	BRIGHTNESS CONTROL OF PENDANT LCD	I3-2
4	The battery for absolute encoders	I4-1
3.1.	SPECIFICATION	I4-1
3.2.	EXCHANGE	I4-2

1 Alarms


1.1 Kinds of alarms

Alarms are classified in different ranks. Each rank has different operation programs and different halt conditions.

Alarm Rank	C o n t e n t
0	Alarm rank 0 is an extremely high emergency alarm. When Alarm 0 is indicated, the servo stops right away and operation also stops. When turning on the power switch, internal check is performed. If the result is not satisfactory, alarm occurs. When this alarm is indicated, servo is not turned ON. Reset or turn on the power switch after an adjustment is made. If everything goes normal, then alarm will not occur.
2	This alarm occurs during the program execution. When this alarm is indicated, the circular table and the program stop. Servo does not stop.
8	This alarm occurs when a failure happens during data communications or execution of remote control. If this alarm occurs, communication is terminated. In case of the remote control, program will not be executed.
9	The alarm occurs when the program content, program area or program data is incorrect.
No Rank	When alarm occurs regarding the servo, the same error number as the servo pack is indicated regardless of the alarm rank.

An alarm is displayed in three digits consisting of numeric and the alphabet characters.

The first digit indicates the alarm rank, and the following two digits indicate the kind of the alarm.



1.2. Alarm list

1.2.1.

Alarm rank 0

Alarm No.	Alarm Content Alarm Message	Release	Page
001	Emergency stop EMERGENCY STOP	RESET	I1-10
002	External emergency stop EXT EMERGENCY SP	RESET	I1-10
003	Abnormal temperature in controller ABNORMAL TEMP	RESET	I1-10
008	Watch dog time out WATCHDOG	Power OFF	I1-10
016	Brake failure BRAKE FAILURE	RESET	I1-28
019	Positioning deviation over in braking POS-DEV OVER CL	Power OFF	I1-11
020	Brake clamp positioning deviation waiting POS-DEV WAIT CL	RESET	I1-11
021	ST signal alarm ST SIGNAL ALARM	RESET	I1-11
023	SP signal alarm SP SIGNAL ALARM	RESET	I1-11
024	ZERO pulse waiting ZERO-PULS WAIT	RESET	I1-11
031	Over travel + OVER TRAVEL+	RESET	I1-12
032	Over travel - OVER TRAVEL-	RESET	I1-12
080	EEPROM writing error EEPROM WRITE ERR	RESET	I1-12
082	EEPROM clear error EEPROM CLEAR ERR	RESET	I1-12
083	EEPROM address G, CH writing error EEPROM G/CH ERR	RESET	I1-13
084	EEPROM address J writing error EEPROM J ERR	RESET	I1-13
085	EEPROM address P/F writing error EEPROM P/F ERR	RESET	I1-13
086	EEPROM address D/E writing error EEPROM D/E ERR	RESET	I1-13
087	EEPROM address A/L writing error EEPROM A/L ERR	RESET	I1-13
089	EEPROM check error EEPROM CHECK ERR	Power OFF	I1-13

Alarm No.	Alarm Content	Release	Page
	Alarm Message		
090	NC pulse CPU connection time out	RESET	I1-13
	NC PLS CPU TIMOUT		
091	Power OFF alarm	Power OFF	I1-13
	POWER OFF ALARM		
092	Power ON error	Power OFF	I1-14
	POWER ON ERROR		

1.2.2.

Alarm rank 2

Alarm No.	Alarm Content Alarm Message	Release	Page
200	External ZRN input WZERO specification error ZRN WZERO ERROR	RESET	I1-14
201	WZRN alarm WORK ZRN ALARM	RESET	I1-14
202	Stack underflow STACK UNDERFLOW	RESET	I1-14
203	Stack overflow STACK OVERFLOW	RESET	I1-14
204	Not return alarm NOT RETURN ALARM	RESET	I1-14
205	Positioning time over POS TIME OVER	RESET	I1-14
207	Divide command (DIV) error DIVIDE CMD ERROR	RESET	I1-15
208	G27 data 0 error G27 DATA0 ERROR	RESET	I1-15
209	G27 P>E Error G27 P>E ERROR	RESET	I1-15
210	F data error F DATA ERROR	RESET	I1-15
213	Software limit + SOFTWARE LIMIT+	RESET	I1-15
214	Software limit - SOFTWARE LIMIT-	RESET	I1-15
215	Zero return alarm MZRN INPUT ERROR	RESET	I1-15
216	Angle error in absolute command ANGLE ERROR IN ABS	RESET	I1-15
217	G99FIN time out G99FIN TIME-OUT	RESET	I1-16
218	Channel set alarm CHANNEL SET ALARM	RESET	I1-16
219	External mode selection error EXT MODE SEL ERROR	RESET	I1-16
230	G09 execution axis error ILLEGAL G09	RESET	I1-16

1.2.3.

Alarm rank 8

Alarm No.	Alarm Content Alarm Message	Release	Page
800	Address error NC ADDRESS ERROR	RESET	I1-16
801	NC axis command error NC AXIS ERROR	RESET	I1-16
803	NC set range error NC SET RANGE OVER	RESET	I1-16
804	NC channel number error NC CHANNEL ERROR	RESET	I1-17
805	NC block number error NC BLOCK NO. ERROR	RESET	I1-17
808	NC command error NC COMMAND ERROR	RESET	I1-17
820	RS232C Hardware alarm RS232C H/W ALARM	RESET	I1-17
826	Flaming alarm FLAMING ALARM	RESET	I1-17
827	Parity alarm PARITY ALARM	RESET	I1-17
851	Illegal command alarm ILLEGAL CMD ALARM	RESET	I1-17
852	No command alarm NO COMMAND ALARM	RESET	I1-17
853	Illegal G-code, address alarm ILLEGAL G/ADD	RESET	I1-17
854	Over-run alarm OVER-RUN ALARM	RESET	I1-18
855	Command receiving disable mode CMD ILLEGAL MODE	RESET	I1-18

1.2.4.

Alarm rank 9

Alarm No.	Alarm Content	Release	Page
	Alarm Message		
901	EEPROM Program area error	RESET	I1-18
	EEPROM PROG ERROR		
911	Parameter input error	RESET	I1-18
	PRM INPUT ERROR		
930	Program channel number input error	RESET	I1-18
	PROG CH ERROR		
931	Block number input error	RESET	I1-18
	PROG BLOCK ERROR		
940	Program G-code input error	RESET	I1-18
	PROG G ERROR		
941	Program J-address input error	RESET	I1-19
	PROG J ERROR		
942	Program F-address input error	RESET	I1-19
	PROG F ERROR		
943	Program P-address input error	RESET	I1-19
	PROG P ERROR		
944	Program A -address input error	RESET	I1-19
	PROG A ERROR		
945	Program L -address input error	RESET	I1-19
	PROG L ERROR		
946	Program D-address input error	RESET	I1-19
	PROG D ERROR		
947	Program E-address input error	RESET	I1-19
	PROG E ERROR		
950	Parameter range over	RESET	I1-19
	PRM RANGE OVER		
951	CH block variable change error	RESET	I1-19
	CH BLOCK SET ERROR		
952	Block set error	RESET	I1-19
	BLOCK SET ERROR		
961	EDIT Block copy error	RESET	I1-19
	BLOCK INS ERROR		
962	EDIT Illegal G-code	RESET	I1-20
	EDIT ILLEGAL G		

1.2.5.

Servo alarm

Alarm No.	Alarm Content Alarm Message	Release	Page
020	Parameter destruction PRM DESTRUCT	Released by servo.	I1-21
030	Main circuit detection error MC PDE ERROR	Released by servo.	I1-21
040	Parameter setup error PRM SETUP ERROR	Released by servo.	I1-21
041	Dividing pulse output set error PG PLS SET ERROR	Released by servo.	I1-21
050	Combination error COMBINATION ERROR	Released by servo.	I1-21
100	Over current or overheat of heat sink OVER CURRENT	Released by servo.	I1-21
300	Regenerative error REGENERATIVE ERROR	Released by servo.	I1-21
320	Regenerative overload REGENERATIVE OL	Released by servo.	I1-22
330	Main circuit power source wiring error MAIN CIRCUIT ERR	Released by servo.	I1-22
400	Over voltage OVER VOLTAGE	Released by servo.	I1-22
410	Under voltage UNDER VOLTAGE	Released by servo.	I1-22
510	Over speed OVER SPEED	Released by servo.	I1-22
511	Dividing pulse output speed PLS OUT SPEED	Released by servo.	I1-22
520	Vibration alarm VIBRATION ALARM	Released by servo.	I1-23
710	Over load (Momentary maximum load) OL(FLASHMAX)	Released by servo.	I1-23
720	Over load (Continuous maximum load) OL(RATINGMAX)	Released by servo.	I1-23
730	DB Over load DB OVERLOAD	Released by servo.	I1-23
740	Inrush current limit resistance overload INRUSHRESOL	Released by servo.	I1-23
7A0	Heat sink overheat HEATSINK HEATING	Released by servo.	I1-23
810	Encoder backup alarm ENC BACKUP ALARM	Released by servo.	I1-24
820	Encoder same check alarm ENC SAMECHK ALARM	Released by servo.	I1-24

Alarm No.	Alarm Content Alarm Message	Release	Page
830	Encoder battery alarm ENC BATTERY ALARM	Released by servo.	I1-24
840	Encoder data alarm ENC DATA ALARM	Released by servo.	I1-24
850	Encoder over speed ENC OVER SPEED	Released by servo.	I1-24
860	Encoder overheat ENC OVER HEAT	Released by servo.	I1-25
B10	Speed command A/D error V-REF A/D ERROR	Released by servo.	I1-25
B20	Torque command A/D error T-REF A/D ERROR	Released by servo.	I1-25
B31	Current detection alarm 1 CURRENT DET ALM1	Released by servo.	I1-25
B32	Current detection alarm 2 CURRENT DET ALM2	Released by servo.	I1-25
B33	Current detection alarm 3 CURRENT DET ALM3	Released by servo.	I1-25
BF0	System alarm SYSTEM ALARM0	Released by servo.	I1-25
BF1	System alarm 1 SYSTEM ALARM1	Released by servo.	I1-25
BF2	System alarm 2 SYSTEM ALARM2	Released by servo.	I1-25
BF3	System alarm 3 SYSTEM ALARM3	Released by servo.	I1-25
BF4	System alarm 4 SYSTEM ALARM4	Released by servo.	I1-25
C10	Burn-up check detection BURN-UP CHKDET	Released by servo.	I1-25
C80	Encoder clear error ENC CLEAR ERROR	Released by servo.	I1-26
C90	Encoder communication error ENC COMMUNI ERROR	Released by servo.	I1-26
C91	Encoder communication position data acceleration error ENC COM POS ERROR	Released by servo.	I1-26
C92	Encoder communication timer error ENC COM TIME ERROR	Released by servo.	I1-26
CA0	Encoder parameter error ENC PRM ERROR	Released by servo.	I1-26
CB0	Encoder echo back error ENC ECHOBACK ERROR	Released by servo.	I1-26
CC0	Multi-limit mis-compare MULT LM MISCOMPARE	Released by servo.	I1-26

Alarm No.	Alarm Content	Release	Page
	Alarm Message		
D00	Positioning deviation Over	Released by servo.	I1-27
	POS-DEV OVER		
D01	Servo OFF positioning deviation over	Released by servo.	I1-27
	SV OFF POS-DEV OVER		
D02	Servo ON positioning deviation over	Released by servo.	I1-27
	SV ON POS-DEV OVER		
F10	Power line open-phase	Released by servo.	I1-27
	PSUNACTIVATED		
F20	Motor cable disconnection	Released by servo.	I1-27
	MOTOR DISCONNECTION		
CPU00	Main CPU communication error	Released by servo.	I1-27
	MAIN COMMUNI ERROR		
400	Machine zero position unset	Released by servo.	I1-27
	MZERO POS UN-SETUP		

Though there is a case that the servo alarm is the same as other alarm No., this trouble occurs because of the alarm numbers that occur by the controller and the servo amplifier. In this case, check the alarm conditions by the alarm message contents.

1.3. Alarm causes and countermeasures

Err.No.	Description of alarm	Details
	Cause	Countermeasures
001	Emergency stop	Emergency stop input is checked.
	1. Emergency stop button on the panel is pushed. If alarm occurs when emergency stop button is not pushed, the causes are as shown below. 2. The contact point of the emergency stop button is broken. 3. The emergency stop cable in the controller is broken.	1. Check the safety around the area and release the emergency stop. Turn the emergency stop button clockwise to release it. 2. Replace the emergency stop button. 3. Replace the cable.
002	External emergency stop	Emergency stop is inputted from outside.
	1. Emergency stop is inputted from outside. 2. CB3 cable is broken. 3. The contact point for the external output on the other machine is opened (operational defect).	1. Check the safety around the area and release the external emergency stop. 2. Replace the CB3 cable. 3. Refer to the manufacturer of the machine.
003	Abnormal temperature in controller	The surface temperature of the main board exceeds 60 °C.
	1. The ambient temperature exceeds 45 °C. 2. Cooling fan stops because of clogging. 3. Exposed to direct sunlight. 4. The main board is heated remarkably. 5. Temperature sensor fails.	1. Shift the controller to well-ventilated location. 2. Replace the cooling fan. Clean or replace the filter. 3. Shut the sunlight or shift the controller in the shade. 4-1. Lower the feedrate. 4-2. Increase the constant during acceleration. 5. Replace the controller of the main board.
008	Watch dog time out.	The watch dog circuit triggers to check CPU's normal operation.
	1. Noise 2. Thunder	Turn ON the power. If the alarm occurs frequently, The internal circuit may be damaged. Contact with Kitagawa's Serviceman or your agent. Replace the controller with a new one..
016	Brake failure	The brake is damaged.
	See the detailed alarm clause for Err.016	

Err.No.	Description of alarm	D e t a i l s
	C a u s e	C o u n t e r m e a s u r e s
019	Droop over in braking	The motor starts rotation by an external force during clamping, exceeding the set value.
	<ol style="list-style-type: none"> 1. Air pressure is low. 2. Heavy cutting is performed. 3. The set value of the parameter is small. 4. Overshooting occurs because the inertia of jig, etc., is large. 	<ol style="list-style-type: none"> 1. Raise the air pressure. 2-1. Lower the cutting speed of the machine. 2-2. Reduce the amount of cutting. 3. Raise the set value of PRM015. 4-1. Servo adjustment. 4-2. Lower the feedrate.
020	Brake clamp droop waiting	The parameter does not become less than set value even if 5 seconds elapses after the distribution is finished.
	<ol style="list-style-type: none"> 1. Overload. 2. The set value of the parameter is small. 	<ol style="list-style-type: none"> 1. Reduce the load. 2. Make the set value for PRM015 higher.
021	ST Signal alarm	ST signal is not turned off when more than 5 seconds passed since the power gets ON.
	<ol style="list-style-type: none"> 1. Start input is kept ON at external equipment. 2. ST and INCOM are short-circuited. 	<ol style="list-style-type: none"> 1. Release the status that keeps the starting input. 2. Replace the cable CB3 if the cable is incorrect.
023	SP Signal alarm	SP signal is not turned ON when more than 5 seconds passed since the power gets ON.
	<ol style="list-style-type: none"> 1. Stop input is kept ON at external equipment. 2. SP cable is broken. 	<ol style="list-style-type: none"> 1. Release the status that keeps the stop input. 2. Replace the cable CB3.
024	ZERO pulse waiting	Zero pulse is not checked in MZRN even if the table rotates by the constant angular.
	<ol style="list-style-type: none"> 1. The acceleration constant is small. 2. CB1 cable is broken. 3. Motor encoder is incorrect. 	<ol style="list-style-type: none"> 1. Raise the acceleration constant. 2. Replace CB1 cable. 3. Replace the motor.

Err.No.	Description of alarm	D e t a i l s
	C a u s e	C o u n t e r m e a s u r e s
031 032	<p>Over travel + Over travel -</p> <p>1. Over travel is detected. (The machine is positioned at O T)</p> <p>Though machine is not in OT position, when alarm occurs, the following problems are considered.</p> <p>2. The detect switch for over travel is out of order.</p> <p>3. The cable for over travel is incorrect.</p> <p>4. Parameter setting is inadequate.</p>	<p>Hard limit + side is detected. Hard limit - side is detected.</p> <p>1-1. Release the over travel with the following procedure when an alarm is detected during table rotation. After reset, set mode to MANUAL. In case of Err.031, push DEL key to shift table to the location where over travel is released. In case of Err.032, use INS key for the same procedure.</p> <p>In case of Err.031、 032, in order to avoid collision, single use of DEL or INS key can not rotate table to the direction of the collision.</p> <p>1-2. When shifting table in direction other than escape direction even if alarm is detected, release OT according to the following procedure. After resetting and set mode to MANUAL. In case of Err.031, push OVR + DEL keys to rotate the table to the location where over travel is released. In case of Err.032, use OVR + INS keys for the same procedure.</p> <p><u>Because the table is rotated forcedly by pushing OVR key, take extreme care to release OT.</u> For safety reasons, rotation speed is set at 0.5min⁻¹ in the collision direction.</p> <p>2. Replace the over travel detecting switch.</p> <p>3. Replace the cable.</p> <p>4. Recheck and change PRM206.</p>
080	<p>EEPROM Writing error</p> <p>1. An inconsistency is identified by checking after EEPROM WRITE.</p>	<p>An error occurs on EEPROM check in power ON.</p> <p>1-1. Reset or turn ON power again. 1-2. Clear RAM if it is not released by power recharge.</p>
082	<p>EEPROM clear error</p> <p>1. An inconsistency identified by checking after the content of EEPROM is erased.</p>	<p>An error occurs during an EEPROM check in power ON.</p> <p>1-1. Reset or turn ON power again. 1-2. Clear RAM if it is not released by power recharge.</p>

Err.No.	Description of alarm	D e t a i l s
	C a u s e	C o u n t e r m e a s u r e s
083	EEPROM address G, CH writing error	An error occurs during EEPROM check in power ON.
	<ol style="list-style-type: none"> After EEPROM writing, a check mode indicates that the data of address G is inadequate. The memorized channel number is not valid. 	<ol style="list-style-type: none"> Reset or turn ON power again. Clear RAM if it is not released by power recharge.
084	EEPROM address J writing error	An error occurs during EEPROM check in power ON.
	<ol style="list-style-type: none"> After EEPROM writing, a check mode indicates that the data of address J is inadequate. 	<ol style="list-style-type: none"> Reset or turn ON power again. Clear RAM if it is not released by power recharge.
085	EEPROM address P/F writing error	An error occurs during EEPROM check in power ON.
	<ol style="list-style-type: none"> After EEPROM writing, a check mode indicates that the data of address P/F is inadequate. 	<ol style="list-style-type: none"> Reset or turn ON power again. Clear RAM if it is not released by power recharge.
086	EEPROM address D/E writing error	An error occurs during EEPROM check in power ON.
	<ol style="list-style-type: none"> After EEPROM writing, a check mode indicates that the data of address D/E is inadequate. 	<ol style="list-style-type: none"> Reset or turn ON power again. Clear RAM if it is not released by power recharge.
087	EEPROM address A/L writing error	An error occurs during EEPROM check in power ON.
	<ol style="list-style-type: none"> After EEPROM writing, a check mode indicates that the data of address A/L is inadequate. 	<ol style="list-style-type: none"> Reset or turn ON power again. Clear RAM if it is not released by power recharge.
089	EEPROM check error	An error occurs during EEPROM check in power ON.
	<ol style="list-style-type: none"> An inconsistent or incorrect data is detected during EEPROM check in power ON. 	<ol style="list-style-type: none"> Turn ON power again. Clear RAM if it is not released by power recharge.
090	NC pulse CPU connection time out	A failure occurs in data communications between the main CPU and the target CPU.
	<ol style="list-style-type: none"> A failure in data communications 	<ol style="list-style-type: none"> Reset.
091	Power OFF alarm	<ol style="list-style-type: none"> Parameter that requires power distribution is changed.
	<ol style="list-style-type: none"> Parameter that requires power distribution is changed. Parameter is inputted from outside equipment. 	<ol style="list-style-type: none"> Turn ON power again.

Err.No.	Description of alarm	Details
	Cause	Countermeasures
092	Power ON error	Data fetching fails in power ON.
	1. Data fetching fails in power ON.	1. Reset or turn ON power again.
200	External ZRN input WZERO specification error	WZRN is commanded with EXT ZRN INPUT before determining MZERO position.
	1. WZRN is commanded at the state of NOT READY (PRM123=0)	1. Determine the MZERO position before commanding to WZRN
201	WZRN alarm	Command is issued by WZERO key or through communication to WZRN before determining MZERO position.
	1. WZRN is commanded at the state of NOT READY (PRM123=0).	1. Determine the MZERO position before commanding to WZRN
202	Stack underflow	Program error
	1. Subroutine return is executed at J-1 without subroutine call.	1. Check and correct the program.
203	Stack overflow	Program error
	1. Nesting exceeds 8 while repeating G27. 2. Jump command is executed during subroutine call.	1,2. Check and correct the program.
204	Not return alarm	Program error
	1. Return command is not executed at the final block when subroutine call is executed at the address J.	1. Check and correct the program.
205	Positioning time over	Deviation amount does not become smaller than the set value for PRM010 within the duration set at PRM009 after distribution is finished while droop check is valid.
	1. Overloading. 2. The set time for droop check (PRM009) is short. 3. The set amount of droop check (PRM010) is small.	1. Reduce the load. If speed cannot be reduced within the acceleration time, servo adjustment is required. 2. Make the droop check set time larger than acceleration time. 3. Make the droop check set amount larger.

Err.No.	Description of alarm	Details
	Cause	Countermeasures
207	Divide command (DIV) error	Divide command value is incorrect.
	1. Processed angular value of divide command becomes 0.001 ° or less.	1. Command angular / divide (DIV) <0.001 °
208	G27 data 0 data error	The values of address P, E, L are inadequate when G27 is executed.
	1. Any of the addresses P, E, L is set to zero, or is not set at all when G27 is executed.	1. Check and correct the program.
209	G27 P>E error	The relation between the addresses P and E at G27 is inadequate.
	1. The value of the address P is larger than the address E when G27 is executed.	1. Check and correct the program.
210	F data error	Rev. speed is not set during the program.
	1. Rev. speed is not commanded to the address F when the program is executed.	1. Check and correct the program.
213 214	Software limit +	Current position or the reached position exceeds the limited area.
	Software limit -	
	1. Manual operation exceeds the software limit (PRM103) for normal motion when PRM100=1 or 2.	1 ~ 4
	2. Automatic operation exceeds the software limit (PRM103) for normal motion when PRM100= 2.	Correct the value of the parameter if PRM101 and PRM103 are in adequate.
	3. Manual operation exceeds the software limit (PRM101) for reverse motion when PRM100=1 or 2 .	1 , 3
	4. Automatic operation exceeds the software limit (PRM103) for reverse motion when PRM100= 2.	Perform manual operation with a great care.
	5. Main board's fails.	2 , 4
215	Zero return alarm	Over travel signal and ZRN deceleration signal are inputted simultaneously in ZRN.
	1. Cable is broken or short-circuited. 2. Wrong wiring.	1. Replace the cable. 2. Correct the wiring.
216	Angle error in ABS	Program error.
	1. Angular command is issued for more than 360 when an absolute command is in effect.	1. Check and correct the program.

Err.No.	Description of alarm	D e t a i l s
	C a u s e	C o u n t e r m e a s u r e s
217	G99FIN time out	G99 check signal for handshake does not turn ON within the designated duration.
	<ol style="list-style-type: none"> 1. G99 check signal is not detected within the set time for PRM028 when PRM027=1 2. Either PRM028 is zero, or PRM029 is other than 2, when PRM027=1.(determined during automatic operation) 	<ol style="list-style-type: none"> 1. See if G99FIN circuit functions properly. 2. Check and correct the parameter.
218	Channel set alarm	When channel select is executed at binary mode after CHSET input, wrong channel is selected.
	<ol style="list-style-type: none"> 1. Channel setting becomes inadequate when external channel is changed. 2. Channel number is not displayed when program is transferred. 	<ol style="list-style-type: none"> 1. Replace the controller (main board). 2. Check the transfer content and send normal data.
219	External mode selection error	Input of the both external signals, AUTOSET and MANUALSET are detected.
	<ol style="list-style-type: none"> 1. Wiring of AUTOSET or ANUALSET is short-circuited. 	<ol style="list-style-type: none"> 1. Check and correct the circuit of AUTOSET and MANUALSET. Replace the cable when CB3 cable is incorrect.
230	G09 execution axis error	Program error.
	<ol style="list-style-type: none"> 1. In the case of 2-axis controller, the axes that were not used for G08 command are used for G09 command. 	<ol style="list-style-type: none"> 1. Check the program and correct them so that the same axes as used for G08 command are used for G09 command.
800	Address error	The transfer program is inadequate.
	<ol style="list-style-type: none"> 1. The display shows other than /A/ nor /B/ when program is transferred. 2. An address that does not exist is transferred. 3. NC program is not enclosed with / or [] when remote controlled. 	<ol style="list-style-type: none"> 1,2. Check the transfer content and send normal data. 3. Check the content of the remote program command and send normal data.
801	NC axis command error	The transfer program is inadequate.
	<ol style="list-style-type: none"> 1. /A/ or /b/ is displayed on the NC program transferred through remote control single-axis specification. 2. The letter behind / is not A,B,/ or [. 	<ol style="list-style-type: none"> 1,2. Check the transfer content and send normal data.
803	NC set range over	The transfer program is inadequate.
	<ol style="list-style-type: none"> 1. The set value of the NC program address is wrong when automatic operation is performed. 	<ol style="list-style-type: none"> 1. Check the address of the sending program and send normal data.

Err.No.	Description of alarm	D e t a i l s
	C a u s e	C o u n t e r m e a s u r e s
804	NC channel number error	The transfer program is inadequate.
	1. NC program channel number is wrong when automatic operation is performed.	1. Check the channel number of the sending program and send normal data.
805	NC block number error	The transfer program is inadequate.
	1. NC program block number is wrong, when automatic operation is performed	1. Check the block number of the sending program and send normal data.
808	NC command error	Program error.
	1. G code that became failure because of the internal processing, is executed.	1. Reset the failure.
820	RS232C Hardware alarm	Communication failure
	1. The top of the host command is not DC2.	1,2. Transfer the control code of XON/XOFF at a normal state.
	2. The end of the host command is not DC4.	
	3. The message received in the host connection exceeds 256 characters.	3. Make a communication data consisting of 256 characters or less.
826	Flaming alarm	Communication failure
	1. Transfer speed of RS232C does not correspond to the controller.	1. Make the communication protocol corresponding to it on controller side.
827	Parity alarm	Communication failure
	1. Parity bit of the transfer data for RS232C does not correspond to the controller.	1. Make the communication protocol corresponding to it on controller side.
851	Illegal command alarm	Transfer command of the remote control (RC) is wrong.
	1. Received a host command that does not correspond with RC.	1. Check the transfer command on the machine, and send a correct command.
852	No command alarm	Transfer command of the remote control (RC) is wrong.
	1. Received STT, STA and STB command when no program exists in CH99 at RC	1. Check the transfer command on the machine, and send a correct command.
853	Illegal G-code, address alarm	Received the remote control (RC) code incorrectly.
	1. Addresses that do not correspond with G code (A,D,F,...) exist.	1 ~ 3.
	2. Received G code that does not exist at RC.	Check the transfer command on the machine, and send a correct command.
	3. Received an address J at RC.	

Err.No.	Description of alarm	Details
	Cause	Countermeasures
854	Over-run alarm	Internal error
	1. Receiving buffer is full.	1. Reset failure.
855	Command receiving disable mode	Remote control (RC) mode is wrong.
	1. Neither AUTO nor SINGLE mode is selected when receiving a host command to order an operation.	1. Select AUTO or SINGLE mode when executing remote control.
901	EEPROM program area error	Program EDIT is wrong.
	1. Block copy is executed at the final block.	1. Block copy cannot be executed at the final block. Use an expansion channel if the number of blocks in the channel is not enough.
911	Parameter input error	Remote control mode is wrong.
	1. INPUT key is pushed regardless of parameter CHANGE or UNCHANGE in PARAM mode when PRM110 is not 1, or PRM110 is not 999.	2. Set PRM110 at 1 or 999 when changing the parameter.
930	Program channel number input error	Selected the channel number that cannot be selected.
	1. Selected the channel the block number of which is 0.	1. The channel the parameter of which is 0 cannot be selected for PRM400 ~ PRM489.
931	Program block number input error	Selected the block number that cannot be selected.
	1. Selected a block number that does not exist.	1. Block numbers higher than set value for PRM400 ~ PRM489 cannot be selected.
940	Program G-code input error	The set value for Program G-code is wrong.
	1. Input a wrong value for program G code. 2. G-code in the sending program through communication is wrong.	1. Input an adequate value for G-code. 2. Check the transfer content program and send normal data.

Err.No.	Description of alarm	D e t a i l s
	C a u s e	C o u n t e r m e a s u r e s
941	Program J-address input error	The set value for J code in the program is wrong.
942	Program F-address input error	The set value for F code in the program is wrong.
943	Program P-address input error	The set value for P code in the program is wrong.
944	Program A-address input error	The set value for A code in the program is wrong.
945	Program L-address input error	The set value for L code in the program is wrong.
946	Program D-address input error	The set value for D code in the program is wrong.
947	Program E-address input error	The set value for E code in the program is wrong.
	1. Input the wrong value for the program address. 2. The address in the sending program through communication is wrong.	1. Input a right value for the address. 2. Check the transfer content program and send normal data.
950	Parameter range over	Attempted to set an incorrect value to the parameter set area.
	1. A wrong value is set for the parameter.	1. Input the value settable in the parameter range
951	CH block variable change error	An internal error
	1. The total number of the blocks exceeds 2000 when PRM390 is not 0. 2. Program must be deleted when PRM390 is set to 1.	1. Set the total number of blocks at 2000 or less. 2. Backup the program if existing program is necessary. Set PRM390=2 if the program is not necessary.
952	Block set error.	Wrong blocks are selected when setting an extension channel.
	1. The setting of the number of blocks in CH00 is 0 when PRM390 is not 0. 2. When the channels used for CH00 ~ CH89 are not continuous.	1. When PRM390 is not 0, 0 cannot be set for CH00. 2. Set the blocks to PRM400 ~ PRM489 of continuous channels.
961	EDIT block copy error	A failure occurs in an automatic generation of block numbers such as jump command during copying blocks.
	1. The starting block for G27 falls on the final block. 2. The finishing block for G27 falls on the final block. 3. Final block copy is executed when the destination of jump is the final block	1,2. Check and correct the program for G27command block. 3. Block cannot be copied at the final block.

Err.No.	Description of alarm	D e t a i l s
	C a u s e	C o u n t e r m e a s u r e s
962	EDIT Illegal G-code	A failure is checked at G codes (07,22,25) co the program check.
	<ol style="list-style-type: none"> 1. Address A is set empty at G07 command. 2. Address A is set empty at G25 command. 3. Jump command does not exist at G25 command. 4. When operating with two-axis, only one axis has G22 command. 	<p>1 ~ 4.</p> <p>Check and correct the program.</p>

Err.No.	Description of alarm	D e t a i l s
	C a u s e	C o u n t e r m e a s u r e s
020	Parameter destruction	EEPROM data that stores parameter is incorrect.
	1. Power cuts off during parameter-WRITE. 2. The number of times of parameter-WRITE exceeds the limit.	1. Initialize the parameter to reset it. 2. Replace the servo pack.
030	Main circuit detection error	
	1. Servo pack is broken.	1. Replace the servo pack.
040	Parameter setup error	Parameter is full in set area.
	1. EEPROM and peripheral circuit are broken.	1. Replace the servo pack.
041	Dividing pulse output set error	
	1. Set value for PRM566 is wrong.	1. Check and correct PRM566.
050	Combination error	Motor capacity exceeds the limit for combination structure.
	1. The capacities of servo pack and motor are not conformed.	1. Check the motor capacity.
	2. Parameter written in encoder is wrong.	2. Replace the motor.
	3. Servo pack substrate is broken.	3. Replace the servo pack.
100	Over current or overheat of heat sink	Excessive current flows on the power transistor. Heat sink is overheated.
	1. Servo pack substrate and thermo switch are not connected properly.	1. Replace the servo pack.
	2. U, V, W and the grounding cables are not connected properly.	2,3. Check and correct the wiring.
	3. The phases among the motors U, V and W are short-circuited.	
	4. The load exceeds the regenerative processing capacity.	4. Review the loading and operation conditions.
	5. Servo pack fan stops.	5,6. Replace the servo pack.
	6. Servo pack is broken.	
300	Regenerative error	
	1. Servo pack substrate is broken.	1. Replace the servo pack.
	2. Regenerative resistance wiring is wrong.	2. Check and correct the wiring.
	3. Servo pack is broken.	3. Replace the servo pack.

Err.No.	Description of alarm	Details
	Cause	Countermeasures
320	Regenerative overload	Regenerative energy exceeds the limit.
	<ol style="list-style-type: none"> 1. Servo pack substrate is broken. 2. Regenerative energy exceeds the limit. 3. Power source voltage exceeds 270V. 4. Servo pack is broken. 	<ol style="list-style-type: none"> 1. Replace the servo pack. 2. Review the loading and operation conditions. 3. Set an adequate voltage. 4. Replace the servo pack.
330	Main circuit power source wiring error	
	<ol style="list-style-type: none"> 1. Servo pack is broken. 2. AD power source is supplied with DC power source input. Or DC power source is supplied with AC power source input. 3. PRM633 is not 0 when regenerative resistance is not connected. 	<ol style="list-style-type: none"> 1. Replace the servo pack. 2-1. Check and correct the wiring. 2-2. Check PRM501 and set it to 0. 3. Check PRM633 and set it to 0.
400	Over voltage	DC voltage in the main circuit exceeds DC410V.
	<ol style="list-style-type: none"> 1. AD power source voltage exceeds 290V. 2. Working frequency is high, and loading moment of inertia is high. 3. Servo pack is broken. 	<ol style="list-style-type: none"> 1. Set AC power source voltage within the normal range. 2. Review the loading and operation conditions. 3. Replace the servo pack.
410	Under voltage	DC voltage in the main circuit is below DC170V.
	<ol style="list-style-type: none"> 1. AC power source voltage is below 120V. 2. Servo pack fuse is meltdown. 3. Inrush current limit resistance is broken. 4. Momentary blackout occurs. 5. Motor and cable are short-circuited. 	<ol style="list-style-type: none"> 1. Adjust AC power source voltage within the normal range. 2,3. Replace the servo pack. 4. Reset the alarm and start an operation. 5. Replace the motor. Repair the cable.
510	Over speed	Feedback speed that exceeds the maximum frequency $\times 1.1$ is detected.
	<ol style="list-style-type: none"> 1. Servo pack substrate is broken. 2. The order among U, V and W phases in the motor wiring is wrong. 3. Encoder wiring is wrong. 4. Noise occurs in the encoder and it is operated in mistake. 5. Over input of commands for location and speed. 	<ol style="list-style-type: none"> 1. Replace the servo pack. 2. Correct the motor wiring. 3. Correct the encoder wiring. 4. Countermeasures against noise in the encoder wiring. 5. Reduce the command value.
511	Dividing pulse output speed	
	<ol style="list-style-type: none"> 1. Dividing pulse output frequency exceeds 1.6MHz. 	<ol style="list-style-type: none"> 1-1. Check the PG dividing ratio (PRM566). 1-2. Reduce the motor revolving speed.

Err.No.	Description of alarm	D e t a i l s
	C a u s e	C o u n t e r m e a s u r e s
520	Vibration alarm	Abnormal vibration is detected during the motor rotation.
	<ol style="list-style-type: none"> 1. Abnormal vibration is detected during the motor rotation. 2. The value of moment of inertia is higher than real value. Or it changes with great fluctuation. 	<ol style="list-style-type: none"> 1-1. Reduce the revolving speed. 1-2. Reduce the speed loop gain (PRM510). 2. Set the ratio of moment of inertia (PRM513) within an adequate range.
710	Over load (Momentary maximum load)	High load is rotated instantaneously.
720	Over load (Continuous maximum load)	Load is rotated for a certain period with a torque exceeding the rating.
	<ol style="list-style-type: none"> 1. Servo pack is broken. 2. Motor wiring is incorrect. 3. Encoder wiring is incorrect. 4. Effective torque exceeds the rated torque. 5. Startup torque exceeds either the rated torque or the maximum torque by a large margin. 	<ol style="list-style-type: none"> 1. Replace the servo pack. 2. Correct the motor wiring. 3. Correct the encoder wiring. 4,5. Review the conditions for loading and operation.
730	DB over load	Rotating energy when dynamic brake (DB) is shut down exceeds the capacity of DB resistance.
	<ol style="list-style-type: none"> 1. Servo pack substrate is broken. 2. Rotating energy when dynamic brake (DB) is shut down exceeds the capacity of DB resistance. 	<ol style="list-style-type: none"> 1. Replace the servo pack. 2-1. Reduce the working frequency for motor. 2-2. Reduce the load moment of inertia. 2-3. Reduce the occurrence of DB shutdown.
740	Inrush current limit resistance overload	Switch the main circuit power source ON/OFF at the frequency that exceeds 10times/2min.
	<ol style="list-style-type: none"> 1. Servo pack substrate is broken. 2. Inrush current resistance exceeds the limit of permissible frequency when the main circuit power source is ON/OFF. 	<ol style="list-style-type: none"> 1. Replace the servo pack. 2. The number of times for the main circuit power source to switch ON/OFF must be 5 times per min. or less.
7A0	Heat sink overheat	The temperature of the heat sink in the servo pack exceeds 100℃.
	<ol style="list-style-type: none"> 1. Servo pack substrate is broken. 2. Servo pack substrate and thermo switch are not connected properly. 3. Servo pack fan stops. 4. The load exceeds the rated load. 5. The ambient temperature of the servo pack exceeds 55℃. 	<ol style="list-style-type: none"> 1 ~ 3. Replace the servo pack. 4. Review the conditions for loading and operation. 5. Lower the ambient temperature around the controller.

Err.No.	Description of alarm	Details
	Cause	Countermeasures
810	Encoder backup alarm	Encoder location data is cleared.
	<ol style="list-style-type: none"> 1. Servo pack substrate is broken. 2. Power is supplied to the absolute encoder for the first time. 3. Encoder cable is detached from the motor. 4. Both PC power source (+5V) from servo pack and battery power source are down. 5. Absolute encoder is broken. 	<ol style="list-style-type: none"> 1. Replace the servo pack. 2,3. Set location data based on machine zero return method. 4. Check the PG wiring. Correct +5V supply. 5. Replace the servo motor.
820	Encoder same check alarm	Encoder crosscheck is incorrect.
	<ol style="list-style-type: none"> 1. Servo pack is broken. 2. Absolute encoder is broken. 	<ol style="list-style-type: none"> 1. Replace the servo pack. 2. Replace the servo motor.
830	Encoder battery alarm	The battery voltage does not reach the rated value within 2 ~ 4 seconds after the control source is supplied.
	<ol style="list-style-type: none"> 1. Servo pack is broken. 2. Battery voltage is lower than the rated value (2.7V). 3. Batteries are not connected properly, or not connected at all. 	<ol style="list-style-type: none"> 1. Replace the servo pack. 2. Replace the battery. 3. Connect the batteries properly.
840	Encoder data alarm	Abnormality occurs in the encoder data.
	<ol style="list-style-type: none"> 1. Servo pack substrate is broken. 2. Encoder's improper operation. 3. Encoder is broken. 	<ol style="list-style-type: none"> 1. Replace the servo pack. 2. Take proper measures on wiring and peripherals of the encoder. Divide the interconnections between encoder and power source. 3. Replace the motor.
850	Encoder over speed	Motor rotates at the fixed speed or higher when encoder power source is supplied.
	<ol style="list-style-type: none"> 1. Motor rotates at 200min^{-1} or higher when encoder power source is supplied. 2. Servo pack substrate is broken. 3. Encoder is broken. 	<ol style="list-style-type: none"> 1. Turn on the encoder power source when the motor rotation speed is 200min^{-1} or lower. 2. Replace the servo pack. 3. Replace the motor.

Err.No.	Description of alarm	D e t a i l s
	C a u s e	C o u n t e r m e a s u r e s
860	Encoder overheat	The temperature of the encoder is high.
	1. Motor is operated at the load exceeding the rated load.	1. Set the motor load within the rated values.
	2. Motor is in continuous operation.	2. Reduce the motor rotation speed.
	3. Servo pack substrate is broken.	3. Replace the servo pack.
	4. Encoder is broken.	4. Replace the motor.
B10	Speed command A/D error	An error occurs in speed command read-in.
	1. Servo pack substrate is broken.	1. Replace the servo pack.
	2. Malfunction of the speed command input read-in unit.	2. Reset the alarm and start operation.
B20	Torque command A/D error	An error occurs in torque command read-in.
	1. Servo pack substrate is broken.	1. Replace the servo pack.
	2. Malfunction of the torque command input read-in unit.	2. Reset the alarm and start operation.
B31	Current detection alarm 1	An error occurs in the U phase current detection circuit.
	1. Malfunction of U phase current detection circuit.	1. Replace the servo pack.
B32	Current detection alarm 2	An error occurs in the V phase current detection circuit.
	1. Malfunction of V phase current detection circuit.	1. Replace the servo pack.
B33	Current detection alarm 3	An error occurs in the current detection circuit.
	1. Malfunction of current detection circuit.	1. Replace the servo pack.
	2. Motor cable is broken.	2. Review the motor wiring.
BF0	System alarm 0	An error in the internal program processing
BF1	System alarm 1	Internal program operation error.
BF2	System alarm 2	Current control processing internal program error.
BF3	System alarm 3	An error in the encoder interface processing unit.
BF4	System alarm 4	CPUWDT error
	1. Servo pack substrate is broken.	1. Replace the servo pack.
C10	Burn-up check detection	Servo motor burns-up.
	1. The order among U, V and W phases in motor wiring is wrong.	1. Review the motor wiring.
	2. Servo pack is broken.	2. Replace the servo pack.
	3. Encoder is broken.	3. Replace the motor.


Err.No.	Description of alarm	D e t a i l s
	C a u s e	C o u n t e r m e a s u r e s
C80	Encoder clear error	
	1. Servo pack is broken. 2. Encoder is broken.	1. Replace the servo pack. 2. Replace the motor.
C90	Encoder communication error	No communication can be made between the servo pack and the encoder.
C91	Encoder communication position data acceleration error	
C92	Encoder communication timer error	
CB0	Encoder echo back error	
	1. Encoder connection error. Contact error. 2. Noise generates because of the different encoder cable specification. 3. Noise generates because encoder cable is long. 4. Encoder cable is bundled with large-sized current cable, or runs close to it. 5. FG fluctuates with the influences from the welder with the motor. 6. Excessive vibration impact on the encoder. 7. Servo pack is broken. 8. Encoder is broken.	1. Correct the encoder wiring. 2. Use the specified cable. 3. The maximum wiring distance is 20m. 4. Remove surge-applied force from the encoder cable. 5. Route the grounding cable from machines to prevent the current branch to FG on PG. 6. Reduce the machine vibration or check the motor installation. 7. Servo pack is broken. 8. Encoder is broken.
CA0	Encoder parameter error	Encoder parameter is incorrect.
	1. Servo pack is broken. 2. Encoder is broken.	1. Replace the servo pack. 2. Replace the motor.
CC0	Multi-limit mis-compare	Encoder parameter error
	1. User constant for servo pack is wrong. 2. The setup of encoder multi turn limit value is wrong. 3. Encoder is broken.	1. Check PRM561. 2. Re-setup the gear ratio of PRM011. 3. Replace the motor.

Err.No.	Description of alarm	D e t a i l s
	C a u s e	C o u n t e r m e a s u r e s
D00	POS-DEV Over	Position deviation exceeds PRM623 when servo is ON.
	<ol style="list-style-type: none"> 1. Servo pack substrate is broken. 2. Connection among the motors U, V and W is wrong. 3. Motor gain adjustment error. 4. Frequency of position command pulse is too high. 5. Position deviation over level (PRM623) is not adequate. 6. Load condition and motor specification are not adequate. 	<ol style="list-style-type: none"> 1. Replace the servo pack. 2. Correct the motor wiring. 3. Raise the set values of velocity loop gain (PRM510) and position loop gain (PRM512). 4.1. Raise or reduce the frequency of position command pulse. 4.2. Review the electronic gear ratio. 5. Optimize the position deviation over level (PRM623). 6. Review the load.
D01	Servo OFF POS-DEV over	
	<ol style="list-style-type: none"> 1. Position deviations are accumulated excessively when servo is OFF. 	<ol style="list-style-type: none"> 1. Keep the motor stop when servo is OFF.
D02	Servo ON POS-DEV over	
	<ol style="list-style-type: none"> 1. When servo is turned ON with position deviations increased, command pulse is inputted during operation at the limited speed, exceeding the position deviation over alarm level (PRM623). 	<ol style="list-style-type: none"> 1-1. Keep the motor stop when servo is OFF. 1-2. Optimize the limited velocity level (PRM628) when servo is ON.
F10	Power line open-phase	In either R, S or T phase remains at low voltage for 1 second when the main power source is ON.
	<ol style="list-style-type: none"> 1. Servo pack is broken. 2. Wiring for three-phase power source is wrong. 3. Imbalance in the three-phase power source. 	<ol style="list-style-type: none"> 1. Replace the servo pack. 2. Correct the power source wiring. 3. Repair the imbalance in the power source (Replacement among phases).
F20	Motor cable disconnection	Motor cable is disconnected.
	<ol style="list-style-type: none"> 1. Motor cable is disconnected. 	<ol style="list-style-type: none"> 1. Review the motor wiring.
CPU00	Main CPU communication error	Communication between the controller main board and servo pack is incorrect.
	<ol style="list-style-type: none"> 1. Communication cable connection error 2. Main board is broken. 3. Servo pack is broken. 	<ol style="list-style-type: none"> 1. Check the connection of communication cable. Replace the cable. 2. Replace the controller. 3. Replace the servo pack.
400	Machine zero position unset	Machine zero position is not set yet.
	<ol style="list-style-type: none"> 1. Machine zero position is not established yet. 	<ol style="list-style-type: none"> 1. Set machine zero position. (See the section; machine zero positioning)

Detailed explanation on the alarm for Err.016



Pattern 1


The following shows a flowchart of troubleshooting for Err.016 that occurs when the power is ON, or during clamp after table rotation.



Checking Method 1

- A. Use the self-diagnostic function.

Method : Push  (CL/DGN) to display self-diagnostic screen and push  (CL/DGN) six times to check EA-0(Output signal for each axis).





The above BRAKE ON shows the following information.


0 : Non-excitation (Clamped)

1 : Excitation (Unclamped)

Checking Method 2

- B. Use the self-diagnostic function.

Method : Push  (CL/DGN) to display self-diagnostic screen and push  (CL/DGN) four times to check EA-I(Input signal for each axis).



In the case of the checking method 2, items shown below are normal.

0 : Not detecting (Unclamp checked)


1 : Detecting (Clamp checked)

Clamp signal and unclamp signal never become 1 or 0 simultaneously under normal situation. However it could happen just for a moment when solenoid is changed.

Detailed explanation on the alarm for Err.016



Pattern 2


The following shows a flowchart of troubleshooting for Err.016 that occurs soon after the rotation starts or during.



Check Method 3

- C. Use the self-diagnostic function.

Method : Push  (CL/DGN) to display self-diagnostic screen and push  (CL/DGN) six times to check EA-0(Output signal for each axis).





The above BRAKE ON shows the following information.


0 : Non-excitation (State of clamp)

1 : Excitation (State of unclamp)

Check Method 4

- D. Use the self-diagnostic function.

Method : Push  (CL/DGN) to display self-diagnostic screen and push  (CL/DGN) four times to check EA-1(Input signal for each axis).



In the case of the checking method 4, items shown below are normal.

0 : Not detecting (Clamp checked)

1 : Detecting (Unclamp checked)

Pattern 3

If Error .016 occurs when the power is ON and brake is not used (PRM032=1), take measures of troubleshooting in the pattern 2 after the section of “Do you hear the exhaust sound when brake is OFF as for air?”.

2. RAM Clear

When RAM clear is performed, because inputted data and set work zero position are erased and the reconstitution of data becomes impossible, take extreme care of operation.

It is recommended to save the program data, parameter data and work zero position with the external equipment.



Though the following RAM clear modes are provided, unless otherwise special reasons are provided, do not use these modes.

- | | | | |
|----|--------------------------------------|--------------------|--------------------|
| 1. | Program data + Parameter | All clear | (Initialization) |
| 2. | Program data | All clear | |
| 3. | Parameter data | All clear | (Initialization) |
| 4. | Initialization of system information | System information | (Initialization) |

2.1. All data clear of programs and parameter data


When this operation is performed, all data (programs, parameters and work zero position) stored into the memory in the controller are erased to return the memory to an initial setting state.

The all clear modes of program data and parameter data can be used continuously. For details, refer to each item.

- 1)  +  → The all clear mode (CL-1) of program is entered in power ON.
+ POWER ON

CL-1


Program Clear Screen


- 2)  → When the all clear of program is started, 『ALL PRG DEL』 flickers and 『ALL PRG END』 is displayed, the all clear mode is finished, the mode is shifted to the parameter clear mode.

CL-2

Parameter Clear Screen

Even if **CAN** is pushed during program clear, the program clear mode cannot be interrupted.

- 3)  → Number “1” (Standard) is displayed on the right side of “CL-2” display by inputting **ENT**.

- 4) [*****]  → Selects that the parameter clear is performed at which content.
- 1 : General parameter of MAC mini I series
 - 2 : General parameter of MAC mini iH series
 - 3 : Servo parameter

The parameter clear is started and the value during clear is counted on the right side. When 『CL-2 END』 is displayed, the clear mode is finished.



Even if **CAN** is pushed during parameter clear, the parameter clear mode cannot be interrupted.

- 5) Starting screen → The same screen as a starting state in usual power ON is displayed to start the screen.

Because parameter clear is performed, 『Err.400 MZERO POS UN-SETUP』 and 『Err.930 ENC BATTERY ALARM』 occur certainly.


2.2. All data clear of programs

When this operation is performed, only program data stored into the memory in the controller is erased.

- 1)  +  → The all clear mode (CL-1) of program is entered in power ON.
+ POWER ON

CL-1

Program Clear Screen



- 2)  → When the all clear of program is started, 『ALL PRG DEL』 flickers and 『ALL PRG END』 is displayed, the all clear mode is finished, the mode is shifted to the parameter clear mode.

Even if **CAN** is pushed during program clear, the program clear mode cannot be interrupted.

- 3) Starting screen → The same screen as a starting state in usual power ON is displayed to start the screen.



2.3. All data clear of parameter



When this operation is performed, the parameter data stored into the memory in the controller is initially set.

- 1)  +  → The all clear mode (CL-2) of program is entered in power ON.
+ POWER ON


CL-2

Parameter Clear Screen

- 2)  → Number “1” (Standard) is displayed on the right side of “CL-2” display by inputting .

- 3) []  → Selects that the parameter clear is performed at which content.
- 1 : General parameter of MAC mini I series
 - 2 : General parameter of MAC mini iH series
 - 3 : Servo parameter

The parameter clear is started and the value during clear is counted on the right side. When 『CL-2 END』 is displayed, the clear mode is finished.



Even if  is pushed during parameter clear, the parameter clear mode cannot be interrupted.

- 4) Starting screen → The same screen as a starting state in usual power ON is displayed to start the screen.

Because parameter clear is performed, 『Err.400 MZERO POS UN-SETUP』 and 『Err.930 ENC BATTERY ALARM』 occur certainly.


2.4. Initialization of system information

When this operation is performed, the controller information into the memory in the controller is rewritten to the information of a new system.

- 1)  +  → The initialization mode of system information mode (CL-3) of program is entered in power ON.
+ POWER ON

CL-3

Initialization Screen of system information

- 2)  → The initialization of system information is started by inputting **ENT**, “EEPROM INIT” is displayed and the character of “EEPROM INIT” flickers during initialization.

Even if **CAN** is pushed during initialization of system information, the initialization mode cannot be interrupted.

- 3) Starting screen → The same screen as a starting state in usual power ON is displayed to start the screen.

3 Adjustment

3.1. Servo Adjustment

When the unbalanced workpiece or jig is mounted to the rotary table, vibration, abnormal noise, etc., may occur.


At this time, the set values for servo parameters for adjusting servo are shown in the following list.

If their parameters are inadequate for the machine, the vibration and abnormal noise may be increased. Therefore, check the machine operation so that the machine can be stopped immediately when operating the machine after changing the parameter.

M/C rigid set No.	Speed loop gain PRM510	Speed loop integral gain PRM511	Pos. loop gain PRM512	Torque command filter time constant PRM584	Inertia
1	150	6000	150	250	Large
2	200	4500	200	200	
3	300	3000	300	130	
4	400	2000	400	100	
5	600	1500	600	70	Small

If the vibration and abnormal noise occur at standard value, change the parameter to the lower number of machine rigid.

3.2. Brightness control of pendant LCD



Rear View of Pendant

Brightness control steps


1. Remove the hole plug located on the rear face of pendant (See left figure) (Inside volume switch can be checked from hole).
2. The volume switch can be turned with the minus screw driver to right or left in order to adjust LCD brightness.
3. Adjust LCD to optimum brightness, watching the LCD screen.
4. After adjusting, return the hole plug to the original position.

4 Battery for Absolute Encoder

4.1. Specifications

The motor for MAC mini i is the absolute encoder and takes the back-up data with lithium battery. In case something happens on the lithium battery for data back-up, the encoder data disappears. When the voltage of the lithium battery becomes lower than the specified value, 『Error 830 Encoder Battery Alarm』appears and therefore, the lithium battery should be changed along with the instruction below.

Lithium Battery Specifications

Model	JZSP-BA01 (YASKAWA ELECTRIC Corp.) (Battery : ER3V Toshiba Battery Corp.)
Specifications	3.6V 1000mAh
Outside View	

4.2. How to change

Turn MAC mini i on,

Take off the CB1i cable from the motor case and pull off the inside part of CB1i cable from inside the motor case. The battery is fixed on the inside part of CB1i cable.

Take off the present battery from connector and put the new battery.

Tighten up the battery on the cable with a band and put the CB1i cable connection back to as it is.

Remarks

The original position for Machine should be re-set up, if changing the battery would be carried out while turning MAC mini i off.

CONNECTION MANUAL

■ Readers for This Manual

Readers for this manual are as follows:

- Persons who create detailed design
- Persons who make installation work
- Persons who perform maintenance and inspection

C o n t e n t s

1	Appearance	C1-1
1.1.	APPEARANCE OF MAC MINI iH / iHF	C1-1
1.2.	APPEARANCE OF MAC MINI iH2 / iHT / iHP	C1-2
1.3.	APPEARANCE OF PENDANT	C1-3
2	Power Connection	C2-1
2.1.	POWER	C2-1
2.1.1.	INPUT power voltage range	C2-1
2.1.2.	Momentary power interruption	C2-1
2.1.3.	Withstand power noise	C2-1
2.2.	GROUNDING	C2-1
3	Interactive Connection Diagram	C3-1
3.1.	MAC MINI iH / iHF TYPES	C3-2
3.2.	MAC MINI iH2 / iHT TYPES	C3-3
3.3.	MAC MINI iHP TYPE	C3-4
4	Connection Cable	C4-1
4.1.	CB1iHA CABLE	C4-2
4.2.	CB1iHF CABLE	C4-3
4.3.	CB1iHB CABLE	C4-4
5	CB2i Cable (External SOL Cable)	C5-1
6	CB3i Cable (External Connection Cable)	C6-1
6.1.	CB3iHA CABLE	C6-2
6.2.	CB3iHB CABLE	C6-4
7	CB4i Cable (Power Cable)	C7-1
7.1.	CB4iHA CABLE	C7-1
7.2.	CB4iHB CABLE	C7-1


8	I/O Signals	C8-1
8.1.	INPUT SIGNAL	C8-1
8.1.1.	INPUT Signals(for rotary table)	C8-1
8.1.1.1.	BK.C signal	C8-2
8.1.1.2.	BK.UC Signal	C8-2
8.1.1.3.	OVRUN Signal	C8-2
8.1.2.	INPUT signals(for external terminals)	C8-3
8.1.2.1.	ST Signal	C8-4
8.1.2.2.	SP signal	C8-4
8.1.2.3.	EXTEM signal	C8-5
8.1.2.4.	External channel select signal	C8-5
8.1.2.5.	CHSEL0,1,2,3 signals (Binary type)	C8-5
8.1.2.6.	CHSEL0,1,2,3 signals (M-signal type)	C8-6
8.1.2.7.	CHSET signal	C8-6
8.1.2.8.	RST signals	C8-7
8.1.2.9.	ZRN signal	C8-7
8.1.2.10.	MZRN	C8-7
8.1.2.11.	WZRN	C8-8
8.1.2.12.	FIN signal for G99	C8-8
8.1.2.13.	AUTOSET, MANUALSET signals	C8-8
8.2.	OUTPUT SIGNALS	C8-9
8.2.1.	OUTPUT signals(for rotary table)	C8-9
8.2.1.1.	BK Signal	C8-9
8.2.2.	Output signals(for EXE)	C8-10
8.2.2.1.	BLKFIN signal	C8-11
8.2.2.2.	G99FIN signal	C8-12
8.2.2.3.	360FIN signal	C8-13
8.2.2.4.	ZRNFIN signal	C8-13
8.2.2.5.	ALMOUT Signal	C8-14
8.2.2.6.	CHOUT Signal	C8-14
8.2.2.7.	EMOUT signal	C8-14
8.3.	SIGNAL TIMING IN PROGRAM	C8-15
8.3.1.	General programs.....	C8-15
8.3.2.	HOLD Time chart	C8-16
8.3.3.	G08,G09 Time chart.....	C8-17
8.3.4.	G07 Time chart	C8-17
8.3.5.	G21 Time chart	C8-17
8.3.6.	BLKFIN Time chart.....	C8-18
8.4.	EXE I/O SPEC. LIST	C8-19

9	I/O Signal Format	C9-1
9.1.	INPUT FORMAT	C9-1
9.1.1.	Input format	C9-1
9.2.	OUTPUT FORMAT	C9-2
9.2.1.	Output format	C9-2
9.2.2.	Output format for clamp	C9-3
9.2.3.	Emergency stop output format	C9-3
9.3.	PRECAUTIONS USING I/O CIRCUIT	C9-4
10	Detailed External Connection (CB3i cable) ...	C10-1
10.1.	MAC MINI iH / iHF / iHP TYPE	C10-1
10.2.	MAC MINI iH2 / iHT TYPE	C10-2
11	RS232C Connection	C11-1
11.1.	DETAILED RS232C CONNECTOR	C11-1
11.2.	DETAILED RS232C CABLE WIRING	C11-1
12	Connection to Machine	C12-1
12.1.	MACHINE CONNECTION WIRING	C12-1
12.2.	MACHINE CONNECTING EXAMPLE	C12-2
13	Block Diagram	C13-1
13.1.	MAC MINI iH / iHF BLOCK DIAGRAM	C13-1
13.2.	MAC MINI iH2 / iHT BLOCK DIAGRAM	C13-2

1 Appearance


1.1. Appearance of MAC mini iH / iHF

MAC mini iH / iHF are equipped with each pendant in Clause 1.3.




1.2. Appearance of MAC mini iH2 / iHT / iHP

MAC mini iH2 / iHT / iHP are equipped with each pendant in Clause 1.3.



1.3. Appearance of pendant



The controller may be changed without prior notice because of modification, spec., change, etc.

2 Power Connection

2.1. Power

2.1.1.

INPUT power voltage range

Input power voltage of AC200/230V is used at range of +10%, -10%.
The frequency of 50/60Hz is used.

Precautions

If power exceeds AC230V+10%, the machine damage will be caused.

2.1.2.

Momentary power interruption

- ① A momentary power interruption of 1-cycle or less is not detected.
- ② In the momentary power interruption between 1-cycle and 4-cycle, the machine stops or restarts normally.
- ③ When the momentary power interruption exceeding 4-cycle, the machine restarts.

※ Restarting means that the power is turned ON from OFF.

2.1.3.

Withstand power noise

The power noise from external equipment is to be within 1.5KV(50n ~ 1 μ sec). If the power noise exceeds 1.5KV, the machine damage will be caused.

2.2 Grounding


Route a grounding cable at C-class grounding (Grounding resistance value 100 or less) or more.

※ The machine without routing a grounding cable may cause an electric shock.


3. Interactive Connection Diagram

The interactive connection diagram of controller is shown every type.


3.1. MAC mini iH / iHF Types



3.2. MAC mini iH2 / iHT Types



3.3. MAC mini iHP Type




4 Connection Cable

The connection cable CB1i (Controller ~ Circular table) of MAC mini iH Series differs by the controller.

CB1HA Cable	MAC mini iH / iH2 / iHT
CB1iF Cable	MAC mini iHF
CB1iHB Cable	MAC mini iH2 / iHT

The cable of CB1iH type is equipped with a polyamide and metal blade.

4.1. CB1iHA Cable




Signal Name	Controller Side		Table side		Cable Spec.	Wire No. • Color	Remarks
	Name	Pin No	Name	Pin No			
MU1	CB1A-M	1	MOTOR1	4	0.75SQ × 4 core	Brown	Motor U
MV1		2		3		Blue	Motor V
MW1		3		2		Black	Motor W
PE		SHELL		1		Green/yellow	PE
BK.C1		4	BK.C1	2	CAV 0.5SQ	Blue	Clamp check
COM		5	BK.UC1	1	CAV 0.5SQ	Blue	INPUT common
COM		7		1	CAV 0.5SQ	Red	INPUT common
BK.UC1		6	BK.1	2	CAV 0.5SQ	Red	Unclamp check
OVRUNA1		10		2	CAV 0.5SQ	White	Overrun A1 check
COM		11	OT.A1	1	CAV 0.5SQ	White	INPUT common
OVRUNB1		12		2	CAV 0.5SQ	Black	Overrun B1 check
COM		13	OT.B1	1	CAV 0.5SQ	Black	INPUT common
BK+1		14		2	CAV 0.5SQ	Blue	Brake + OUTPUT
BK-1		15	BK.1	1	CAV 0.5SQ	Blue	Brake - OUTPUT
BAT+1		18		9	Batch shield 0.2SQ × 3P	Red	Battery power +
BAT-1		19	PG1	8		Red bar	Battery power -
PS1		20		4		Green	PS1 Signal
/PS1		21		5		Green bar	/PS1 Signal
PG5V1		16		6		Black	PG Power +
PG0V1		17		3		Black bar	PG Power -
SG		22		SHELL		Shield	PG Shield
BAT+1	BAT1	1	PG1	9	0.2SQ × 1P	Black	Battery power +
BAT-1		2		8		black/white	Battery power -

Connector Type List

Connector Name	Connector Type	Maker
CB1A-M	CDDM24	I.L.M.E.
MOTOR1	JZSP-CSM9-3	JST (Nippon crimp terminal)
BK.C1、BK.UC1、OT.A1	52117-241	MOLEX
BK.1	52117-341	
BAT1	DF3-2EP-2C	HRS (HIROSE DENKI)
PG1	54346-0020	MOLEX

4.2. CB1iHF Cable




Signal Name	Controller Side		Table side		Cable Spec.	Wire No. • Color	Remarks
	Name	Pin No	Name	Pin No			
MU1	CB1A-M	1	MOTOR1	4	0.5SQ × 4 core	Brown	Motor U
MV1		2		3		Blue	Motor V
MW1		3		2		Black	Motor W
PE		SHELL		1		Green/yellow	PE
BK.C1		4	BK.C1	2	CAV 0.5SQ	Blue	Clamp check
COM		5		1	CAV 0.5SQ	Blue	INPUT common
COM		7	BK.UC1	1	CAV 0.5SQ	Red	INPUT common
BK.UC1		6		2	CAV 0.5SQ	Red	Unclamp check
OVRUNA1		10	OT.A1	2	CAV 0.5SQ	White	Overrun A1 check
COM		11		1	CAV 0.5SQ	White	INPUT common
OVRUNB1		12	OT.B1	2	CAV 0.5SQ	Black	Overrun B1 check
COM		13		1	CAV 0.5SQ	Black	INPUT common
BK+1		14	BK.1	2	CAV 0.5SQ	Blue	Brake + OUTPUT
BK-1		15		1	CAV 0.5SQ	Blue	Brake - OUTPUT
BAT+1		18	PG1	9	Batch shield 0.2SQ × 3P	Red	Battery power +
BAT-1		19		8		Red bar	Battery power -
PS1		20		4		Green	PS1 Signal
/PS1		21		5		Green bar	/PS1 Signal
PG5V1		16		6		Black	PG Power +
PG0V1		17		3		Black bar	PG Power -
SG		22		SHELL		Shield	PG Shield
BAT+1	BAT1	1	PG1	9	0.2SQ × 1P	Black	Battery power +
BAT-1		2		8		black/white	Battery power -

Connector Type List

Connector Name	Connector Type	Maker
CB1A-M	CDDM24	I.L.M.E.
MOTOR1	JZSP-CSM9-2	JST (Nippon crimp terminal)
BK.C1、BK.UC1、OT.A1	52117-241	MOLEX
BK.1	52117-341	
BAT1	DF3-2EP-2C	HRS (HIROSE DENKI)
PG1	54346-0020	MOLEX

CB1iHB Cable



Signal Name	Controller Side		Table side		Cable Spec.	Wire No. • Color	Remarks
	Name	Pin No	Name	Pin No			
MU2	CB1A-M	1	MOTOR2	4	0.75SQ × 4 core	Brown	Motor U
MV2		2		3		Blue	Motor V
MW2		3		2		Black	Motor W
PE		SHELL		1		Green/yellow	PE
BK.C2		4	BK.C2	2	CAV 0.5SQ	Blue	Clamp check
COM		5		1	CAV 0.5SQ	Blue	INPUT common
COM		7	BK.UC2	1	CAV 0.5SQ	Red	INPUT common
BK.UC2		6		2	CAV 0.5SQ	Red	Unclamp check
OVRUNA2		10	OT.A2	2	CAV 0.5SQ	White	Overrun A2 check
COM		11		1	CAV 0.5SQ	White	INPUT common
OVRUNB2		12	OT.B2	2	CAV 0.5SQ	Black	Overrun B2 check
COM		13		1	CAV 0.5SQ	Black	INPUT common
BK+2		14	BK.2	2	CAV 0.5SQ	Blue	Brake + OUTPUT
BK-2		15		1	CAV 0.5SQ	Blue	Brake - OUTPUT
BAT+2		18	PG2	9	Batch shield 0.2SQ × 3P	Red	Battery power +
BAT-2		19		8		Red bar	Battery power -
PS2		20		4		Green	PS1 Signal
/PS2		21		5		Green bar	/PS1 Signal
PG5V2		16		6		Black	PG Power +
PG0V2		17		3		Black bar	PG Power -
SG		22		SHELL		Shield	PG Shield
BAT+2		BAT2		1		PG2	0.2SQ × 1P
BAT-2	2		8	black/white	Battery power -		

Connector Type List

Connector Name	Connector Type	Maker
CB1A-M	CDDM24	I.L.M.E.
MOTOR2	JZSP-CSM9-3	JST (Nippon crimp terminal)
BK.C2, BK.UC2、 OT.A2, OT.B2,	52117-241	MOLEX
BK, 2	52117-341	
BAT2	DF3-2EP-2C	HRS (HIROSE DENKI)
PG2	54346-0020	MOLEX

5 CB2i Cable (External SOL Cable)


Since the NC circular table of hydraulic clamp spec., is equipped with the solenoid valve for clamp to the external equipment, it is necessary to output the power for clamping from the controller.

In this case, the cable of CB2i is connected.

The cable of CB2i is connected to the connector for the brake of main board in the controller.

However, the voltage outputted for the external solenoid is used for only DC24V 0.5A.

The CB2i cable is attached to only hydraulic clamp type. Other circular tables are not equipped with its cable.



CB2i cable is packed together with cable clamp parts.

MAC mini iH/iHF / iHP

Cable Name	Connector	Pin No.	Terminal Indication	Remarks
CB2i	BRAKE1	1	BK+1	DC24V Brake OUTPUT +
		2	BK-1	DC24V Brake OUTPUT -

MAC mini iH2 / iHT


Cable Name	Connector	Pin No.	Terminal Indication	Remarks
CB2i	BRAKE1	1	BK+1	DC24V Brake OUTPUT + for A-axis
		2	BK-1	DC24V Brake OUTPUT - for A-axis
CB2i2	BRAKE2	1	BK+2	DC24V Brake OUTPUT + for B-axis
		2	BK-2	DC24V Brake OUTPUT - for B-axis

6 CB3i Cable (External Connection Cable)

To communicate signals between the controller and the external equipment, the CB3i cable is used. The controller is connected with the cable corresponding to the controller specification. This CB3i cable is used for MAC mini i / iF.

CB3iHA Cable	MAC mini iH / iHF / iHP
CB3iHB Cable	MAC mini iH2 / iHT

6.1. CB3iHA Cable




No	Connector in panel		Wiring color	Signal Name	Signal Display	Cable Spec.
	Name	Pin No.				
1	NC1	1	Black	BLOCK FINISH	BLKFIN	UL2464 AWG20 × 33-core
2		2	White	BLOCK FINISH COMMON	BLKFINCOM	
3		3	Red	OPT FINISH OUTPUT 1	G99FIN1	
4		4	Green	360 ° OUTPUT 1	360FIN1	
5		5	Yellow	ALARM A-CONTACT OUTPUT	ALMOUTA	
6		6	Blown	ALARM B-CONTACT OUTPUT	ALMOUTB	
7		7	Blue	ZRN FINISH 1	ZRNFIN1	
8		8	Gray	OUTPUT COMMON 1	OUTCOM1	
9		9	Orange	STOP	SP	
10		10	Bright green	START	ST	
11		11	Pink	CHANNEL SELECT 0	CHSEL0	
12		12	Violet	CHANNEL SELECT 1	CHSEL1	
13		13	Black(short bar)	CHANNEL SELECT 2	CHSEL2	
14		14	White(short bar)	CHANNEL SELECT 3	CHSEL3	
15		15	Red(short bar)	CHANNEL SET	CHSET	
16		16	Green(short bar)	EXE EMG STOP INPUT	EXTEM	
17		17	Yellow(short bar)	INPUT COMMON	INCOM	
18		18	Blown(short bar)	INPUT COMMON	INCOM	
19		19	Blue(short bar)	EMG STOP OUTPUT	EMOUT	
20		20	Gray(short bar)	EMG STOP OUTPUT COMMON	EMOUTCOM	

No	Connector in panel		Wiring color	Signal Name	Signal Display	Cable Spec.
	Name	Pin No.				
21	NCOP1	1	Orange(short bar)	EXE RESET	RST	
22		2	Bright green (short bar)	EXE ZRN REQUEST 1	ZRN1	
23		3	Pink(short bar)	EXE ZRN REQUEST 2	ZRN2	
24		4	Violet(short bar)	EXE MANUAL MODE SELECT	MANUALSET	
25		5	Black(long bar)	EXE AUTO MODE SELECT	AUTOSET	
26		6	White(long bar)	CHANNEL NO. OUTPUT 0	SELOUT0	
27		7	Red(long bar)	CHANNEL NO. OUTPUT 1	SELOUT1	
28		8	Green(long bar)	CHANNEL NO. OUTPUT 2	SELOUT2	
29		9	Yellow(long bar)	CHANNEL NO. OUTPUT 3	SELOUT3	
30		10	Blown(long bar)	CHANNEL NO. OUTPUT 4	SELOUT4	
31		11	Blue(long bar)	CHANNEL NO. OUTPUT 5	SELOUT5	
32		12	Gray(long bar)	CHANNEL NO. OUTPUT 6	SELOUT6	
33		13				
34		14				
35		15	Orange(long bar)	OUTPUT COMMON 1	OUTCOM1	

Connector spec.

Connector Name	Parts Name	Type	Maker
NC1	Connector	DF1B-20DS-2.5RC	HIROSE ELECTRIC CO.
	Pin	DF1B-2022SC	HIROSE ELECTRIC CO.
NCOP1	Connector	DF1B-15S-2.5RC	HIROSE ELECTRIC CO.
	Pin	DF1B-2022SC	HIROSE ELECTRIC CO.

6.2. CB3iHB Cable



No	Connector in panel		Wiring color	Signal Name	Signal Display	Cable Spec.
	Name	Pin No.				
1	NC1	1	Black	BLOCK FINISH	BLKFIN	UL2464 AWG20 × 37-core
2		2	White	BLOCK FINISH COMMON	BLKFINCOM	
3		3	Red	OPT FINISH OUTPUT 1	G99FIN1	
4		4	Green	360 ° OUTPUT 1	360FIN1	
5		5	Yellow	ALARM A-CONTACT OUTPUT	ALMOUTA	
6		6	Blown	ALARM B-CONTACT OUTPUT	ALMOUTB	
7		7	Blue	ZRN FINISH 1	ZRNFIN1	
8		8	Gray	OUTPUT COMMON 1	OUTCOM1	
9		9	Orange	STOP	SP	
10		10	Bright green	START	ST	
11		11	Pink	CHANNEL SELECT 0	CHSEL0	
12		12	Violet	CHANNEL SELECT 1	CHSEL1	
13		13	Black(short bar)	CHANNEL SELECT 2	CHSEL2	
14		14	White(short bar)	CHANNEL SELECT 3	CHSEL3	
15		15	Red(short bar)	CHANNEL SET	CHSET	
16		16	Green(short bar)	EXE EMG STOP INPUT	EXTEM	
17		17	Yellow(short bar)	INPUT COMMON	INCOM	
18		18	Blown(short bar)	INPUT COMMON	INCOM	
19		19	Blue(short bar)	EMG STOP OUTPUT	EMOUT	
20		20	Gray(short bar)	EMG STOP OUTPUT COMMON	EMOUTCOM	

No	Connector in panel		Wiring color	Signal Name	Signal Display	Cable Spec.
	Name	Pin No.				
21	NCOP1	1	Orange(short bar)	EXE RESET	RST	
22		2	Bright green (short bar)	EXE ZRN REQUEST 1	ZRN1	
23		3	Pink(short bar)	EXE ZRN REQUEST 2	ZRN2	
24		4	Violet(short bar)	EXE MANUAL MODE SELECT	MANUALSET	
25		5	Black(long bar)	EXE AUTO MODE SELECT	AUTOSET	
26		6	White(long bar)	CHANNEL NO. OUTPUT 0	SELOUT0	
27		7	Red(long bar)	CHANNEL NO. OUTPUT 1	SELOUT1	
28		8	Green(long bar)	CHANNEL NO. OUTPUT 2	SELOUT2	
29		9	Yellow(long bar)	CHANNEL NO. OUTPUT 3	SELOUT3	
30		10	Blown(long bar)	CHANNEL NO. OUTPUT 4	SELOUT4	
31		11	Blue(long bar)	CHANNEL NO. OUTPUT 5	SELOUT5	
32		12	Gray(long bar)	CHANNEL NO. OUTPUT 6	SELOUT6	
33		13				
34		14				
35		15	Orange(long bar)	OUTPUT COMMON 1	OUTCOM1	
36	NC2	1	Bright green (long bar)	OPT FINISH OUTPUT 2	G99FIN2	
37		2	Pink(long bar)	360 ° OUTPUT 2	360FIN2	
38		3	Violet(long bar)	ZRN FINISH 2	ZRNFIN2	
39		4	Black/white	OUTPUT COMMON 2	OUTCOM2	

Connector Spec.

Connector Name	Parts Name	Type	Maker
NC1	Connector	DF1B-20DS-2.5RC	HIROSE ELECTRIC CO.
	Pin	DF1B-2022SC	HIROSE ELECTRIC CO.
NCOP1	Connector	DF1B-15S-2.5RC	HIROSE ELECTRIC CO.
	Pin	DF1B-2022SC	HIROSE ELECTRIC CO.
NC2	Connector	DF1B-4S-2.5RC	HIROSE ELECTRIC CO.
	Pin	DF1B-2022SC	HIROSE ELECTRIC CO.

7 CB4i Cable (Power Cable)

CB4i cable for power supply of controller differs by type.


CB4iHA Cable

MAC mini iH / iHF / iH2 / iHT

CB4iHB Cable

MAC mini iHP


7.1. CB4iHA Cable



MAC mini iH / iHF / iH2 / iHT

No.	Signal Name	Terminal Indication	Cable Spec.	Cable Color	Power
1	Power 1	L1	1.5SQ × 3C	Brown	1 AC200/230V ± 10%
2	Power 2	L2		Blue	
3	PE(Grounding)	PE		Green/Yellow	

7.2. CB4iHB Cable



MAC mini iHP

No.	Signal Name	Terminal Indication	Cable Spec.	Cable Color	Power
1	Power 1	L1	2.5SQ × 4C	Brown	3 AC200/230V ± 10%
2	Power 2	L2		Blue	
3	Power 3	L3		Black	
4	PE(Grounding)	PE		Green/Yellow	

8 I/O Signals

8.1. Input signal

Two INPUT signals are provided for controller:

- Input signal from rotary table.
- Input signal from external terminal

8.1.1. INPUT Signals (for rotary table)

MAC mini iH / iHF / iHP

No.	Name	Signal	Description
1	CLAMP	BK.C1	Checks CLAMP of brake.
2	UNCLAMP	BK.UC1	Checks UNCLAMP of brake.
3	OVERRUN	OVRUNA1	Checks + side of over-travel.
4		OVRUNB1	Checks - side of over-travel.
5	COMMON	COM	Common line of No.1 ~ 4

MAC mini iH2 / iHT (2-axis controller)

Axis	No.	Name	Signal	Description
1 st Axis	1	CLAMP	BK.C1	Checks CLAMP of brake.
	2	UNCLAMP	BK.UC1	Checks UNCLAMP of brake.
	3	OVERRUN	OVRUNA1	Checks + side of over-travel.
	4		OVRUNB1	Checks - side of over-travel.
	5	COMMON	COM	Common line of No.1 ~ 4
2 nd Axis	6	CLAMP	BK.C2	Checks CLAMP of brake.
	7	UNCLAMP	BK.UC2	Checks UNCLAMP of brake.
	8	OVERRUN	OVRUNA2	Checks + side of over-travel.
	9		OVRUNB2	Checks - side of over-travel.
	10	COMMON	COM	Common line of No.6 ~ 9

For these INPUT signals, an exclusive cable (CB1i) is routed to connect the controller and the rotary table.

8.1.1.1**BK.C signal**

➤ Contents

CLAMP can be checked by short-circuiting BK. C and INCOM.

BK.C1 is for A-axis (single axis) and BK. C2 is for B-axis.

➤ Conditions

1. BK.C signal is for monitoring usually in case of PRM038=1, and it is unused in case of PRM038=0.
2. BK.C signal INPUT time is to be continuous 100msec or more.

8.1.1.2.**BK.UC Signal**

➤ Contents

UNCLAMP can be checked by short-circuiting BK. C and INCOM.

BK.UC1 is for A-axis (single axis) and BK. UC2 is for B-axis.

➤ Conditions

1. BK.UC signal is for monitoring usually.
2. BK.UC signal INPUT time is to be continuous 100msec or more.

8.1.1.3.**OVRUN Signal**

➤ Contents

OVER TRAVEL is checked by the signal between OVRUN and INCOM.

OVRUNA1 and OVRUNB1 are for A-axis (single), and OVRUNA2 and OVRUNB2 are for B-axis.

➤ Conditions

1. OVRUN signal is for monitoring usually.
2. OVRUN signal INPUT time is to be continuous 100msec or more.

8.1.2.

**INPUT signals
(for external terminals)**

The INPUT signals of controller vary every type.

The following list shows INPUT signals for the controller.

These signals are transmitted through CB3i cable.

Type	No.	Name	Signal	Description
Com.	1	START	ST	Executes program in “AUTO” or “SINGLE” mode.
	2	HOLD	SP	Decelerates and stops rotary table in “AUTO” or “SINGLE” mode.
	3	EXE EMG STOP	EXT EM	EMG STOP signal inputted from external terminal can stop rotary table immediately.
	4	CHANNEL SELECT	CHSEL0 CHSEL1 CHSEL2 CHSEL3	Selects program channel from external terminal by binary mode and M-signal mode.
	5	CHANNEL SET	CHSET	When EXE CHANNEL is finally selected, this code is inputted.
	6	RESET	RST	Can be reset from external terminal.
	7	AUTO MODE CHANGE	AUTOSET	Can be changed to AUTO mode.
	8	MANUAL MODE CHANGE	MANUALSET	Can be changed to MANUAL mode.
	9	EXE ZRN	ZRN1	Performs MZRN or WZRN of 1 st axis.
iH2 iHT	10	REQUEST	ZRN2	Performs MZRN or WZRN of 2 nd axis.
Com.	11	INPUT COM	IN COM	Common line of No.1 ~ 10.
	12	INPUT COM	IN COM	

The above common type means MAC mini iH / iHF / iHP / iH2 / iHT.

8.1.2.1. ST Signal

➤ Contents


The start (ST) signal is inputted by short-circuiting ST and IN COM.

The program of selected channel is executed under AUTO or SINGLE mode.


When the ST signal is inputted with the controller stopped temporarily, the program is restarted.

➤ Conditions

1. The ST signal is to be INVALID unless an input time is continuous 100msec or more.



2. The AUTO or SINGLE mode is to be possible to start the program.
3. The program is not to be executed. (STATUS is not to be RUN. However, it is except in case of RUN+STOP.)
4. Any alarm is not to be occurred. (STATUS is not to be ALARM.)
5. Other START signals (Panel) are not to be INPUT state.
6. Temporary stop (SP) is to be ON.
7. BLKFIN is not to be outputted, and after BLKFIN is OFF, 100msec or more is to be passed.



8.1.2.2 SP signal

➤ Content

The STOP signal is inputted by opening SP and IN COM.

The program operation is stopped temporarily.

➤ Conditions

1. To be during AUTO RUN. (STATUS is to be RUN.)
2. When SP signal is turned OFF during ST signal ON, the program operation is stopped immediately.
3. Even if ST signal is turned ON during SP signal OFF, AUTO RUN is not to be started.

8.1.2.3. EXTEM signal

➤ Contents

The EMERGENCY STOP from the external equipment can be inputted by opening EXTEM and INCOM.

When the external EMERGENCY STOP is turned OFF, ^⑦ Err.002 EXT EMERGENCY SP ^⑧ occurs.

When the power supply to the motor is turned OFF and short-circuit is braked ON simultaneously, the motor is stopped immediately.

➤ Conditions

1. Usually monitored.
2. When EXTEM is OFF, it has priority over other functions (except EMG SP).
3. The motor must not be reset until EXTEM and INCOM are opened.

8.1.2.4. External channel select signal

The external channel has two kinds of binary mode and M-signal mode, which are selected by parameters.

Each signal differs by a used mode.

8.1.2.5. CHSEL0,1,2,3 signals (Binary type)

➤ Contents

When INCOM is short-circuited in order of CHSEL0, CHSEL1, CHSEL2, CHSEL3, the channel No. can be inputted at binary signal.

When the binary signal is inputted during AUTO mode, the channel No. can be selected.

However, this signal only selects the channel No., and it cannot perform a setting change. When the setting change is performed, it is necessary to input CHSET.

➤ Conditions

1. This mode is valid for only when PRM033=0 and also PRM112=1.
2. When STATUS is STOP or RESET state under AUTO mode, the binary signal can be changed.
3. The selection of channel inputted during BLKFIN or G99FIN output is to be invalid.

8.1.2.6.**CHSEL0,1,2,3 signals (M-signal type)** ➤ Contents

When CHSEL0 and INCOM are short-circuited, channel No. 00 is selected as ZERO signal.

When CHSEL1 and INCOM are short-circuited, channel No. is added one by one as PLUS1 signal.

When CHSEL2 and INCOM are short-circuited, channel Nos. are added ten by ten as PLUS10 signal.

When CHSEL3 and INCOM are short-circuited, channel Nos. are reduced ten by ten as PLUS10 signal.

Channels can be increased to max. channels without exceeding its set value. (Max. value is determined to PRM390、PRM400 ~ PRM489.)

➤ Conditions

1. This mode is valid for only when PRM033=1 and also PRM112=1.
2. When STATUS is STOP or RESET state under AUTO mode, M-signal can be changed.
3. While any signal is being inputted, other signals cannot be inputted.
4. ZERO、PLUS1、PLUS10、MINUS10 signals are to be inputted continuously at 100msec or more.
5. ZERO signal and PLUS signal are continuously inputted, the intervals of 100msec or more are to be provided.
6. The selection of channel inputted during BLKFIN or G99FIN output is to be invalid.

8.1.2.7.**CHSET signal** ➤ Contents

When CHSET and INCOM are short-circuited during the binary mode, the channel can be changed.

➤ Conditions

1. This mode is valid for only when PRM033=0 and also PRM112=1.
2. When the channel setting mode is set to AUTO, STATUS is to be STOP or RESET state.
3. CHSET is to be continuously inputted for 500msec or more.
4. The selection of channel inputted during BLKFIN or G99FIN output is to be invalid.

8.1.2.8. RST signal

➤ Contents

RESET mode is inputted by short-circuiting RST and INCOM.

Operational contents is the same as **RESET** key on the panel and it is shown in the following list.

- An alarm is released and the program is returned to top at EDIT mode.
- RESET operation varies by mode and status.

Mode	Status	Content
AUTO	RUN	PROGRAM STOP
	RUN & STOP	PROGRAM RESET & REWIND
	STOP	PROGRAM RESET
	RESET	PROGRAM REWIND
	ALARM	ALARM RESET
EDIT		PROGRAM REWIND

➤ Conditions

1. All RESET modes are to be valid.
2. An RESET signal INPUT time is to be continuous 100msec or more.

8.1.2.9. ZRN signal

The zero return INPUT signal is divided into two kinds (MZRN and WZRN by parameters) and it can be inputted for finishing to G99 OUTPU.

ZRN1 shows A-axis and ZRN2 B-axis.

8.1.2.10. MZRN

➤ Contents

MZRN of A-axis is performed by short-circuiting ZRN1 and INCOM.

MZRN of B-axis is performed by short-circuiting ZRN2 and INCOM.

➤ Conditions

1. PRM029 is 0. (PRM029=0)
2. Only MANUAL mode is to be valid.
3. ZRN signal INPUT time is continuous 100msec or more.

8.1.2.11. WZRN

➤ Contents

WZRN of A-axis is performed by short-circuiting ZRN1 and INCOM.

WZRN of B-axis is performed by short-circuiting ZRN2 and INCOM.

➤ Conditions

1. PRM029 is 1. (PRM029=1)
2. Only MANUAL mode is to be valid.
3. ZRN signal INPUT time is continuous 100msec or more.
4. MZRN is to be finished.

8.1.2.12. FIN signal for G99

➤ Contents

G99FIN1 OUTPUT of A-axis is turned OFF by short-circuiting ZRN1 and INCOM.

G99FIN2 OUTPUT of B-axis is turned OFF by short-circuiting ZRN2 and INCOM.

➤ Conditions

1. PRM029 is 2. (PRM029=2)
2. AUTO and SINGLE modes become valid.
3. ZRN signal INPUT time is continuous 100msec or more.

8.1.2.13. AUTOSET, MANUALSET signals

➤ Contents

AUTO mode is selected from outside by short-circuiting AUTOSET and INCOM.

MANUAL mode is selected from outside by short-circuiting MANUALSET and INCOM.

➤ Conditions

1. EXE mode SELECT becomes valid at READY status.
2. EXE mode SELECT is to be changed from any mode. However, in the following case, it is not to be changed.
 - While editing the program under EDIT mode.
 - While setting the parameter under PARAM mode.
3. EXE mode is to be selected only by inputting any mode. When both modes are inputted, 『 Err.219 EXT MODE SEL ERR 』 occurs.
4. The mode just after INPUT OFF of EXE mode SELECT is returned to the mode just before INPUT ON.
5. In EXE mode SELECT INPUT ON, panel mode is not selected.

8.2. Output signals

Output signal from external terminal is divided into two kinds.

- Output signal from rotary table
- Output signal from external terminal.

8.2.1.

OUTPUT signals (for rotary table)

MAC mini iH / iHF / iHP

No.	Name	Signal	Description
1	Brake + OUTPUT	BK+1	Power (DC24V) for brake operation is supplied.
2	Brake - OUTPUT	BK-1	

MAC mini iH2 / iHT (2-axis controller)

Axis	No.	Name	Signal	Description
A-axis	1	Brake + OUTPUT	BK+1	Power (DC24V) for brake of A-axis is supplied.
	2	Brake - OUTPUT	BK-1	
B-axis	1	Brake + OUTPUT	BK+2	Power (DC24V) for brake of B-axis is supplied.
	2	Brake - OUTPUT	BK-2	

For these INPUT signals, an exclusive cable (CB1i) is routed to connect the controller and the rotary table.

8.2.1.1. BK Signal

➤ Contents

In UNCLAMP, power DC24V is outputted between BK+ and BK-.
BK+ is + pole and BK- is - pole.

When setting PRM032=1, power DC24V is usually outputted to this cable line.

BK+1 and BK-1 are for A-axis (single) and BK+2 and BK-2 are B-axis.

8.2.2.

Output signals
(for EXE)

The following list shows OUTPUT signals for the controller.

These OUTPUT signals are transmitted through CB3i cable.

Type	No.	Name	Signal	Description
COM.	1	BLOCK FIN	BLKFIN	When 1 block motion of program RUN is finished during AUTO mode, BLKFIN is outputted. Also, when external channel is changed, it is outputted for checking.
	2	BLOCK FIN COMMON	BLKFINCOM	This is private output common mode of BLKFIN.
	3	OPTION FIN	G99FIN1	When the program of G98, G99, or G21L99 is executed, G99FIN1 is outputted. In G98, this signal is outputted together with BLK FIN. In G99, BLK FIN is not outputted.
	4	360°FIN	360FIN1	During PRM25 = 0 (One shot output type) , when the table passes through WZERO position or stops at its place, 360FIN1 is outputted for the time set to PRM036. During PRM025=1 (Continuous output type) , when the circular table shifts in the area set to PRM026, this signal is outputted. The signal is continuously outputted while the circular table is in the area.
	5	ZERO RETURN FINISH	ZRNFIN1	When MZRN is finished, this signal is outputted.
	6	ALARM OUTPUT A-CONTACT	ALMOUTA	When alarm occurs, the signal that A-contact is closed is outputted.
	7	ALARM OUTPUT B-CONTACT	ALMOUTB	When alarm occurs, the signal that B-contact is opened is outputted.
	8	CHANNEL NO. OUTPUT	CHOUT0	Channel number while selecting currently is outputted by binary.
	9		CHOUT1	
	10		CHOUT2	
	11		CHOUT3	
	12		CHOUT4	
	13		CHOUT5	
	14		CHOUT6	
	15	OUTPUT COMMON 1	OUTCOM1	Common line of No.3 ~ 14
iH2 iHT	16	OPTION FIN2	G99FIN2	Content is the same as above G99FIN1. However, this code is outputted for B-axis.
	17	360°FIN2	360FIN2	Content is the same as above 360FIN1. However, this code is outputted for B-axis.
	18	ZERO RETURN FIN2	ZRNFIN2	Content is the same as above ZRNFIN1. However, this code is outputted for B-axis.
	19	OUTPUT COMMON 2	OUTCOM2	Common line of No.16 ~ 18
COM.	20	EMG STOP OUTPUT	EMOUT	The EMG STOP SW mode on the panel is outputted to machine side (NC side) at B-contact state.
	21	EMGSTOPOUTPUT COMMON	EMOUTCOM	This is output common for EMOUT.

Common types are MAC mini iH / iHF / iHP / iH2 / iHT .

8.2.2.1. BLKFIN signal

➤ Contents

The contact between BLKFIN and BLKFINCOM is closed in BLKFIN of program run (AUTO mode).

The exception shown below is outputted when the program is executed.

- OUTPUT timing in G07 (outputted when program is started.)
- OUTPUT timing in G08, 09 (outputted when G08 is executed (started) .)

The output time is from BLKFIN to ST signal OFF check (PRM035=0) or the time set to PRM035.

When the external channel is selected during the binary mode, this signal is outputted for checking the channel change.

When the external channel is selected during M-signal mode, this signal is outputted for checking the following signals.

- ZERO signal (CHSEL0-INCOM)
- PLUS1 signal (CHSEL1-INCOM)
- PLUS10 signal (CHSEL2-INCOM)
- MINUS10 signal (CHSEL3-INCOM)

In the MAC mini iH2 series (2-axis spec.) , when there are execution commands for both axes into one block, the BLKFIN is outputted after executing both axes.

For the timing chart of BLKFIN, see various timing charts as shown in the latter section.

8.2.2.2.

G99FIN signal


➤ Contents

When program G99 is executed, the contact between G99FIN and OUTCOM is closed.


When program G98 is executed, this signal is outputted together with BLKFIN signal.

When program G21 L99 is executed, G99FIN is outputted.


The output times of the above , , are fixed to 500msec.



The output time in PRM029=2(G99 check signal) is PRM028.



When set to PRM018=2, G99FIN is continuously outputted while BK is being outputted because it is different from the usual G99FIN output.



G99FIN1 is for A-axis (single axis) and G99FIN2 is for B-axis. G99FIN2 is for exclusive MAC mini iH2.


8.2.2.3. 360FIN signal

➤ Contents


In case of PRM025=0, when the table passes through WZERO position or stops at its place, this signal is outputted from the connection between 360FIN and OUTCOM.

The output contact can be changed at PRM034.

The output time of one shot type is set to PRM036.



In case of PRM025=1, the output area based on WZERO is set to PRM026. When the current coordinate is in the area, this signal is continuously outputted from the connection between 360FIN and OUTCOM.



360FIN1 is for A-axis (single axis) and 360FIN2 is for B-axis.
360FIN2 is for exclusive MAC mini iH2.


8.2.2.4. ZRNFIN signal

➤ Contents

When the motion for MZRN command is finished, the contact between ZRNFIN and OUTCOM is closed.


The output time of ZRNFIN is fixed to 500msec.

The output start timing is the same as BLKFIN.



ZRNFIN1 is for A-axis (single axis) and ZRNFIN2 is for B-axis.
ZRNFIN2 is for exclusive MAC mini iH2.

When G23 is commanded (only single or both) at 2-axis spec., and BLKFIN is outputted at operation finish of both axes, the axis that finished MZRN outputs ZRNFIN.



8.2.2.5. ALMOUT Signal

➤ Contents

When the STATUS of controller is in alarm state, this signal is outputted from the connection between ALMOUTA and OUTCOM, and connection between ALMOUTB and OUTCOM.

When any alarm occurs, the connection between ALMOUTA and OUTCOM is closed, and the connection between ALMOUTB and OUTCOM is opened.

The alarm is continuously outputted while the STATUS is in alarm.

8.2.2.6. CHOUT Signal

➤ Contents

The channel number during selection is outputted between CHOUT0, 1, 2, 3, 4, 5, 6 and OUTCOM by binary.

Channel number OUTPUT is changed simultaneously with BLKFIN OUTPUT for checking channel change.

8.2.2.7. EMOUT signal

➤ Contents

The contact of emergency stop button of controller is outputted from the connection between EMOUT and EMOUTCOM.


Since EMOUT is B-contact spec., the contact is closed in normal and it is opened when the emergency stop button is pushed.

8.3. Signal timing in program

8.3.1.

General programs

The basic time chart from the program start to operation finish is shown in the following figure.



Operation steps

ST INPUT ON

Brake OUTPUT ON (UNCLAMPED)

CLAMP CHECK: OFF , UNCLAMP CHECK: ON

Rotation is started by checking UNCLAMP.

Entered in in-position by indexing.

Brake OUTPUT OFF after PRM009 time (CLAMPED)

CLAMP CHECK: ON , UNCLAMP OUTPUT: OFF

BLKFIN OUTPUT ON at CLAMP CHECK ON

ST signal OFF at BLKFIN OUTPUT ON CHECK


BLKFIN OFF at ST INPUT OFF CHECK

(BLKFIN is remained until ST INPUT is OFF.)

Though ST signal can be inputted at one shot, use the ST signal that is OFF at BLKFIN ON CHECK for preventing errors.

8.3.2 HOLD Time chart


The basic time chart from the program start to operation finish is shown in the following figure.




8.3.3. G08, G09 Time chart

When using G08, G09, BLKFIN OUTPUT timing can be changed by PRM020.

PRM020=0




PRM020=1



8.3.4. G07 Time chart


When using G07, BLKFIN OUTPUT timing can be changed by PRM021.



8.3.5. G21 Time chart

In machine interlock of G21, it is very difficult to adjust the timing with the machine. Therefore, it is necessary to be synchronized simply by setting the following time.

Since this controller is synchronized with the machine by an external signal, a complete synchronization is impossible.



8.3.6. BLKFIN Time chart


In the timing outputted when BLKFIN signal is finished, object contents can be changed by setting the parameter.

The object contents include CLAMP CHECK signal, UNCLAMP CHECK signal and position deviation.

The following shows the timing by this combination.

CLAMP CHECK TYPE

PRM022=0 PRM038=1 (PRM032=0) ... Standard setting




UNCLAMP CHECK TYPE

PRM022=0 PRM038=0 (PRM032=0)



POS. DEVIATION CHECK TYPE

PRM022=1 or PRM032=1




8.4. EXE I/O SPEC. LIST

NO.	Signal name	I/O	Type	Spec.	Remarks
1	ST	I	Dry or Tr	DC24V 10mA	
2	SP	I	Dry or Tr	DC24V 10mA	
3	EXT EM	I	Dry or Tr	DC24V 10mA	
4	CHSEL0	I	Dry or Tr	DC24V 10mA	
5	CHSEL1	I	Dry or Tr	DC24V 10mA	
6	CHSEL2	I	Dry or Tr	DC24V 10mA	
7	CHSEL3	I	Dry or Tr	DC24V 10mA	
8	CHSET	I	Dry or Tr	DC24V 10mA	
9	RST	I	Dry or Tr	DC24V 10mA	
10	ZRN1	I	Dry or Tr	DC24V 10mA	
11	AUTOSET	I	Dry or Tr	DC24V 10mA	
12	MANUALSET	I	Dry or Tr	DC24V 10mA	
13	BLKFIN	O	Dry	DC30V 0.4A	Min. DC5V 100mA
14	G99FIN1	O	Dry	DC30V 0.4A	Min. DC10mV 10 μ A
15	360FIN1	O	Dry	DC30V 0.4A	Min. DC10mV 10 μ A
16	ZRNFIN1	O	Dry	DC30V 0.4A	Min. DC10mV 10 μ A
17	ALMOUTA	O	Dry	DC30V 0.4A	Min. DC10mV 10 μ A
18	ALMOUTB	O	Dry	DC30V 0.4A	Min. DC10mV 10 μ A
19	CHOUT0	O	Dry	DC30V 0.4A	Min. DC10mV 10 μ A
20	CHOUT1	O	Dry	DC30V 0.4A	Min. DC10mV 10 μ A
21	CHOUT2	O	Dry	DC30V 0.4A	Min. DC10mV 10 μ A
22	CHOUT3	O	Dry	DC30V 0.4A	Min. DC10mV 10 μ A
23	CHOUT4	O	Dry	DC30V 0.4A	Min. DC10mV 10 μ A
24	CHOUT5	O	Dry	DC30V 0.4A	Min. DC10mV 10 μ A
25	CHOUT6	O	Dry	DC30V 0.4A	Min. DC10mV 10 μ A
26	EMOUT	O	Dry	600V 10A	Min. AC/DC3V 5mA
27	ZRN2	I	Dry or Tr	DC24V 10mA	
28	G99FIN2	O	Dry	DC30V 0.4A	Min. DC10mV 10 μ A
29	360FIN2	O	Dry	DC30V 0.4A	Min. DC10mV 10 μ A
30	ZRNFIN2	O	Dry	DC30V 0.4A	Min. DC10mV 10 μ A

The marking part in the above columns shows the additional spec., data for MAC mini iH2 / iHT. MAC mini iH / iHF / iHP have not spec., data.


9.2.1. Output format



The electric specifications for output contact are within values specified to PELV (Protection Ultra Low Voltage) and the following specifications are to be observed.

Max. switching voltage	25V ACrms / 30V DC
Max. switching current	1A
Max. switching capacity	DC24W, AC25VA
Min. applicable load	DC1V 1mA


9.2.2 Output format for clamp



- Clamp output specification

Output rating	DC24V $\pm 10\%$ 0.5A
---------------	-----------------------

9.2.3. Emergency stop output format



- Contact specifications for emergency stop push button


Rated insulation voltage	600V
Rated current	10A
Min. applicable load	AC/DC3V 5mA

9.3. Precautions using I/O circuit


When the load connected to the output mode is an inductive load, it is possible to reduce noise by providing the surge killer such as diode, barrister, CR, etc.

- When the power used for the inductive load is DC (Direct Current), use the surge killer of diode type (Fig. A).
- When the power used for the inductive load is AC (Alternating Current), use the surge killer of CR type (Fig. B).
- ※ Unless the surge killer is inserted, the service life of contact is shortened or noise occurs. Be sure to insert the surge killer so as not to cause malfunction or damage.

(A) Protection by diode




(B) Protection by CR




Use electric apparatuses within rated range.

10. Detailed External Connection (CB3i cable)

10.1. MAC mini iH / iHF / iHP type



10.2. MAC mini iH2 / iHT type



11 RS232C Connection


11.1. Detailed RS232C connector

The following shows the detailed RS232C connector installed on the controller.

Pin No.	Signal Name	Description	I/O
1	CD	Carrier detection	OUTPUT
2	RD	Receiving data	INPUT
3	SD	Transmitting data	OUTPUT
4	ER	Ready on controller	OUTPUT
5	SG	Grounding for signal	
6	DR	Data setting ready	INPUT
7	RS	Transmitting request (Signal showing communicability to external equipment.)	OUTPUT
8	CS	Transmittable (Signal permitting transmission from external equipment.)	INPUT
9			

11.2. Detailed RS232C cable wiring

Two types of 25-pin type and 9-pin type are described on the external equipment side for cables.



If communication fails because of noise, etc., disconnect either SG cable.

12 Connection to Machine


12.1. Machine connection wiring

The system receives and transmits the start signal (M-signal) and 1 block finish signal from/to the external equipment.

In addition to the above, since the following signals can be communicated, be sure to route the cables for their signals.

- ★ **START (ST)**
The program is executed by this signal during “AUTO” or “SINGLE” mode.
- ★ **STOP (SP)**
Though this signal is used as a temporary stop signal of program, since SP signal is B-contact specification even if this function is not used, it is necessary to be short-circuited with INCOM line.
- ★ **EXTERNAL EMERGENCY STOP (EXTEM)**
This signal is used for inputting the emergency stop from the external equipment.
- ★ **INPUT COMMON (INCOM)**
This the common line for an input signal.
- ★ **1 BLOCK FINISH (BLKFIN)**
This signal is outputted when 1 block motion is finished during “AUTO” mode.
- ★ **1 BLOCK FINISH COMMON (BLKFINCOM)**
This is the common for 1 block finish output signal.
- ★ **ALARM OUTPUT B (ALMOUTB)**
This is for issuing the alarm signal on the circular table side.
- ★ **OUTPUT COMMON (OUTCOM)**
This is the common for output signal.
- ★ **EMERGENCY STOP OUTPUT (EMOUT)**
This is for outputting the emergency stop button state of controller.
- ★ **EMERGENCY STOP OUTPUT COMMON (EMOUTCOM)**
This is the common for emergency stop output signal.

12.2. Machine connecting example




- Input B-contact for SP signal. When the SP signal is not used, short-circuit the connection between SP and INCOM.
- When the external emergency stop mode is inputted, input EXTEM signal at B-contact.


When these two input signals are not turned ON, the program does not run.

13 Block Diagram

13.1. MAC mini iH / iHF Block diagram



13.2. MAC mini iH2 / iHT Block diagram




PARTS LIST

C o n t e n t s

1	MAC mini iH / iHF Parts List	A1-1
1.1.	Arrangement view	A1-1
1.2.	Controller unit	A1-2
1.3.	Servo motors	A1-2
2	MAC mini iH2 / iHT Parts List	A2-1
2.1.	Arrangement view	A2-1
2.2.	Controller unit	A2-2
2.3.	Servo motors	A2-3
3	Pendant Parts List	A3-1
3.1.	Arrangement view	A3-1
3.2.	Pendant unit	A3-2

1 MAC mini iH / iHF Parts List

1.1. Arrangement view



1.2. Controller unit


NO.	Code	Parts Name	Type	Maker	Q'ty	Remarks
1	PDT	Pendant	-	KITAGAWA	1	
2	PB1	Control substrate	PB001-H001B	KITAGAWA	1	
3	PB3	Control substrate	PB008-H001-A	KITAGAWA	1	
4	CP1	Circuit protector	CP22RM/5-B1	FUJI DENKI	1	MAC mini iHF
			CP22RM/10-B1	FUJI DENKI		MAC mini iH
5		CP1 cover	136029-J020-A	KITAGAWA	1	
6	SV1	Servo amplifier	SGDS-04A01A	YASKAWA	1	MAC mini iHF
			SGDS-08A01A	YASKAWA		MAC mini iH
7	NF1	Nozzle filter	MBS-1210-22	DENSEI-LAMBDA	1	
8	NF2	Nozzle filter	MBW-1203-22	DENSEI-LAMBDA	1	
9	F1 , F2	Ferrite core	ZCAT3035-1330	TDK	2	
10	MC1	Magnet conductor	SJ-0G DC24V 1a	FUJI DENKI	1	
11	AVR1	DC power AC200V/DC5V	LDA10F-5	COSEL	1	
12	AVR2	DC power AC200V/DC24V	LDA30F-10	COSEL	1	
13	FAN	Fan	PUDC24D4	NIPPON SERVO	1	
14	FAN-C	Fan cover	F-80	NIPPON SERVO	2	Renewal parts
15	SK1 ~ SK3	Surge protection element	ENE471D-14A	FUJI DENKI	3	
16	SK4	Spark killer	RE1201	OKAYA	1	
17		Mounting legs	CP-30-FF-4A	TAKIGEN	4	
18		Mounting hole plug	OB-13	IZUMI	1	
19	RS232C	D-Sub25 connector	HDEB-9P	HIROSE	1	
20		D-Sub25 connector cover	DE-60-J2	JAPAN Aviation Electronics Industry	1	
21	CN1	CN1 housing	CZI06L	ILME JAPAN	1	
22		CN1 connector	CDDF24	ILME JAPAN	1	
23		CN1 pin	CDMF0.3	ILME JAPAN	18	
24		CN1 pin	CDFM1.0	ILME JAPAN	4	
25	CB2-C	Hole plug	CP-30-HP-10	ILME JAPAN	1	
26	CB3-C	CB3 connector	NYS5-15B	DAIWA	1	
27	CB4-C	CB4 connector	NYS5-8B	DAIWA	1	
28	K100-C	CB100 connector	NYS5-8B	DAIWA	1	

1.3. Servo motors

NO.	Code	Parts Name	Type	Maker	Q'ty	Remarks
	SVM1	Servo motor	SGMPS-04A2A6S	YASKAWA	1	MAC mini iHF
			SGMAS-08A2A6S	YASKAWA		MAC mini iH
	BAT1	Battery	JZSP-BA01	YASKAWA	1	

2 MAC mini iH2 / iHT Parts List

2.1. Arrangement view



2.2. Controller unit


NO	Code	Parts Name	Type	Maker	Q'ty	Remarks
1	PDT	Pendant	-	KITAGAWA	1	
2	PB1	Control substrate	PB001-H001B	KITAGAWA	1	
3	PB2	2-axis substrate	PB004-H001B	KITAGAWA	1	
4	PB3	Control substrate	PB008-H001-A	KITAGAWA	1	
5	CP1	Circuit protector	CP22RM/15-B1	FUJI DENKI	1	
6		CP1 cover	136029-J020-A	KITAGAWA	1	
7	SV1	Servo amplifier	SGDS-04A01A	YASKAWA	1	MAC mini iHT
			SGDS-08A01A	YASKAWA		MAC mini iH2
8	SV2	Servo amplifier	SGDS-08A01A	YASKAWA	1	
9	NF1	Nozzle filter	MBS-1220-22	DENSEI-LAMBDA	1	
10	NF2	Nozzle filter	MBW-1203-22	DENSEI-LAMBDA	1	
11	F1 ~ F3	Ferrite core	ZCAT3035-1330	TDK	3	
12	MC1	Magnet conductor	SJ-0G DC24V 1a	FUJI DENKI	1	
13	AVR1	DC power AC200V/DC5V	LDA10F-5	COSEL	1	
14	AVR2	DC power AC200V/DC24V	LDA75F-10	COSEL	1	
15	FAN	Fan	PUDC24D4	NIPPON SERVO	1	
16	FAN-C	Fan cover	F-80	NIPPON SERVO	2	Renewal parts
17	SK1 ~ SK3	Surge killer	ENE471D-14A	FUJI DENKI	3	
18	SK4	Spark killer	RE1201	OKAYA	1	
19	C1	Condenser	1 μ f	TAKIGEN	1	
20	C2 ~ C3	Condenser	0.22 μ F	IZUMI	2	
21		Mounting legs	CP-30-FF-4A	TAKIGEN	4	
22		Mounting hole plug	OB-13	IZUMI	1	
23	RS232C	D-Sub25 connector	HDEB-9P	HIROSE	1	
24		D-Sub25 connector cover	DE-60-J2	JAPAN Aviation Electronics Industry	1	
25	CN1	CN1 housing	CZI06L	ILME JAPAN	1	
26		CN1 connector	CDDF24	ILME JAPAN	1	
27		CN1 pin	CDMF0.3	ILME JAPAN	18	
28		CN1 pin	CDFM1.0	ILME JAPAN	4	
29	CN2	CN2 housing	CZI06L	ILME JAPAN	1	
30		CN2 connector	CDDF24	ILME JAPAN	1	
31		CN2 pin	CDMF0.3	ILME JAPAN	18	
32		CN2 pin	CDFM1.0	ILME JAPAN	4	
33	CB2-C	Hole plug	CP-30-HP-10	TAKIGEN	2	
34	CB3-C	CB3 connector	NYS5-17B	DAIWA	1	
35	CB4-C	CB4 connector	NYS5-11B	DAIWA	1	
36	K100-C	CB100 connector	NYS5-8B	DAIWA	1	

2.3. Servo motors

NO	Code	Parts Name	Type	Maker	Q'ty	Remarks
	SVM1	Servo motor	SGMPS-04A2A6S	YASKAWA	1	MAC mini iHT
			SGMAS-08A2A6S	YASKAWA		MAC mini iH2
	SVM2	Servo motor	SGMAS-08A2A6S	YASKAWA	1	
	BAT1	Battery	JZSP-BA01	YASKAWA	1	
	BAT2	Battery	JZSP-BA01	YASKAWA	1	

3 Pendant Parts List

3.1. Arrangement view



3.2. Pendant Unit

No.	Code	Parts Name	Type	Maker	Q'ty	Remarks
1	PPB1	Pendant substrate	PB006-H001B	KITAGAWA	1	
2	EPB1	Emergency stop switch	AH165-V5R02	FUJI DENKI	1	
3	ESW1	ENABLE switch	HE3B-M2P	IZUMI DENKI	1	
4	LCD	LCE	PVC200203P	PICVUE	1	
5	CB2-C	Hole plug	HP-8	MISMI	1	
6	F10	Ferrite core	ESD-SR-16	NEC TOKIN	1	